

Manuals.plus /
› Sun Joe /
› Sun Joe SPX2004-90DEG 90 Degree Nozzle Instruction Manual

Sun Joe SPX2004-90DEG

Sun Joe SPX2004-90DEG 90 Degree Nozzle Instruction Manual

Model: SPX2004-90DEG | Brand: Sun Joe

PRODUCT OVERVIEW

The Sun Joe SPX2004-90DEG is a genuine replacement 90-degree nozzle designed specifically for Sun Joe SPX2003-SJH and SPX2004 Series Electric Pressure Washers. This accessory is essential for reaching difficult angles and ensuring effective cleaning with your compatible pressure washer.



Image: The Sun Joe SPX2004-90DEG 90-degree replacement nozzle, shown from a side angle, highlighting its angled design and connection point.

IMPORTANT SAFETY INFORMATION

Always disconnect the pressure washer from the power supply and water source before performing any maintenance, installation, or replacement of parts. Wear appropriate personal protective equipment, including eye protection, when working with pressure washers and their accessories. Ensure all connections are secure to prevent leaks and accidental disconnections during operation.

COMPATIBILITY

This 90-degree replacement nozzle is exclusively designed for use with the following Sun Joe Electric Pressure Washer models:

- Sun Joe SPX2003-SJH Series Electric Pressure Washers
- Sun Joe SPX2004 Series Electric Pressure Washers

Using this nozzle with incompatible pressure washer models may result in improper function or damage.

INSTALLATION GUIDE

1. **Preparation:** Ensure your Sun Joe pressure washer is turned off, unplugged from the power outlet, and disconnected from the water supply. Release any residual pressure in the system by squeezing the trigger gun.
2. **Remove Existing Nozzle (if applicable):** If replacing an old nozzle, firmly grasp the existing nozzle and twist it counter-clockwise to detach it from the spray wand or gun.
3. **Attach New Nozzle:** Align the new Sun Joe SPX2004-90DEG 90-degree nozzle with the end of your pressure washer's spray wand or gun. Push it in firmly and twist clockwise until it clicks securely into place. Ensure it is fully seated and does not wobble.
4. **Check Connection:** Gently tug on the nozzle to confirm it is securely attached. A loose connection can lead to leaks or the nozzle detaching during use.
5. **Test:** Reconnect the water supply and power to your pressure washer. Briefly run the pressure washer to check for any leaks around the nozzle connection point.



Image: A close-up view of the Sun Joe 90-degree nozzle's connection end, illustrating the mechanism for attachment to a pressure washer wand.

OPERATING THE 90-DEGREE NOZZLE

Once installed, the 90-degree nozzle allows you to direct the high-pressure spray at an angle, making it ideal for cleaning hard-to-reach areas such as undercarriages of vehicles, gutters, wheel wells, or the underside of lawnmowers. Simply aim the nozzle and activate your pressure washer as you normally would.

Note: The 90-degree angle provides a concentrated spray pattern. Always maintain a safe distance from the surface being cleaned to avoid damage, especially on delicate materials.

MAINTENANCE

To ensure optimal performance and longevity of your 90-degree nozzle:

- **Rinse After Use:** After each use, rinse the nozzle thoroughly with clean water to remove any dirt, debris, or chemical residues.
- **Inspect for Clogs:** Periodically check the nozzle opening for any blockages. If clogged, use a small pin or the included nozzle cleaning tool (if provided with your pressure washer) to clear the obstruction.
- **Store Properly:** Store the nozzle in a clean, dry place away from extreme temperatures.

- **Check for Wear:** Inspect the nozzle for any signs of wear, cracks, or damage. A worn nozzle can affect spray pattern and pressure. Replace if damaged.



Image: The Sun Joe 90-degree nozzle, viewed from an angle that clearly shows the spray opening, which should be kept clear of debris.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No water or low pressure from nozzle.	Nozzle is clogged.	Clear the nozzle opening with a small pin or cleaning tool.
Water leaking from nozzle connection.	Nozzle not securely attached or O-ring is damaged.	Ensure nozzle is fully seated and twisted clockwise until secure. Inspect and replace O-ring if damaged.
Inconsistent spray pattern.	Partial clog or worn nozzle.	Clean the nozzle. If problem persists, the nozzle may be worn and require replacement.

PRODUCT SPECIFICATIONS

Model:	SPX2004-90DEG
Product Type:	Replacement 90 Degree Nozzle
Material:	Metal
Compatibility:	Sun Joe SPX2003-SJH/SPX2004 Series Electric Pressure Washers

Item Dimensions (L x W x H): 1 x 1 x 1 inches (Nozzle only)

Item Weight: 2.82 ounces

Package Dimensions (L x W x H): 4.48 x 4.40 x 2.20 inches

Package Weight: 0.17 Pounds

WARRANTY AND CUSTOMER SUPPORT

Specific warranty information for this replacement part was not provided in the product data. For detailed warranty terms and conditions, or for customer support inquiries, please refer to the official Sun Joe website or contact Sun Joe customer service directly.

You can often find support resources and contact information on the [Sun Joe Brand Store on Amazon](#) or by visiting the manufacturer's official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BGJMQDNT>

More documents and user manuals: <https://manuals.plus/>