

[Manuals.plus](#) /

› [KCO](#) /

› KCO Lighting Mid Century Modern Semi Flush Mount Ceiling Light Fixture Farmhouse Black Globe Sputnik Chandelier Ceiling Light 4-Light Milk Glass Hallway Ceiling Light Black 4 Light User Manual

KCO C1027-B-4

KCO Lighting Mid Century Modern Semi Flush Mount Ceiling Light Fixture

INSTRUCTION MANUAL

Brand: KCO | Model: C1027-B-4

1. Introduction

Thank you for purchasing the KCO Lighting Mid Century Modern Semi Flush Mount Ceiling Light Fixture. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new lighting fixture. Please read this manual thoroughly before beginning installation and retain it for future reference.

2. Safety Information

WARNING: To avoid the risk of electrical shock, always disconnect power at the circuit breaker or fuse box before beginning installation or performing any maintenance. All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). If you are unfamiliar with proper electrical wiring connections, consult a qualified electrician.

- Do not install this fixture in wet or damp locations. It is designed for indoor use only.
- Ensure the mounting surface can support the weight of the fixture.
- Use only G9 base bulbs with a maximum wattage of 60W.
- Do not exceed the maximum wattage specified.
- Handle glass components with care to prevent breakage.

3. Package Contents

Carefully unpack your fixture and check that all parts are included. Keep the packaging materials until you are sure all parts are present and the fixture is working correctly.

- Light Fixture Body (Matte Black)
- Frosted White Glass Globe Shades (4 pieces)

- Mounting Hardware Kit (includes mounting bracket, screws, wire nuts)
- G9 Base Bulbs (4 pieces)
- Instruction Manual

PRODUCT DETAILS




Figure 3.1: Product Details and Components

4. Setup and Installation

Before installation, ensure the power is turned off at the circuit breaker. This fixture is designed for semi-flush mount installation on a ceiling.

1. **Prepare for Installation:** Turn off the power to the junction box at the circuit breaker. Remove the existing fixture if applicable.
2. **Attach Mounting Bracket:** Secure the mounting bracket to the junction box using the provided screws. Ensure the bracket is firmly attached and level.
3. **Make Electrical Connections:** Connect the fixture's wires to the corresponding wires from the junction box using the provided wire nuts. Connect the black wire (live) to the black wire, the white wire (neutral) to the white wire, and the ground wire to the ground wire. Ensure all connections are secure.
4. **Mount the Fixture:** Carefully push the wired connections into the junction box. Align the fixture body with the

mounting bracket and secure it with the canopy screws.

5. **Install Glass Shades and Bulbs:** Screw the G9 base bulbs into the sockets. Carefully attach the frosted glass globe shades to the fixture arms. Ensure they are securely fastened.



Figure 4.1: Installed Fixture in a Hallway



Figure 4.2: Installed Fixture in a Bedroom

5. Operating Instructions

Once installed, restore power at the circuit breaker. The fixture is now ready for use.

- **Turning On/Off:** Operate the light fixture using a standard wall switch connected to the circuit.
- **Dimmable Functionality:** This fixture is fully dimmable when used with dimmable G9 bulbs and a compatible dimmer switch (bulbs and dimmer switch are not included). You can adjust the light intensity to create your desired ambiance.
- **Bulb Compatibility:** The fixture uses G9 base bulbs. Ensure replacement bulbs do not exceed 60 watts per bulb.



Figure 5.1: Lighting Effects (Turn Off vs. Turn On)

DIMMABLE



Figure 5.2: Dimmable Feature and Color Temperature Options (with compatible bulbs)

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your light fixture.

- **Cleaning:** Always turn off the power and allow the fixture to cool before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or glass.
- **Bulb Replacement:** Ensure the power is off and bulbs have cooled. Unscrew the old G9 bulb and replace it with a new one of the same type and wattage (max 60W). Handle glass globes carefully during this process.

7. Troubleshooting

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on	No power to fixture; Loose wiring; Faulty bulb; Faulty switch	Check circuit breaker/fuse; Verify all wire connections are secure; Replace bulb; Test/replace switch.
Light flickers	Loose bulb; Incorrect bulb type; Loose wiring; Incompatible dimmer switch	Tighten bulb; Ensure G9 base and correct wattage; Check wiring; Use a compatible dimmer switch if applicable.
One or more globes not lighting	Faulty bulb in that globe; Loose connection at the socket; Damaged socket/arm	Replace the bulb in the affected globe; Ensure bulb is fully seated in the socket. If issue persists, contact customer service for assistance.

If you are unable to resolve the issue after following these steps, please contact KCO Lighting customer service for further assistance.

8. Specifications

Feature	Detail
Brand	KCO
Model Name	C1027-B-4
Color	Black 4 Light
Material	Glass, Metal
Style	Mid-Century Modern
Light Fixture Form	Close to Ceiling / Semi Flush Mount
Product Dimensions (L x W x H)	19.7" x 19.7" x 11.8" (50cm x 50cm x 30cm)
Glass Globe Diameter	5.9" (15cm)
Canopy Diameter	4.7" (12cm)
Power Source	AC
Voltage	110 Volts
Bulb Base	G9
Maximum Compatible Wattage	60 Watts (per bulb)
Number of Light Sources	4
Assembly Required	Yes
Item Weight	6.69 pounds

PRODUCT DIMENSIONS


BLUBS NOT INCLUDED



60W MAX



110-240V



G9 BASE



DIMMABLE



HARDWIRED




Figure 8.1: Product Dimensions

9. Warranty and Support

KCO Lighting is committed to providing high-quality products and excellent customer service.

- **3-Year Warranty:** We offer a 3-year warranty for this light fixture. If you receive broken, damaged, or cracked glass globe shades, or if any parts are missing or defective, please contact us for a free replacement.
- **Professional After-Sales Service:** Our customer service team is available to assist you with any questions or issues you may encounter. Please contact us via your order number, and we will provide a solution within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the KCO Lighting official store page.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BGKCDJQ9>

More documents and user manuals: **<https://manuals.plus/>**