## Snailax SL-591-APP

# Snailax Vibration Foot Massager with Heat User Manual

Model: SL-591-APP | Brand: Snailax

## 1. Product Overview

The Snailax Vibration Foot Massager with Heat is designed to provide relief and relaxation for your feet, calves, and even your back. It features adjustable vibration intensity, optional heat therapy, and convenient control methods including a remote control and a smartphone application. This device aims to improve circulation, alleviate fatigue, and promote overall well-being.




Image: The Snailax Vibration Foot Massager, highlighting its compact design and app control capability.

## 2. Safety Information

Please read all safety warnings and instructions carefully before using this product to ensure safe operation and prevent injury or damage.

- **Electrical Safety:** Always ensure the power cord and plug are in good condition. Do not use if damaged. Disconnect from power outlet when not in use or before cleaning. Keep away from water.
- **Proper Usage:** Do not stand on the massager. Use while seated. Ensure proper body positioning to avoid strain.
- **Heat Function:** Use the heat function with caution, especially if you have sensitive skin or circulation issues. Avoid prolonged use of heat on one area to prevent burns.
- **Contraindications:** Consult a physician before use if you have medical conditions such as heart disease, diabetes, phlebitis, thrombosis, or if you are pregnant. Do not use on swollen, inflamed, or injured areas.
- **Children and Pets:** Keep out of reach of children and pets. This device is not a toy.

*Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to*

*diagnose, treat, cure, or prevent any disease or health condition. This product is not a medical device.*

## 3. Setup

### 3.1 Unboxing and Components

Carefully remove all components from the packaging. Verify that all items are present:

- Snailax Foot Massager Unit
- Remote Control (with 1 C battery included)
- Home Adapter (Power Cord)
- Dust Cover
- User Manual (this document)




Image: Contents included in the Snailax Foot Massager package.

### 3.2 Power Connection

Connect the home adapter to the power input port on the massager unit. Plug the adapter into a standard electrical outlet. Ensure the connection is secure.

### 3.3 Smartphone App Control Setup

The Snailax Foot Massager can be controlled via the "SNAILAX" smartphone application. Follow these steps to set up the app:

1. **Download App:** Search for "SNAILAX" in your smartphone's app store (iOS App Store or Google Play Store) and download the application.
2. **Register:** Open the app and follow the on-screen instructions to register an account.
3. **Connect to Bluetooth:** Ensure your smartphone's Bluetooth is enabled. The app will guide you to connect to the massager via Bluetooth.
4. **Add Device:** Within the app, select the option to add a new device and choose your Snailax Foot Massager.
5. **Start Using:** Once connected, you can control all functions of the massager directly from your smartphone.




Image: Visual guide for setting up the Snailax smartphone application.

## 4. Operating Instructions

### 4.1 Power On/Off

Press the power button on the massager unit or the remote control to turn the device on or off. The device will typically start in a default massage mode.

### 4.2 Massage Modes and Intensity

The massager offers 3 massage modes and 3 levels of vibration intensity. Use the corresponding buttons on the unit, remote, or app to cycle through these options:

- **Modes:** Select from various vibration patterns to suit your preference.
- **Intensity Levels:** Adjust the strength of the vibration (Level 1: Low, Level 2: Medium, Level 3: High).




Image: Illustration of the three vibration intensity levels available on the massager.

### 4.3 Heat Function

Activate the optional heat function for added comfort and improved circulation. There are 2 heating levels available. Press the heat button to toggle the heat on/off or adjust the level.




Image: Depiction of the soothing heat function warming the feet.

### 4.4 Multi-Purpose Use

The Snailax Foot Massager is versatile and can be used for various body parts while seated:

- **Feet:** Place your feet on the massage pads for foot relaxation.
- **Calves:** Position your calves on the unit for leg muscle relief.
- **Back:** Place the unit behind your lower back while seated for back massage.




Image: Examples of using the massager for feet, calves, and back.

### 4.5 Session Duration

The default session duration is 15 minutes. The device will automatically shut off after this period. It is recommended to use the massager for up to 3 cycles (45 minutes total) per day.

## 5. Maintenance

Proper maintenance ensures the longevity and hygiene of your Snailax Foot Massager.

- **Cleaning:** Always unplug the device before cleaning. Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Dust Cover:** Use the provided dust cover when the massager is not in use to protect it from dust and debris. The cover is washable for easy maintenance.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight and extreme temperatures.

## 6. Troubleshooting

If you encounter issues with your Snailax Foot Massager, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Device does not turn on. | Not plugged in; power outlet issue; power button not pressed correctly. | Ensure power cord is securely plugged into the unit and a working outlet. Press the power button firmly. |
| No vibration or weak vibration. | Intensity set too low; internal malfunction. | Increase the vibration intensity level. If issue persists, contact customer support. |
| Heat function not working or too weak. | Heat function not activated; low heat setting; internal malfunction. | Ensure heat function is turned on and set to a higher level. Note that heat is gentle and not intended to be intense. If issue persists, contact customer support. |
| Remote control not responding. | Battery drained; obstruction between remote and unit. | The remote control comes with a C battery included. If it stops working, replace the battery. Ensure no obstructions are blocking the signal. |
| Smartphone app not connecting. | Bluetooth off; app not updated; device not paired. | Ensure Bluetooth is enabled on your phone and the massager is powered on. Restart the app and try re-pairing the device. |

For issues not listed here, please contact Snailax customer support.

## 7. Specifications

| Feature | Detail |
|---|---|
| Product Dimensions | 12.8 x 4.33 x 16.46 inches |
| Item Weight | 7 Pounds (3.18 Kilograms) |
| Item Model Number | SL-591-APP |
| Power Source | Corded Electric |
| Batteries (Remote) | 1 C battery (included) |
| Brand | Snailax |
| Color | Black and Orange |
| Massage Modes | 3 Vibration Modes |
| Intensity Levels | 3 Vibration Intensity Levels |
| Heat Levels | 2 Optional Heating Levels |
| Control Methods | Remote Control, Smartphone App |

## 8. Warranty and Support

The Snailax Vibration Foot Massager comes with a standard **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.
You may be able to extend your warranty to **3 years** by registering your product. Please refer to the product packaging or the Snailax official website for details on warranty registration.
For technical support, warranty claims, or any questions regarding your product, please contact Snailax customer service:

**Website:** www.snailax.com (Please check the official website for the most current contact information.)

**Email:** Refer to the Snailax website or product packaging for customer support email.

When contacting support, please have your model number (SL-591-APP) and proof of purchase readily available.

© 2023 Snailax. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question