

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Honor Choice](#) /
- › [Honor Choice Earbuds X3 Lite Wireless Earphones User Manual](#)

Honor Choice X3 Lite

Honor Choice Earbuds X3 Lite Wireless Earphones User Manual

Model: X3 Lite | Brand: Honor Choice

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Honor Choice Earbuds X3 Lite Wireless Earphones. Please read this manual thoroughly before using the product and retain it for future reference.



Image: Honor Choice Earbuds X3 Lite, white, resting in their open charging case. The earbuds are visible, showing their in-ear design and stems.

PACKAGE CONTENTS

- Honor Choice Earbuds X3 Lite (Left and Right Earbuds)
- Charging Case
- USB Type-C Charging Cable
- User Manual (this document)

IMPORTANT SAFETY INFORMATION

- Do not expose the device to extreme temperatures or direct sunlight.
- Avoid using the earbuds at high volume levels for extended periods to prevent hearing damage.
- Keep the device away from water and moisture, except for its IPX4 water resistance. Do not submerge.

- Do not attempt to disassemble or repair the device yourself. Contact authorized service personnel.
- Dispose of batteries and electronic components responsibly according to local regulations.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case.
2. Connect the USB Type-C charging cable to the charging port on the case and to a power source.
3. The indicator light on the charging case will show charging status. A full charge provides up to 28 hours of total battery life with the case, and 6 hours of listening time on a single earbud charge.



Image: An hourglass graphic illustrating the battery life of the Honor Choice Earbuds X3 Lite. It shows "28 HR of battery life with charging case" and "6 HR of listening time on one charge," with multiple earbuds circling the hourglass.

2. Initial Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "HONOR CHOICE Earbuds X3 Lite" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

OPERATING INSTRUCTIONS

Touch Controls

The earbuds feature touch controls for various functions. Specific gestures can be customized via the HONOR AI Space App.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud.
- **Activate Voice Assistant:** Triple tap on either earbud (customizable).
- **Game Mode:** Tap to enter Game Mode for 73ms ultra-low latency.

Dual-Device Connection

The earbuds support simultaneous connection to two devices, allowing for seamless switching between them.

1. Pair the earbuds with the first device as described in the "Initial Pairing" section.
2. Disconnect the earbuds from the first device's Bluetooth settings (do not unpair).
3. Pair the earbuds with the second device.
4. Reconnect the earbuds to the first device from its Bluetooth settings. The earbuds will now be connected to both devices.
5. Audio will automatically switch to the device playing content or receiving a call.



Two devices are connected at the same time
seamless switching is freer

Image: A man wearing Honor Choice Earbuds X3 Lite, looking at a laptop while holding a smartphone. This illustrates the dual-device connection feature, allowing seamless switching between two connected devices.

HONOR AI Space App

Download the HONOR AI Space App for additional features and customization:

- **OTA Updates:** Receive firmware updates for improved performance and new features.
- **Custom Settings:** Personalize touch controls and sound effects.
- **Battery Status:** View real-time battery levels for each earbud and the charging case.

Noise Cancellation for Calls

The earbuds feature dual microphones and an AI ENC (Environmental Noise Cancellation) algorithm to reduce background noise during calls, ensuring clear communication.




Image: A man wearing Honor Choice Earbuds X3 Lite, holding a smartphone to his ear, in an outdoor setting. Text overlay indicates "AI ENC Noise Cancelling" and "Accurately eliminate environmental noise, Create an immersive listening experience."

MAINTENANCE

Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the earbud tips and speaker mesh using a small, soft brush or cotton swab.

Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.

Water Resistance (IPX4)

The Honor Choice Earbuds X3 Lite are rated IPX4 for water resistance, meaning they are protected against splashing water from any direction. This makes them suitable for exercise and light rain.

- Do not submerge the earbuds in water.
- Do not expose them to pressurized water or high-velocity water, such as showering or swimming.
- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.




Image: A man intensely exercising, wearing Honor Choice Earbuds X3 Lite. Text overlay states "Water Resistance" and "Provide Seal Protection for Your Music Life When you Exercise," indicating their suitability for workouts.

TROUBLESHOOTING

Earbuds not pairing or connecting

- Ensure the earbuds and charging case are sufficiently charged.

- Make sure Bluetooth is enabled on your device.
- Place the earbuds back into the charging case, close the lid, wait a few seconds, then open it again to re-enter pairing mode.
- If previously paired, try forgetting the device ("HONOR CHOICE Earbuds X3 Lite") from your device's Bluetooth settings and then re-pair.
- Try restarting your source device (phone, tablet).

No sound or poor sound quality

- Check the volume level on both your earbuds and your connected device.
- Ensure the earbuds are properly seated in your ears.
- Clean any debris from the earbud speaker mesh.
- Move closer to your connected device to avoid interference.
- Try disconnecting and reconnecting the earbuds.

Earbuds not charging

- Ensure the charging cable is securely connected to both the case and the power source.
- Verify that the power source is active.
- Check for any debris in the charging port of the case or on the charging contacts of the earbuds.
- Try using a different USB Type-C cable and power adapter.

SPECIFICATIONS

Feature	Detail
Product Name	HONOR CHOICE Earbuds X3 Lite
Model	WT50106-01 (X3 LITE)
Color	White
Bluetooth Version	BT 5.3
Bluetooth Codec	AAC/SBC
Earbud Battery Capacity	45mAh (Typical)
Charging Case Battery Capacity	500mAh (Typical)
Charging Port	USB Type-C
Water Resistance Rating	IPX4
Single Earbud Dimensions	33.8mm x 17.7mm x 15.8mm
Case Dimensions	64.7mm x 52.9mm x 27mm
Item Weight	47 Grams (total)
Audio Driver Size	10mm Dynamic Driver
Audio Latency	73 Milliseconds (Game Mode)
Control Method	Touch Control, App

Feature	Detail
Included Components	Wireless Charging Case

WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please refer to the official Honor Choice website or contact your local retailer. Specific warranty terms may vary by region.

No specific warranty duration or contact information is provided within this document.