

[Manuals.plus](#) /

› [TW Steel](#) /

› TW Steel CE4104 CEO Tech Chronograph Watch User Manual

TW Steel CE4104

TW Steel CE4104 CEO Tech Chronograph Watch User Manual

Model: CE4104

1. INTRODUCTION

This user manual provides comprehensive instructions for the operation, maintenance, and care of your TW Steel CE4104 CEO Tech Chronograph Watch. Please read this manual thoroughly before using your watch to ensure proper function and longevity.

The TW Steel CE4104 is a robust chronograph watch designed for precision timekeeping and durability, featuring a 44mm case and a 10 ATM water resistance rating suitable for swimming and snorkeling.

2. PRODUCT OVERVIEW



Figure 2.1: Front view of the TW Steel CE4104 watch, highlighting the black dial, silver case,

and chronograph subdials with red accents.



Figure 2.2: Angled view of the TW Steel CE4104 watch, providing a perspective of the watch face and the side profile of the case and crown.



Figure 2.3: Side view of the TW Steel CE4104 watch, detailing the crown and pushers located on the right side of the watch case.



Figure 2.4: Back view of the TW Steel CE4104 watch, displaying the engraved case back and the attached watch strap.

Key Features:

- **Model:** TW Steel CE4104 Men's Watch
- **Crystal:** Mineral glass for durability and scratch resistance.
- **Clasp:** Buckle clasp for secure fastening.
- **Water Resistance:** 10 ATM (suitable for swimming and snorkeling).
- **Movement:** Chronograph movement for precise time measurement.

3. SETUP

3.1 Initial Time Setting

1. **Unscrew the Crown:** If your watch has a screw-down crown, gently unscrew it counter-clockwise until it pops out to position 1.
2. **Pull Crown to Position 2:** Carefully pull the crown out to the second click position (Position 2). This is typically for setting the time.
3. **Set Time:** Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
4. **Push Crown Back:** Once the time is set, push the crown back into Position 0. If it's a screw-down crown, gently push and screw it back in clockwise to ensure water resistance.

3.2 Date Setting (if applicable)

1. **Pull Crown to Position 1:** If your watch has a screw-down crown, unscrew it first. Then, pull the crown out to the first click position (Position 1).
2. **Set Date:** Rotate the crown to adjust the date. Be careful not to set the date between 9 PM and 3 AM, as this can damage the movement.
3. **Push Crown Back:** Push the crown back into Position 0 and screw it down if applicable.

4. OPERATING THE CHRONOGRAPH

The chronograph function allows you to measure elapsed time independently of the main time display.

4.1 Chronograph Buttons

- **Button A (Top Pusher):** Starts and stops the chronograph.
- **Button B (Bottom Pusher):** Resets the chronograph to zero.

4.2 Using the Chronograph

1. **Start:** Press Button A to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press Button A again to stop the chronograph. The elapsed time will be indicated by the chronograph hands (seconds, minutes, and hours, depending on the movement).
3. **Reset:** After stopping the chronograph, press Button B to reset all chronograph hands to their zero positions.
4. **Lap Time (if applicable):** Some chronographs allow for lap time measurement. Consult specific movement instructions if this feature is desired.

5. MAINTENANCE AND CARE

Proper care will ensure the longevity and performance of your TW Steel watch.

- **Cleaning:** Wipe the watch case and strap regularly with a soft, dry cloth. For water-resistant models, a slightly damp cloth can be used, but ensure the crown is fully pushed in and screwed down (if applicable).
- **Water Resistance:** The CE4104 is rated 10 ATM. This means it is suitable for swimming and snorkeling. *Do not operate the crown or pushers while the watch is wet or submerged.* Avoid hot water, steam, and sudden temperature changes, as these can compromise water seals.
- **Temperature:** Avoid exposing your watch to extreme temperatures (above 60°C / 140°F or below 0°C / 32°F) or sudden temperature changes.
- **Shocks:** While durable, avoid strong impacts or shocks to the watch.
- **Chemicals:** Keep the watch away from solvents, detergents, perfumes, and cosmetic products, as they can damage the case, strap, or seals.
- **Magnetism:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones), as they can affect the accuracy of the movement.
- **Battery Replacement:** When the battery needs replacing, it is recommended to have it done by an authorized TW Steel service center to ensure proper sealing and function.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or is running slow.	Battery depleted.	Replace battery at an authorized service center.
Chronograph hands do not reset to zero.	Requires calibration or internal issue.	Consult an authorized service center for adjustment or repair.
Condensation inside the watch.	Temperature change or compromised water resistance.	Immediately take the watch to an authorized service center to prevent damage.
Date changes at noon instead of midnight.	Time is set 12 hours off.	Advance the time by 12 hours.

7. SPECIFICATIONS

- **Model Number:** CE4104
- **Brand:** TW Steel
- **Movement:** Quartz Chronograph
- **Case Material:** Stainless Steel
- **Crystal:** Mineral Glass
- **Water Resistance:** 10 ATM (100 meters / 330 feet)
- **Case Diameter:** 44 mm
- **Product Dimensions:** 7 x 2 x 4 cm; 300 g
- **Battery:** 1 Product-specific battery required.
- **First Available Date:** September 27, 2022

8. WARRANTY AND SUPPORT

TW Steel watches typically come with a manufacturer's warranty covering defects in materials and workmanship. The specific duration and terms of the warranty may vary by region and purchase date. Please refer to the warranty card included with your watch or visit the official TW Steel website for detailed warranty information.

For service, repairs, or technical support, it is recommended to contact an authorized TW Steel service center or the retailer from whom you purchased the watch. Using unauthorized service providers may void your warranty.

Contact Information: Refer to your purchase documentation or the official TW Steel website for the most current support contact details.

© 2023 TW Steel. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question