

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BERNY](#) /

› [BERNY Men's Quartz Watch Model 2676MS Instruction Manual](#)

BERNY 2676MS

BERNY Men's Quartz Watch Model 2676MS Instruction Manual

Model: 2676MS

INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your BERNY Men's Quartz Watch, Model 2676MS. Designed with a solid stainless steel case and band, this watch features a precise quartz movement for accurate timekeeping, a day and date display, and luminous hands and markers for enhanced visibility in low light. It is also water-resistant to 3ATM.

Please read this manual thoroughly to ensure correct usage and to prolong the life of your timepiece.

SETUP

Setting the Time and Date

Your BERNY 2676MS watch features a crown on the side for adjusting the time and date. Follow these steps:

- Setting the Date and Day:** Gently pull the crown out to the **first position**. Turn the crown clockwise or counter-clockwise to adjust the date and day. Avoid setting the date and day between 9:00 PM and 3:00 AM, as this can interfere with the automatic date change mechanism.
- Setting the Time:** Pull the crown out to the **second position**. Turn the crown to move the hour and minute hands to the desired time. To ensure accuracy, synchronize with a reliable time source.
- Finalizing Settings:** Once the time and date are set, push the crown back into its normal operating position. Ensure it is fully pushed in to maintain water resistance.



MODEL	2676MS	CASE MATERIAL	Stainless Steel
WEIGHT	116g	STRAP MATERIAL	Stainless Steel
MINERAL GLASS	Mineral Glass	WATCH BUCKLE	Double Locking Fold Over Clasp
MOVEMENT	Quartz Movement Miyota 2105	WATER RESISTANT	3ATM

The size of the watch has been marked, please pay attention before buying.

Image: Diagram illustrating the two crown positions for setting the day/date and time.

Band Adjustment

The stainless steel band is designed for a secure fit. If the band is too loose or too tight, it may require adjustment by removing or adding links. This procedure typically requires specialized tools and is best performed by a professional watch technician to avoid damage to the band or clasp.

OPERATING THE WATCH

Reading the Time and Date

The watch features a classic analog display with hour, minute, and second hands. The day and date are displayed in a window at the 3 o'clock position.



Image: Front view of the BERNY 2676MS watch, highlighting the dial and day/date display.

Luminous Features

The hour markers and hands are coated with a luminous material, allowing you to read the time in low-light conditions after exposure to light. The luminescence will gradually fade over time and reactivate with further light exposure.



Image: The watch dial displaying its luminous features in darkness.

MAINTENANCE

Water Resistance

Your BERNY 2676MS watch is rated for 3ATM (30 meters / 100 feet) water resistance. This means it is suitable for daily use and can withstand splashes, rain, and cold showers. It is **not** suitable for swimming, diving, or hot water activities (e.g., hot showers, saunas), as hot water can compromise the watch's seals. Always ensure the crown is fully pushed in before any contact with water.

30M (3ATM) Waterproof



Image: The watch demonstrating its 3ATM water resistance.

Cleaning

To maintain the appearance of your watch, regularly wipe the case and band with a soft, dry cloth. For more thorough cleaning, a slightly damp cloth can be used, ensuring the crown is fully pushed in. Avoid using harsh chemicals or abrasive materials, which can damage the finish.

Battery Replacement

The BERNY 2676MS uses a quartz movement powered by an SR626SW battery. The battery life typically lasts several years. When the watch stops or begins to lose time consistently, the battery likely needs replacement. It is recommended to have battery replacement performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

TROUBLESHOOTING

- **Watch Not Keeping Time:** If the watch stops or consistently runs slow/fast, the battery may need replacement. If the issue persists after battery replacement, the movement may require inspection by a professional.
- **Day/Date Not Advancing:** Ensure the crown is fully pushed into its normal operating position after setting. If the day or date does not advance at midnight, try resetting it manually. If the problem continues, professional inspection is advised.
- **Condensation Under Crystal:** If you notice moisture or condensation under the watch crystal, this indicates a breach in the water resistance. Have the watch inspected and repaired by a professional immediately to prevent internal damage to the movement.
- **Loose or Tight Band:** If the stainless steel band is uncomfortable, it may need adjustment. As mentioned in the Setup section, this is best handled by a professional to ensure proper link removal/addition and clasp integrity.

SPECIFICATIONS

Feature	Specification
Model Number	2676MS-C
Case Material	Stainless Steel
Strap Material	Stainless Steel
Movement	Quartz Movement Miyota 2105
Water Resistance	3ATM (30 meters / 100 feet)
Clasp Type	Push Button Foldover Clasp With Safety
Lens Material	Mineral Glass
Case Diameter	40mm (1.57 inches)
Case Thickness	9.5mm (0.37 inches)
Band Width	20mm (0.79 inches)
Max Wrist Circumference	200mm (8 inches)
Weight	116g (7.05 ounces)



MODEL	2676MS	CASE MATERIAL	Stainless Steel
WEIGHT	116g	STRAP MATERIAL	Stainless Steel
LENS	Mineral Glass	BUCKLE	Double Locking Fold Over Clasp
MOVEMENT	Quartz Movement Miyota 2105	WATER RESISTANT	3ATM

Image: Detailed dimensions of the BERNY 2676MS watch.

PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video: A general product overview of the BERNY 2676MS watch, showcasing its design and features.

WARRANTY AND SUPPORT

Warranty Information

BERNY provides a **1-year after-sales service warranty** for this watch, covering manufacturing defects from the date of purchase. This warranty does not cover damage resulting from improper use, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For any questions, technical assistance, or warranty claims, please contact the BERNY Official Store directly. Their professional customer service team is available to provide support and satisfactory solutions.

© 2026 BERNY. All rights reserved.