C-Pen ReaderPen 2

C-Pen Reader Pen 2 Instruction Manual

Model: ReaderPen 2 (7350085370127)

Brand: C-Pen

1. Introduction to the C-Pen Reader Pen 2

The C-Pen Reader Pen 2 is an advanced OCR (Optical Character Recognition) scanning device designed to assist with reading, literacy, and learning. It converts printed text into speech in real-time, making it an invaluable tool for individuals with dyslexia, learning differences, or anyone seeking to improve their reading comprehension and vocabulary. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your Reader Pen 2.





Figure 1: The C-Pen Reader Pen 2

2. What's in the Box

Upon unboxing your C-Pen Reader Pen 2, please ensure all the following items are present:



- C-Pen Reader Pen 2 Device
- Carry Case
- USB Cable (for charging and data transfer)
- Instruction Manual (this document)
- Headphones

---

3. Key Features

The C-Pen Reader Pen 2 is equipped with several features designed to enhance the reading and learning experience:

- **Text-to-Speech:** Scans and reads aloud full sentences or single words of printed text with AI-based recognition and various accents.
- **Built-in Dictionary:** Defines and reads aloud the meaning of words, with an audio boost setting for improved clarity.
- **Faster Learning:** Promotes multi-sensory learning by allowing users to listen while reading, making studying more efficient.
- **Multi-Language & Dialect Support:** Recognizes and speaks in English, French, and Spanish, suitable for language learners and travelers.
- **Library Storage:** Stores scanned text (up to 5GB, approximately 600,000 pages) and voice memos (up to 3 days of continuous recording), transferable via USB.
- **Portable Design:** Compact and lightweight, ideal for use at home, school, or on the go.



Figure 2: Using the C-Pen for reading assistance



Figure 3: C-Pen with included headphones

4. Setup Guide

4.1 Initial Charge

Before first use, fully charge your C-Pen Reader Pen 2. Connect the included USB cable to the pen's charging port and plug the other end into a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging progress. A full charge typically takes a few hours.

4.2 Power On/Off

- **To Power On:** Press and hold the power button (usually marked with a power symbol) until the C-Pen logo appears on the screen.
- **To Power Off:** Press and hold the power button until the device prompts you to confirm shutdown, then select 'Yes'.

4.3 First Use & Language Selection

Upon first power-on, the device may guide you through an initial setup wizard to select your preferred language and other basic settings. Follow the on-screen prompts using the navigation buttons.

Video 1: Official ReaderPen 2 User Guide (provided by Scanning Pens Inc.)
This video demonstrates the basic setup and initial functions of the C-Pen Reader Pen 2, including navigating the menu and performing a first scan.

---

5. Operating Instructions

5.1 Scanning Text

To scan text, ensure the pen is in 'Reader' mode. Place the transparent scanning tip flat against the printed material. Gently and steadily drag the pen across the line of text you wish to scan. The device will illuminate the text and read it aloud as you scan. For best results, maintain a consistent speed and keep the pen straight.



Figure 4: Proper scanning technique

5.2 Dictionary Function

In 'Dictionary' mode, you can scan individual words to get their definitions read aloud. This is particularly useful for expanding vocabulary and understanding unfamiliar terms. Navigate to the 'Dictionary' option from the main menu and scan the word as described above.

5.3 Recorder & Library

The Reader Pen 2 includes a 'Recorder' function for voice memos and a 'Library' to store scanned text. You can record audio notes directly onto the device. Scanned text is automatically saved to the internal library. To transfer stored data to a computer, connect the pen via the USB cable and access it as a mass storage device.

5.4 Multi-Language Support

The device supports English, French, and Spanish. You can change the recognition and reading language through the system settings menu. This allows for versatile use across different linguistic materials.

---

6. Maintenance and Care

- **Cleaning:** Gently wipe the scanning lens and the device body with a soft, dry, lint-free cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Charge the device regularly, even if not in constant use.
- **Storage:** Store the C-Pen in its provided carry case when not in use to protect it from dust and physical damage.
- **Protection:** The device is not shock-proof. Consider additional protective measures, such as a robust case, to prevent damage from accidental drops.

7. Troubleshooting

If you encounter issues with your C-Pen Reader Pen 2, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on or respond.	Low or depleted battery.	Connect the device to a power source using the USB cable and allow it to charge for at least 30 minutes before attempting to power on again.
Inaccurate scanning or text recognition.	Improper scanning technique, dirty lens, or unusual font.	Ensure the pen is held flat and dragged steadily across the text. Clean the scanning lens. Try scanning different fonts or printed materials.
Pronunciation issues or incorrect word reading.	Language settings incorrect, or specific word recognition challenge.	Verify that the correct language is selected in the device settings. For specific words, try scanning them multiple times or using the dictionary function.
Device freezes or becomes unresponsive.	Software glitch.	Perform a soft reset by pressing and holding the power button for 10-15 seconds until the device restarts. If the issue persists, ensure firmware is up to date.

8. Technical Specifications

Feature	Detail
Model Number	7350085370127
Product Dimensions	1.3"D x 5.31"W x 0.75"H (approx. 3.3 x 13.5 x 1.9 cm)
Item Weight	8.1 ounces (approx. 0.23 kg)
Battery	1 A battery (included)
Connectivity Technology	USB
Scanner Type	Text
Resolution	300 DPI
Optical Sensor Technology	CIS
Internal Storage	5GB (for scanned text and voice memos)

9. Warranty and Support

9.1 Warranty Information

Specific warranty details for the C-Pen Reader Pen 2 are typically provided with the product packaging or can be found on the official C-Pen website. Please retain your proof of purchase for any warranty claims.

9.2 Customer Support

For further assistance, technical support, or inquiries regarding your C-Pen Reader Pen 2, please visit the official C-Pen website or contact Scanning Pens Inc., the seller, directly through their customer service channels. Contact information is usually available on the product packaging or their official website.

© 2024 C-Pen. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question