

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GYMAX](#) /

› **GYMAX Low Bookcase Cabinet 90x29x90 cm (9-Cube) - Instruction Manual**

GYMAX GYMAX Low Bookcase Cabinet 90x29x90 cm (9-Cube)

GYMAX Low Bookcase Cabinet 90x29x90 cm (9-Cube) - Instruction Manual

Model: 90x29x90 cm | Brand: GYMAX

INTRODUCTION

Thank you for choosing the GYMAX Low Bookcase Cabinet. This manual provides essential information for the safe assembly, proper use, and maintenance of your new furniture. Please read these instructions carefully before assembly and retain them for future reference.



Image: The GYMAX Low Bookcase Cabinet, a white 9-cube storage unit, showcasing its versatile use for books and decor.

SAFETY INFORMATION

Warning:

- Ensure the furniture is placed on a stable, level surface.
- Keep the cabinet away from direct heat sources, such as radiators or fireplaces, to prevent material damage.
- Do not overload the shelves. Adhere to the specified weight limits to maintain stability and prevent collapse.
- Follow all assembly instructions precisely to ensure the structural integrity and stability of the furniture.
- This cabinet includes an anti-tip device. It is crucial to install this device as instructed, especially in households with children, to prevent serious injury from tipping furniture.



Image: Detail of the anti-tip device and a warning against furniture tipping.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged:

- 1 x GYMAX Multi-purpose Cabinet (all panels and hardware)
- 1 x Instruction Manual
- Anti-tip device and mounting hardware

If any parts are missing or damaged, please contact customer support before proceeding with assembly.

SETUP AND ASSEMBLY

Assembly of the GYMAX Low Bookcase Cabinet requires basic tools (not included) such as a screwdriver and a hammer. Follow the step-by-step diagrams provided in the included manual for detailed instructions.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in the separate manual to identify each panel and piece of hardware.
3. **Assemble Frame:** Begin by connecting the main side and back panels using the provided fasteners.

Ensure all connections are secure.

- Install Shelves:** Insert the fixed and adjustable shelves into their designated slots. For the 9-cube model, ensure the central dividers are correctly positioned.
- Attach Doors (if applicable):** For cubes with doors, attach the hinges to the door panels and then to the cabinet frame. Adjust as necessary for proper alignment.
- Install Anti-Tip Device:** Securely attach the anti-tip device to the top-rear of the cabinet and then to a wall stud using appropriate wall anchors. This step is critical for safety.
- Final Check:** Ensure all screws and fasteners are tightened. Gently shake the cabinet to confirm stability.



Image: Dimensional diagram of the cabinet, indicating overall and internal cube measurements.

OPERATING INSTRUCTIONS

The GYMAX Low Bookcase Cabinet is designed for versatile storage and display. To ensure optimal performance and longevity:

- Loading Shelves:** Distribute weight evenly across each shelf. Avoid placing heavy items on the edges or in a way that could cause the cabinet to become unbalanced.
- Weight Limits:** The top surface can hold up to 50 kg. Each individual shelf can hold up to 10 kg, and each cube compartment can hold up to 5 kg. Do not exceed these limits.
- Using Doors:** The cabinet features 3 or 5 closed compartments with easy-open doors. Use the integrated hidden handles to open and close the doors smoothly. Magnetic catches ensure the doors remain securely closed.
- Placement:** This cabinet is suitable for various rooms, including living rooms, bedrooms, and offices, serving as both a bookcase and a display unit.



Image: Details of the hidden door handle and magnetic door catch for secure and convenient use.

MAINTENANCE

Proper care will help maintain the appearance and functionality of your GYMAX cabinet:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, which can damage the engineered wood finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Re-tighten if necessary.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.

TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following common solutions:

- **Cabinet feels wobbly:** Ensure all assembly screws are fully tightened. Verify the cabinet is on a level surface. If not, use shims to stabilize. Confirm the anti-tip device is securely installed.
- **Doors do not close properly:** Check hinge alignment and adjust if needed. Ensure nothing is obstructing the door's path. Verify magnetic catches are correctly installed and aligned.
- **Difficulty during assembly:** Review the assembly manual diagrams carefully. Ensure you are using the correct hardware for each step. Do not force parts together; if they don't fit, re-check the instructions.

SPECIFICATIONS

Feature	Detail
---------	--------

Brand	GYMAX
Model	Low Bookcase Cabinet (9-Cube)
Color	White
Material	Engineered Wood (MDF)
Product Dimensions (L x W x H)	90 x 29 x 90 cm
Maximum Load Capacity (Overall)	100 kg
Top Shelf Load Capacity	50 kg
Load Capacity per Shelf	10 kg
Load Capacity per Cube	5 kg
Number of Shelves/Cubes	9 (6 open, 3 closed compartments)
Special Features	Anti-tip design, Hidden door handles, Magnetic door catches

WARRANTY INFORMATION

GYMAX products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to your purchase documentation or contact customer support for specific warranty terms and conditions applicable to your region.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact GYMAX customer support. Our team is available to help you.

- Online Support:** Visit the official GYMAX website for FAQs and support resources.
- Email:** Refer to your product packaging or purchase invoice for customer service email addresses.
- Phone:** Contact numbers may vary by region. Please check the GYMAX website or your product documentation.