Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ymimi 3031120

Ymimi Replacement Vacuum Belt Instruction Manual

For Bissell CleanView Swivel Rewind Pet Upright Bagless Vacuum Cleaners

Introduction

This instruction manual provides guidance for the installation and maintenance of your Ymimi replacement vacuum belt, designed for various Bissell CleanView Swivel Rewind Pet Upright Bagless Vacuum Cleaner models. Please read these instructions carefully before proceeding with installation to ensure proper function and longevity of your vacuum cleaner.

Compatibility

This replacement belt (Part # 3031120) is compatible with the following Bissell CleanView Swivel Rewind Pet Upright Bagless Vacuum Cleaner models:

- 2252, 2256, 2254, 2258, 22547, 2739, 22582, 2488, 2486, 2487
- 22543, 22548, 22549, 2255, 2739, 22582, 2489, 24899
- 2488, 2486, 2487, 2492, 3590, 3591, 8975, 8975R, 8990, 8990R, 8990W Series

Please verify your vacuum cleaner's model number before installation to ensure proper fit.



Figure 1: Compatible Bissell Vacuum Models. This image displays a replacement vacuum belt alongside various Bissell CleanView Swivel Rewind Pet Upright Bagless Vacuum Cleaner models, indicating their compatibility with the belt.

Package Contents

Your package includes the following items:

- 2 x Ymimi Replacement Vacuum Belts (Part # 3031120)



Figure 2: Package Contents. This image shows two new replacement vacuum belts as included in the package.

Installation Instructions

Replacing the vacuum belt is a straightforward process. Follow these steps carefully:

1. **Safety First:** Always unplug your vacuum cleaner from the power outlet before performing any maintenance or installation.
2. **Access the Brush Roll:** Lay the vacuum cleaner on its side or back to access the brush roll area. You may need to remove a bottom plate or cover, typically secured by screws. Refer to your specific Bissell vacuum cleaner's user manual for detailed instructions on accessing the brush roll.
3. **Remove Old Belt:** Carefully remove the worn or broken belt from the brush roll and motor shaft. Note how the old belt was routed for easier installation of the new one.

4. **Install New Belt:** Loop the new Ymimi replacement belt around the motor shaft first, then stretch it around the brush roll. Ensure the belt is seated correctly in the grooves of both the motor shaft and the brush roll. The belt should be taut but not overly stretched.
5. **Reassemble:** Once the new belt is in place, rotate the brush roll manually a few times to ensure the belt is properly aligned and moves freely. Reattach any covers or plates that were removed, securing them with screws.
6. **Test:** Plug in your vacuum cleaner and turn it on to test the new belt. The brush roll should spin smoothly.



Figure 3: Replacement Belts and Vacuum. This image shows the two replacement belts and a compatible Bissell vacuum, providing a visual reference for the product.

Maintenance Tips

To maximize the lifespan of your vacuum belt and maintain optimal vacuum performance:

- **Regular Inspection:** Periodically inspect the belt for signs of wear, cracking, or stretching. Replace the belt if any damage is observed.
- **Clear Brush Roll:** Regularly remove hair, threads, and debris from the brush roll. Excessive entanglement can put strain on the belt and lead to premature failure.
- **Avoid Obstructions:** Be mindful of objects that can get caught in the brush roll, such as shoelaces or small toys, as these can cause the belt to break.

Troubleshooting

If you encounter issues after replacing the belt, consider the following:

- **Brush Roll Not Spinning:** Ensure the belt is correctly seated on both the motor shaft and the brush roll. Check for any obstructions preventing the brush roll from turning freely.
- **New Belt Breaks Quickly:** This could indicate an underlying issue with the brush roll (e.g., seized bearings) or excessive debris entanglement. Ensure the brush roll spins freely by hand when the belt is removed.
- **Vacuum Not Picking Up:** A broken or stretched belt will prevent the brush roll from agitating the carpet, leading to poor suction. Replace the belt if it is damaged or loose.

Product Specifications

Feature	Detail
Brand	Ymimi
Compatible Part Number	3031120
Material	Rubber
Belt Style	Flexible Belt
Compatible Devices	Bissell CleanView Swivel Rewind Pet Upright Bagless Vacuum Cleaners
Item Weight	9.07 g (0.32 ounces)
Package Dimensions	4.8 x 3.62 x 0.67 inches



Figure 4: Belt Dimensions. This image highlights the perimeter measurement of the replacement vacuum belt.

Customer Support

If you encounter any issues with the product, such as incorrect fit or model incompatibility, please contact us. We are committed to providing after-sales service and will respond to your inquiries within 24 hours.
For general inquiries or assistance, please refer to the contact information provided by your retailer or on the product packaging.

© 2023 Ymimi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BGRYXK3V

More documents and user manuals: **https://manuals.plus/**