

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [MassaMAX](#) /
- › [MassaMAX Full Body Massage Chair Instruction Manual](#)

MassaMAX MD906

MassaMAX Full Body Massage Chair (MD906) Instruction Manual

Model: MD906
Brand: MassaMAX

INTRODUCTION

Welcome to the MassaMAX Full Body Massage Chair experience. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your MD906 massage chair. Please read it thoroughly before first use.



A sleek black full body massage chair with a modern design, featuring a control panel on the side.

IMPORTANT SAFETY INFORMATION

For your safety, always adhere to the following precautions. Failure to do so may result in injury or damage to the product.

- Read all instructions before using the massage chair.
- Do not use if you have any medical conditions that may be aggravated by massage. Consult a physician if unsure.
- Keep away from water and damp environments.
- Ensure the power cord is not damaged and is properly connected.
- Do not allow children or pets to play on or around the chair.
- Do not insert any objects into the chair's openings.
- Unplug the chair when not in use or before cleaning.
- Do not attempt to repair or disassemble the chair yourself. Contact qualified service personnel.

PRODUCT COMPONENTS

Your MassaMAX MD906 massage chair includes the following main components:

- Main Chair Unit
- Footrest Assembly
- Handheld Remote Control
- Power Cord
- User Manual (this document)



The black massage chair positioned in a contemporary living room with a sofa, coffee table, and large windows, demonstrating its aesthetic fit in a home environment.

SETUP INSTRUCTIONS

Your MassaMAX MD906 massage chair arrives approximately 90% pre-assembled. Follow these steps for quick

setup:

1. Carefully remove the chair and its components from the packaging.
2. Position the main chair unit in your desired location, ensuring sufficient space around it for reclining and operation (refer to dimensions in Specifications).
3. Attach the footrest assembly to the main chair unit. This typically involves aligning the connection points and securing them with the provided fasteners. (This step usually takes about 5 minutes).
4. Connect the power cord to the chair and then to a grounded electrical outlet.
5. Ensure all connections are secure before powering on.



A series of diagrams illustrating the chair's dimensions from various angles and the required minimum doorway width (greater than 29.92 inches) for installation.

OPERATING INSTRUCTIONS

The MassaMAX MD906 features an intuitive handheld remote control for easy operation.

Powering On/Off

Press the **POWER** button on the remote to turn the chair on or off.

Body Scan

Upon activation, the chair will perform an automatic body scan to customize the massage experience to your unique body contours. Remain still during this process.

Auto Body Scan



A visual representation of the massage chair performing a body scan, showing a human silhouette with highlighted spinal points, indicating how the chair customizes the massage to the user's body.

Adjusting Recline and Leg Rest

Use the **LEG UP/DOWN** and **BACK UP/DOWN** buttons to adjust the recline angle and leg rest position to your comfort.

The chair also features a Zero Gravity recline function, which elevates your legs above your heart to minimize spinal pressure. Activate this mode using the dedicated **ZERO-G** button.

Massage Programs and Techniques

The MD906 offers a variety of massage styles and preset programs.



A visual guide displaying different massage techniques like Kneading, Tapping, Knocking, Shiatsu, and combination modes, along with indicators for speed levels and air massage intensity.

Preset Automatic Programs

Select from 12 preset automatic programs designed for various needs (e.g., full body, relaxation, sleep, recovery). Refer to the remote control display for program names.

Manual Massage Techniques

Choose from 5 core massage styles: **Kneading**, **Tapping**, **Knocking**, **Shiatsu**, and a **combination of Kneading & Knocking**.

Adjust speed and width of rollers using the remote.

Intelligent Mechanical Massage Hands



A detailed view showing the sophisticated internal mechanism of the massage rollers, highlighting the 'intelligent mechanical massage hands' that mimic human touch.

Airbag Compression Massage

The chair features full-body airbags targeting various muscle groups for compression massage. Adjust intensity levels as desired.

Full Body Airbags Squeezing Massage and Lower Back Heating Therapy



An image of a person relaxing in the massage chair, with blue highlighted areas indicating airbag compression points on the arms, shoulders, and legs, and an orange glow on the lower back representing heat therapy.

Foot Massage

The foot massage area provides rolling, scraping, and air compression techniques.

Foot Rollers Massage



A detailed view of the footrest area, showing blue rollers and air compression elements designed to provide a comprehensive foot massage.

Heating Function

Activate the lower back heating therapy for enhanced relaxation and muscle relief.

Yoga Stretch Function

The unique Yoga Stretch function gently stretches your body to decompress the spine and improve flexibility.

Yoga Stretch



An animated diagram showing a human figure being gently stretched by the massage chair, with arrows indicating the movement and decompression of the spine.

Bluetooth Connectivity

Connect your device via Bluetooth to enjoy music through the chair's integrated speakers during your massage.

MAINTENANCE AND CARE

Cleaning

For general cleaning, use a soft, damp cloth to wipe down the chair's surfaces.

For stubborn spots, use a mild, non-abrasive cleaner. Always spot clean as per product care instructions.

Do not use harsh chemicals or abrasive materials.

Storage

When not in use for extended periods, unplug the chair and store it in a cool, dry place away from direct sunlight.

Regular Checks

Periodically check the power cord for any damage.
Ensure all moving parts operate smoothly.

TROUBLESHOOTING GUIDE

If you encounter any issues with your MassaMAX MD906 massage chair, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not power on.	Power cord not connected or outlet issue.	Ensure power cord is securely plugged into the chair and a working electrical outlet. Check circuit breaker.
Massage intensity is too strong.	Default setting or body scan adjustment.	Adjust intensity settings via the remote control. If needed, place a cushion or blanket between your body and the rollers.
Chair makes unusual noises.	Normal operation or loose component.	Some operational sounds are normal. If the noise is loud or unusual, unplug the chair and contact customer support.
Remote control is unresponsive.	Batteries low or remote not paired.	Replace batteries in the remote control. Ensure the remote is pointed towards the chair's receiver.

For issues not listed here or if troubleshooting steps do not resolve the problem, please contact MassaMAX customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	MassaMAX
Model Name	MD906
Color	Black
Product Dimensions (D x W x H)	57.87" x 29.92" x 43.7"
Maximum Weight Recommendation	260 Pounds
Item Weight	156 pounds
Massage Track	SL Track (53.15 inches)
Massage Styles	Kneading, Tapping, Knocking, Shiatsu, Kneading & Knocking Combination
Preset Programs	12

Feature	Detail
Special Features	Zero Gravity, Yoga Stretch, Airbag Compression, Lower Back Heating, Foot Rollers, Auto Body Scan, Bluetooth Speakers
Assembly	90% Pre-assembled
UPC	850036071280

WARRANTY AND CUSTOMER SUPPORT

Your MassaMAX MD906 massage chair is backed by a 3-year protection plan.

For any questions, technical assistance, or warranty claims, please contact MassaMAX customer support.

Customer Service Phone: 866-909-6062

You can also visit the official MassaMAX store on Amazon for more information and to ask a question [MassaMAX Amazon Store](#)

Alternatively, you can scan the QR code below or click the "Ask a question" link on the seller's page [Ask a question to MassaMAX](#)



An image displaying a QR code and text instructions on how to contact MassaMAX customer service, including a phone number and links to their Amazon seller page.