

T'nB EBSHINYPK2

T'nB SHINY2 Bluetooth 5.1 Wireless Semi In-Ear Earbuds User Manual

Model: EBSHINYPK2

INTRODUCTION

This manual provides detailed instructions for the use and maintenance of your T'nB SHINY2 Bluetooth 5.1 Wireless Semi In-Ear Earbuds. These earbuds are designed for comfort and high-quality audio, featuring Bluetooth 5.1 technology, an integrated microphone, and touch controls. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.

PACKAGE CONTENTS

Ensure all items are present in the package:

- T'nB SHINY2 Wireless Semi In-Ear Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual (this document)

SETUP

1. Charging the Earbuds and Case

- Before first use, fully charge the earbuds and the charging case. The charging case provides additional battery life for your earbuds, extending listening time up to 20 hours.
1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots (L for left, R for right).
 2. Connect the provided USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
 3. The LED indicator on the charging case will display the battery level of both the case and the earbuds during charging. A full charge for the earbuds takes approximately 1 hour.

Indicateur de charge



Image: The charging case with earbuds, displaying the LED charge indicator. This indicator shows the battery level of the case and the earbuds.

Autonomie 20 heures



Autonomie max
Max playing time

Image: T'nB SHINY2 earbuds highlighting their 20-hour battery life with the charging case.

2. Bluetooth Pairing

The SHINY2 earbuds utilize Bluetooth 5.1 technology for a stable connection up to 10 meters.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "T'nB SHINY2" from the list of found devices.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use. The earbuds feature automatic pairing for subsequent uses; they will connect to the last paired device when removed from the case.

Appairage automatique



Image: T'nB SHINY2 earbuds positioned near a smartphone, demonstrating the automatic pairing process.



Bluetooth 5.1

Sans aucun fil

Image: A woman wearing T'nB SHINY2 earbuds, emphasizing the wireless freedom provided by Bluetooth 5.1 technology.

OPERATING INSTRUCTIONS

1. Wearing the Earbuds

The SHINY2 earbuds feature a semi in-ear ergonomic design for comfortable and secure fit during various activities.

- Gently insert each earbud into your ear canal.
- Adjust the position until it feels secure and comfortable. The "L" and "R" markings indicate the left and right earbuds.



Format semi-intra auriculaire : design ergonomique

Image: A woman wearing T'nB SHINY2 earbuds, illustrating their comfortable semi in-ear ergonomic design.

2. Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case to automatically power them off and begin charging.

3. Touch Controls

The SHINY2 earbuds feature intuitive touch controls on each earbud for managing music playback, calls, and volume without needing to access your smartphone.

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause music, Answer/End call
Double Tap (Right Earbud)	Next track
Double Tap (Left Earbud)	Previous track

Action	Function
Triple Tap (Right Earbud)	Volume Up
Triple Tap (Left Earbud)	Volume Down
Long Press (2 seconds)	Reject incoming call, Activate voice assistant

Commandes tactiles



▶||play / volume / pistes de lecture

Image: A close-up view of the T'nB SHINY2 earbuds, highlighting the touch-sensitive area for controls.




Image: A woman making a call using the T'nB SHINY2 earbuds, demonstrating the integrated microphone for clear communication.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Water Resistance:** These earbuds are not water-resistant. Avoid exposure to water, moisture, or excessive humidity.
- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold).

TROUBLESHOOTING

If you encounter issues with your T'nB SHINY2 earbuds, refer to the following common solutions:

- **Earbuds not pairing:**

- Ensure the earbuds are fully charged.
- Make sure Bluetooth is enabled on your device.
- Place the earbuds back in the case, close it, then open it again to re-enter pairing mode.
- Try forgetting "T'nB SHINY2" from your device's Bluetooth settings and re-pairing.

• **No sound from one or both earbuds:**

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly paired and connected.
- Try restarting your device and the earbuds.

• **Charging issues:**

- Ensure the charging cable is securely connected to both the case and the power source.
- Verify that the power source is functional.
- Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.

• **Microphone not working during calls:**

- Ensure the earbuds are selected as the audio input device on your phone during a call.
- Check for any obstructions on the microphone openings.

SPECIFICATIONS

Feature	Detail
Model Number	EBSHINYPK2
Bluetooth Version	5.1
Wireless Range	Up to 10 meters
Earbud Battery Capacity	25 mAh (each earbud)
Charging Case Battery Capacity	300 mAh
Total Playtime (with case)	Up to 20 hours
Earbud Charging Time	Approx. 1 hour
Impedance	32 Ohms
Sensitivity	95 dB
Frequency Range	20 Hz - 20,000 Hz
Control Type	Touch Control
Microphone	Integrated Universal Microphone
Earbud Type	Semi In-Ear
Connector Type	USB-C (for charging case)
Water Resistance	Not water-resistant
Dimensions (Package)	14.4 x 7.8 x 3.7 cm
Weight (Package)	120 g

WARRANTY AND SUPPORT

T'nB products are designed for quality and reliability. For warranty information and technical support, please refer to the warranty card included with your purchase or visit the official T'nB website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact T'nB customer service through their official channels.

© 2024 T'nB. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question