

[Manuals.plus](#) /

› [Hasbro Gaming](#) /

› Hasbro Gaming Twister Air Game Instruction Manual F8158

## Hasbro Gaming F8158

# Hasbro Gaming Twister Air Game Instruction Manual

MODEL: F8158

### Introduction

---

The Hasbro Gaming Twister Air Game is an app-enabled augmented reality game that brings the classic Twister experience to your smart device. Players wear colorful wrist and ankle bands and move their bodies to match colored spots on the screen, earning points for every successful match. This manual provides instructions for setup, gameplay, and maintenance.



Image: The Twister Air Game box, displaying the game's concept with animated characters, colorful bands, and a tablet showing gameplay.

## What's in the Box

- 4 Twister Air Wrist Bands
- 4 Twister Air Ankle Bands
- Device Stand (with clip, base, and post)
- Game Rules



Image: All components of the Twister Air Game laid out: eight colorful bands (four wrist, four ankle) and the white adjustable device stand.

Your browser does not support the video tag.

Video: A closer look at the Twister Air Game components, including the colorful bands and the device stand.

## Setup

1. **Download the Twister Air App:** Scan the QR code provided in the game rules or on the box to download the free Twister Air app on your mobile or digital tablet device. Data rates and in-app purchases may apply.



Image: A smartphone scanning the QR code on the game box to access the Twister Air app download.

2. **Assemble the Device Stand:** Connect the clip, base, and post to form the adjustable device stand.
3. **Place Your Smart Device:** Securely place your smartphone or tablet into the assembled stand. Ensure the device's camera is unobstructed and facing the play area.
4. **Wear the Bands:** Distribute the 8 colorful Twister Air bands among players. Each player wears one band on each wrist and one band on each ankle. The app will guide you on which colors to wear for specific players.




Image: A visual representation of the three main setup steps: downloading the app, wearing the bands, and placing the device in the stand.

5. **Supported Devices:** The Twister Air app is compatible with Apple iOS 13+ (iPhone XS/XR or later, iPhone SE 2nd gen or later, iPad 8th gen or later, iPad Air 3rd gen or later, iPad mini 5th gen or later, iPad Pro 3rd gen or later) and Android OS 10+ (Samsung Galaxy S20, Samsung Galaxy S21 Ultra, Samsung Galaxy Note 10, Samsung Galaxy Tab S7, Google Pixel 5, Sony Xperia 1 II).



Image: A detailed list of compatible Apple iOS and Android devices required to play the Twister Air Game.

## Operating Instructions (How to Play)

1. **Launch the App:** Open the Twister Air app on your smart device.
2. **Select Play Style:** Choose between 'Full Body' (best for large spaces and casting to a TV) or 'Arms Only' (suitable for smaller spaces or sitting).
3. **Choose Game Mode:** Select from 'VS.' (compete against another player), 'Teams' (play with teammates), or 'Solo' (play alone to beat your personal best).
4. **Calibrate Bands:** The app will guide you to position your hands and feet with the bands visible to the device's camera for calibration. Ensure good lighting and a clear area.
5. **Match Bands to Spots:** As music plays, colored spots will appear on your screen. Move your body to match your wrist and ankle bands to these spots. Reach, clap, swipe, and pose as instructed by the game.



Image: A player actively engaging with the Twister Air app, aligning their bands with on-screen targets.

6. **Score Points:** Points are awarded for accurately matching your bands to the colored spots. The player or team with the highest score wins.
7. **Casting to TV:** For an enhanced experience, you can cast the game from your smart device to a compatible TV.



Image: Two children playing Twister Air, demonstrating how the game can be played on a tablet and simultaneously viewed on a larger television screen.

## Maintenance

- **Cleaning:** The Twister Air bands can be wiped clean with a damp cloth. Do not submerge the bands or device stand in water.
- **Storage:** Store all game components in their original packaging or a dry, safe place away from direct sunlight and extreme temperatures.
- **Care:** Avoid excessive force when attaching or detaching the device from the stand. Ensure bands are not stretched beyond their intended use.

## Troubleshooting

- **Bands Not Detected:**
  - Ensure the play area has sufficient lighting.
  - Verify that the bands are worn correctly and are fully visible to the smart device's camera.

- Check that no objects are obstructing the camera's view.

- **App Glitches or Crashes:**

- Close and restart the Twister Air app.
- Ensure your smart device's operating system is up to date.
- Check for any available updates for the Twister Air app.
- Free up storage space on your device if it is running low.

- **Inaccurate Movement Tracking:**

- Re-calibrate the bands within the app settings.
- Ensure players are within the recommended distance from the smart device.
- Avoid playing near windows or reflective surfaces that might interfere with camera detection.

- **Device Stand Instability:**

- Ensure the device stand is placed on a flat, stable surface.
- Verify that your smart device is securely clipped into the stand.

## Specifications

|                              |                             |
|------------------------------|-----------------------------|
| Brand                        | Hasbro Gaming               |
| Model Number                 | F8158                       |
| Product Dimensions           | 13.06 x 10.51 x 1.69 inches |
| Item Weight                  | 15.2 ounces                 |
| Manufacturer Recommended Age | 8+ years                    |
| Language                     | English                     |
| Players                      | 1+                          |

## Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the official Hasbro Gaming website or contact their customer service directly. Specific warranty terms and conditions may vary by region and purchase location.

You can visit the [Hasbro Gaming Store](#) for additional product information and resources.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0BGT6Q343>

More documents and user manuals: <https://manuals.plus/>