

CiBest G1

CiBest G1 Projector User Manual

4K SUPPORT ANDROID TV 10.0 PROJECTOR WITH 5G WiFi, BLUETOOTH, NATIVE 1080P

1. Introduction

Thank you for choosing the CiBest G1 Projector. This manual provides essential information for the safe and efficient operation of your device. Please read this manual thoroughly before use and retain it for future reference. The CiBest G1 Projector offers a high-definition viewing experience with 4K support, Android TV 10.0, 5G WiFi, Bluetooth connectivity, and native 1080P resolution.

2. Safety Instructions

- Do not block ventilation openings. Ensure adequate space around the projector for proper airflow.
- Use only the power adapter supplied with the projector.
- Avoid direct exposure to the projector lens light.
- Do not disassemble the projector. Refer all servicing to qualified personnel.
- Keep the projector away from water, moisture, and extreme temperatures.

3. Product Overview

3.1 Package Contents

- CiBest G1 Projector
- Remote Control
- Power Adapter
- HDMI Cable
- User Manual

3.2 Projector Components

Familiarize yourself with the various parts of your CiBest G1 Projector.



Image 3.2.1: Front view of the CiBest G1 Projector with its remote control, highlighting features like Android TV 10.0, 4K support, 5G WiFi, and Bluetooth.

The image above displays the projector's front, including the lens and ventilation, alongside the remote control. Icons indicate key features such as Android TV 10.0, 4K support, 5G WiFi, and Bluetooth connectivity.

4. Setup

4.1 Placement

Place the projector on a stable, flat surface. Ensure the lens is perpendicular to the projection surface for optimal image geometry. The projection distance will determine the screen size.

4.2 Power Connection

Connect the power adapter to the projector's power input port, then plug the adapter into a power outlet.

4.3 Initial Power On

Press the power button on the projector or the remote control to turn on the device. The projector will boot up and display the Android TV interface.

4.4 Focus Adjustment

The CiBest G1 Projector features autofocus for quick image clarity. If manual adjustment is needed, use the remote control to fine-tune the focus.



Image 4.4.1: The projector demonstrating its autofocus capability, ensuring a sharp and clear image instantly.

This image illustrates the projector's autofocus function, which automatically adjusts the lens to achieve a clear picture, eliminating manual focusing efforts.

4.5 Network Connection (5G WiFi)

1. Navigate to the 'Settings' menu on the Android TV interface.
2. Select 'Network & Internet'.
3. Choose your desired 5G or 2.4G WiFi network from the list.
4. Enter the password if prompted and connect.

4.6 Bluetooth Pairing

1. Go to 'Settings' and select 'Connected Devices'.
2. Turn on Bluetooth and put your Bluetooth device (e.g., headphones, speaker) into pairing mode.
3. Select your device from the list to pair.

5. Operating Instructions

5.1 Android TV 10.0 Interface

The projector runs on Android TV 10.0, providing access to a wide range of applications and content. Use the remote control's directional pad and 'OK' button to navigate the interface.



Image 5.1.1: The Android TV 10.0 home screen on the projector, showing popular streaming applications like Netflix, YouTube, Prime Video, Disney+, and Hulu.

This image illustrates the user-friendly Android TV 10.0 interface, showcasing various pre-installed and downloadable applications for entertainment.

5.2 Streaming Applications

Access popular streaming services such as Netflix, Prime Video, Disney+, and more directly from the Android TV interface. Ensure you are logged into your respective accounts.

5.3 Input Sources

The projector supports multiple input sources:

- **HDMI:** Connect external devices like gaming consoles, Blu-ray players, or laptops.
- **USB:** Play media files directly from a USB drive.
- **AV:** Connect older devices using the included 3-in-1 AV cable.

5.4 Screen Mirroring (Chromecast Built-in)

The projector has Chromecast built-in, allowing you to cast content from your Android or iOS devices. Download the Chromecast app on your mobile device for effortless screen mirroring.

5.5 Voice Assistant

Utilize the built-in voice assistant for quick searches and commands. Press the dedicated assistant button on your remote control and speak your query.

6. Maintenance

6.1 Dust-proof Optical Engine

The CiBest G1 Projector features a full-sealed optical engine designed to prevent dust from entering the lens and internal components. This design minimizes maintenance and extends the projector's lifespan.



Image 6.1.1: An internal diagram illustrating the full-sealed optical engine, designed to protect against dust infiltration.

This diagram shows the internal structure of the projector's optical engine, emphasizing its sealed design for dust protection, which helps maintain image quality and longevity.

6.2 Cleaning

- **Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners.
- **Exterior:** Wipe the projector's exterior with a soft, dry cloth. Avoid using harsh chemicals.

6.3 Storage

When not in use for extended periods, store the projector in a cool, dry place, protected from dust and direct sunlight. Use the original packaging or a protective case if available.

7. Troubleshooting

Problem	Possible Cause	Solution
No image displayed	Power cable disconnected; Incorrect input source; Lens cap on.	Check power connection; Select correct input source; Remove lens cap.
Image is blurry	Focus not adjusted; Projector too close/far.	Adjust focus using remote; Adjust projection distance.
No sound	Volume too low; External audio device not connected; Muted.	Increase volume; Check Bluetooth connection or audio cable; Unmute.
WiFi connection unstable	Weak signal; Router issues.	Move projector closer to router; Restart router; Ensure 5G network is selected if available.

If problems persist after attempting these solutions, please contact customer support.

8. Specifications

Feature	Detail
Model Number	G1
Display Resolution	Native 1920 x 1080 (1080P), 4K Support
Connectivity Technology	HDMI, USB, 3-in-1 AV, 3.5mm Audio, Android TV box, 5G WiFi, Bluetooth
Special Feature	Built-in Speakers, Autofocus, Android TV 10.0, Full-Sealed Optical Engine
Recommended Uses	Indoor/Outdoor Home Entertainment
Product Dimensions	12 x 6 x 17 inches
Item Weight	8.62 pounds

9. Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official CiBest website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question