

[Manuals.plus](#) /

› [Polaroid](#) /

› Polaroid P2 Music Player User Manual

Polaroid P2 (9087)

Polaroid P2 Music Player User Manual

Model: P2 (9087)

INTRODUCTION

The Polaroid P2 Music Player is a portable wireless Bluetooth speaker designed for powerful sound and easy portability. Its compact size allows for versatile placement and use, including as a wearable device. The P2 model integrates with the Polaroid Music App, offering enhanced control and access to curated music content.

WHAT'S IN THE BOX

- P2 Player
- USB-C Charging Cable (1m)
- Quick Start Guide
- Carabiner and Wrist Strap
- Safety & Compliance Leaflet

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Polaroid P2 Music Player.



Figure 1: Front view of the Polaroid P2 Music Player, showcasing its distinctive blue speaker grilles, white body, and central display.



Figure 2: Top panel of the Polaroid P2, detailing the playback controls, volume dial, and other function buttons.

Polaroid Music App

The Polaroid Music app gives you access to Polaroid Radio and thousands of internet radio stations, allowing you to get the most of your speaker.

The app lets you favorite any songs you love while listening to internet radio. Our built-in Shazam music recognition will match the music and add it to your "♥ Songs" list.

Switch between stations directly on your speaker and like songs, all without touching your phone.




Figure 3: The Polaroid P2 Music Player shown with its included blue wrist strap, highlighting its portability.

Controls and Indicators:

- **Power Button:** Located on the side, used to turn the device on/off.
- **Volume Dial:** Central dial on the top panel for adjusting audio volume.
- **Play/Pause Button:** Red button for controlling music playback.
- **Skip/Previous Buttons:** For navigating tracks.
- **Bluetooth Button:** For initiating Bluetooth pairing.
- **Display Screen:** Shows track information and status indicators.
- **USB-C Port:** For charging the device.
- **AUX IN Port:** For wired audio connection.

SETUP

Charging the Device:

1. Connect the supplied USB-C charging cable to the USB-C port on the Polaroid P2 Player.
2. Connect the other end of the cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The device will indicate charging status on its display. A full charge takes approximately 4 hours.

Initial Power On:

1. Press and hold the Power button until the device powers on and the display illuminates.
2. The speaker will typically enter Bluetooth pairing mode automatically upon first use.

Polaroid Music App:

For full functionality, including access to Polaroid Radio and advanced features, download the Polaroid Music App. It is available for both iOS and Android devices.

Figure 4: The Polaroid Music App interface shown on a smartphone, demonstrating its integration with the P2 Music Player.

Search for "Polaroid Music" in your device's app store.

OPERATING INSTRUCTIONS

Bluetooth Pairing:

1. Ensure the Polaroid P2 Player is powered on.
2. Press the Bluetooth button on the top panel to enter pairing mode. The display will indicate pairing readiness.
3. On your audio device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Polaroid P2" from the list of devices to connect.
5. Once connected, the speaker will confirm the successful pairing. The Bluetooth range is approximately 30 feet (10 meters).

Audio Playback:

- **Bluetooth:** After pairing, play audio from your connected device. Use the Play/Pause, Skip, and Previous buttons on the speaker, or control playback directly from your device.
- **AUX IN:** Connect an audio source directly to the AUX IN port using a 3.5mm audio cable (not included). The speaker will automatically switch to AUX mode.
- **Volume Control:** Rotate the central dial to adjust the volume.

Stereo Pairing (TWS):

Two Polaroid P2 speakers can be paired together to create an immersive stereo sound experience.

1. Ensure both Polaroid P2 speakers are powered on and not connected to any other Bluetooth devices.
2. On one speaker (this will be the primary speaker), press and hold the Bluetooth button until it enters TWS pairing mode.
3. On the second speaker, briefly press the Bluetooth button.
4. The two speakers will automatically connect to each other. Once connected, they will indicate successful stereo pairing.
5. Connect your audio device to the primary speaker via Bluetooth. Audio will now play in stereo across both speakers.

Using the Polaroid Music App:

The app provides access to Polaroid Radio, a free curated internet radio service, and allows you to manage your favorite songs. You can switch between stations and like songs directly from the speaker using the analog dial and heart button, without needing to touch your phone.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Water Resistance:** This product is NOT waterproof. Avoid exposure to water or excessive moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery; Power button not pressed correctly.	Charge the speaker fully. Press and hold the Power button for a few seconds.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Device too far; Bluetooth disabled on source device.	Ensure speaker is in pairing mode. Move device closer. Enable Bluetooth on your source device. Forget previous pairings and try again.
No sound or low volume.	Volume too low on speaker or source device; Incorrect input mode.	Increase volume on both speaker and source device. Check if the correct input (Bluetooth/AUX) is selected.
Stereo pairing fails.	Speakers already connected to other devices; Incorrect pairing sequence.	Disconnect both speakers from any other Bluetooth devices. Follow the stereo pairing instructions carefully.

SPECIFICATIONS

Feature	Detail
Model Name	Polaroid Music Player
Model Number	9087 (P2)
Connectivity Technology	Bluetooth 5.1, Auxiliary (3.5mm), USB-C (charging)
Wireless Range	Up to 30 feet (10 meters)
Audio Output Mode	Stereo
Speaker Maximum Output Power	20 Watts
Battery Type	1 Lithium Ion battery (included)
Battery Capacity	2000 mAh
Charging Time	Approximately 4 hours
Playback Time	Up to 15 hours
Product Dimensions (D x W x H)	1.97" x 8.66" x 3.54" (50 x 220 x 90 mm)
Item Weight	1.46 pounds (662 grams)
Water Resistance Level	Not Water Resistant

WARRANTY AND SUPPORT

The Polaroid P2 Music Player comes with a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For warranty claims, technical support, or further assistance, please refer to the contact information provided in the Safety & Compliance Leaflet included with your product, or visit the official Polaroid support website.

Note: Keep your proof of purchase for warranty validation.