

LOZ 1051

LOZ Mini Bricks Halloween Building Block Set (Model 1051) Instruction Manual

Brand: LOZ | Model: 1051

1. INTRODUCTION

This instruction manual provides detailed guidance for assembling the LOZ Mini Bricks 4-in-1 Halloween Building Block Set, Model 1051. This set allows you to construct four distinct Halloween-themed models: a Haunted House, a Freak House, a Pumpkin House, and a Witches House. Please read all instructions carefully before beginning assembly.

2. SAFETY INFORMATION

- **Small Parts Warning:** This set contains small parts and is not suitable for children under 3 years old due to choking hazards.
- **Adult Supervision:** Adult supervision is recommended during assembly, especially for younger children.
- **Material Safety:** All parts are made from ABS material, which is durable and environmentally friendly.
- **Handling:** Handle pieces carefully to avoid damage.

3. PACKAGE CONTENTS

Your LOZ Mini Bricks Halloween Building Block Set (Model 1051) includes the following:

- Approximately 2919 Mini Building Block Pieces (sorted into multiple bags)
- Detailed Instruction Manuals for each model
- Sticker Sheet for decorative details

4. ASSEMBLY INSTRUCTIONS

Each of the four models comes with its own specific instruction manual. Follow the step-by-step visual guides provided in the individual manuals for accurate assembly. It is recommended to sort pieces by color and shape before starting each model.

4.1. Witches House (LOZ 1251)

Assemble the Witches House model by following the dedicated instructions. This model features a purple witch's hat roof and intricate details like a cauldron and black cat figures.



Image: The completed LOZ Mini Bricks Witches House model.



Image: Detailed view of the Witches House entrance.



Image: Interior details of the Witches House.

4.2. Freak House (LOZ 1249)

Construct the Freak House model using its dedicated instructions. This model features a green and grey color scheme, resembling a mad scientist's lab with unique architectural elements.



Image: The completed LOZ Mini Bricks Freak House model.



Image: Detailed view of the Freak House exterior.



Image: Interior details of the Freak House.

4.3. Haunted House (LOZ 1248)

Follow the instructions to build the Haunted House model. This classic Halloween structure features a red roof, a graveyard, and ghost figures.



Image: The completed LOZ Mini Bricks Haunted House model.

4.4. Pumpkin House (LOZ 1250)

Assemble the Pumpkin House model according to its instructions. This festive model is characterized by a large pumpkin on its roof and other pumpkin-themed decorations.



Image: The completed LOZ Mini Bricks Pumpkin House model.

5. OPERATING INSTRUCTIONS

Once assembled, these LOZ Mini Bricks models are designed for display and imaginative play. There are no electronic components or moving parts requiring specific operation.

- **Display:** Place your completed models on a stable, flat surface.
- **Interaction:** The models are sturdy enough for gentle handling and role-playing scenarios.

6. MAINTENANCE

- **Cleaning:** To clean the models, gently wipe them with a dry, soft cloth. Avoid using water or chemical cleaners, as these may damage the plastic or stickers.
- **Storage:** Store models in a cool, dry place away from direct sunlight to prevent discoloration or warping of the plastic. If disassembling for storage, keep all pieces organized to facilitate future reassembly.

7. TROUBLESHOOTING

- **Missing Pieces:** If you find any missing pieces, please contact LOZ customer support. Each package undergoes three tests to ensure completeness.
- **Difficulty Assembling:** Refer to the detailed visual instructions. Ensure pieces are correctly oriented and firmly pressed together.
- **Loose Connections:** If pieces feel loose, ensure they are fully engaged with the studs. The mini bricks require precise alignment.

8. SPECIFICATIONS

Feature	Detail
Brand	LOZ
Model Number	1051
Product Dimensions	4.13 x 4.13 x 7.09 inches (per model, approximate)
Item Weight	2.79 pounds (total package)
Number of Pieces	2919
Material	ABS Plastic
Recommended Age	6 years and up

9. WARRANTY AND SUPPORT

LOZ products are manufactured to high-quality standards. For any issues regarding missing parts or product defects, please contact LOZ customer support directly. Keep your purchase receipt as proof of purchase. For further assistance, please visit the [LOZ Store on Amazon](#).

© 2022 LOZ. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question