



[Manuals.plus](#) /

› [EnHomee](#) /

› EnHomee 16-Drawer Tall Dresser User Manual

## EnHomee 16D

# EnHomee 16-Drawer Tall Dresser User Manual

Model: 16D

## INTRODUCTION

Thank you for choosing the EnHomee 16-Drawer Tall Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read it thoroughly before beginning assembly and retain it for future reference.



Image: The EnHomee 16-Drawer Tall Dresser, featuring a rustic brown finish with a wooden top and sturdy metal frame.

## SAFETY INFORMATION

---

To ensure safe use of your dresser, please observe the following precautions:

- Always install the anti-tipping kit provided. This is crucial to prevent the dresser from tipping over, especially in households with children or pets.
- Do not allow children to climb on or play with the dresser.
- Distribute weight evenly across all drawers. Avoid placing excessively heavy items in a single drawer or on the top surface.
- Ensure the dresser is placed on a flat, level surface to prevent wobbling and instability.
- Keep fingers clear of drawer openings when closing to avoid pinching.

## SETUP AND ASSEMBLY

---

Before you begin, ensure you have all parts and tools laid out in a clear area. Assembly typically requires a Phillips head screwdriver (not included) and may be easier with two people.

### Package Contents:

Verify that all components listed in your product's specific assembly guide are present. Typically, this includes:

- Metal frame components
- Wooden top panel
- Fabric drawers
- Drawer handles
- Assembly hardware (screws, bolts, Allen wrench)
- Anti-tipping kit

### Assembly Steps:

1. Unpack all components and lay them out on a soft, clean surface to prevent scratches.
2. Identify each part by referring to the included assembly diagram.
3. Begin assembling the metal frame according to the step-by-step instructions. **Important: Do not fully tighten all bolts until the entire frame is assembled and squared.** This allows for minor adjustments to ensure proper alignment and drawer fit.
4. Attach the wooden top panel securely to the assembled frame.
5. Assemble the fabric drawers by inserting the bottom board and attaching the handles.
6. Insert the assembled fabric drawers into their respective slots in the frame.
7. Once the dresser is fully assembled and placed in its desired location, securely install the anti-tipping kit to the wall.



Image: A person demonstrating the ease of handling the dresser's components during assembly, highlighting its lightweight design.

## OPERATING INSTRUCTIONS

The EnHomee 16-Drawer Tall Dresser is designed for efficient storage in various rooms.

- **Drawer Usage:** Gently pull and push drawers to open and close. The fabric drawers are lightweight and designed for smooth operation.
- **Storage Capacity:** Utilize the various drawer sizes for different items. The smaller top drawers are ideal for accessories, while larger drawers accommodate clothing, linens, or other household items.
- **Weight Distribution:** For optimal stability and longevity, distribute the weight of stored items evenly across all drawers. Avoid overloading individual drawers.

# 3-Tier Design



Image: An illustration demonstrating the large storage capacity of the dresser, with examples of items like underwear, overcoats, T-shirts, bags, cosmetics, and socks.

## Product Video:

Your browser does not support the video tag.

Video: A short demonstration showcasing the EnHomee dresser in a room setting, highlighting its appearance and capacity for storing various items.

## MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning the Frame and Top:** Wipe with a dry, soft cloth. For stubborn marks, a slightly damp cloth followed by a dry cloth can be used. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning Fabric Drawers:** Spot clean fabric drawers with a mild detergent and a damp cloth. Allow to air dry completely before reinserting into the frame. Do not machine wash or tumble dry.

- **Regular Checks:** Periodically check all bolts and connections to ensure they remain tight. Retighten if necessary.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Dresser wobbles or is unstable.	Uneven floor; loose bolts; anti-tipping kit not installed.	Ensure dresser is on a level surface. Check and tighten all assembly bolts. Install the anti-tipping kit securely to the wall.
Drawers do not slide smoothly or fit correctly.	Frame not perfectly square; bolts overtightened during initial assembly.	Loosen all frame bolts slightly. Adjust the frame to ensure it is square and level. Retighten bolts evenly. Ensure fabric drawers are correctly assembled with bottom boards inserted.
New product odor.	Common with new furniture from packaging.	The odor is typically harmless and will dissipate over time. Air out the room and drawers. Using odor eliminators or placing activated charcoal can help.

## SPECIFICATIONS

Feature	Detail
Brand	EnHomee
Model Number	16D
Product Dimensions (D x W x H)	11.8"D x 37.4"W x 57.1"H
Item Weight	66.9 pounds
Material	Metal Frame, Wooden Top, Fabric Drawers
Finish	Rustic Brown
Room Type	Bedroom, Living Room
Special Feature	Sturdy, Anti-tipping kit included

# Product size

W:11.8"

L:37.5"

H:57"



Image: A detailed diagram illustrating the dimensions of the EnHomee 16-Drawer Tall Dresser, including overall height, width, depth, and individual drawer dimensions.

## WARRANTY AND SUPPORT

EnHomee stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official EnHomee website.

If you encounter any issues, require replacement parts, or have questions regarding your dresser, please contact our customer support team:

**Email:** [support@enhomee.com](mailto:support@enhomee.com)

**Phone:** 1-800-XXX-XXXX (Please check your product packaging for the most current phone number)

**Website:** [www.enhomee.com](http://www.enhomee.com)

Please have your model number (16D) and purchase date ready when contacting support.

