

[Manuals.plus](#) /

› [CAPHAUS](#) /

› CAPHAUS Lift Top Coffee Table 41" Rustic Oak - Model FLT-CH4111LTM-RUOK User Manual

CAPHAUS FLT-CH4111LTM-RUOK

CAPHAUS Lift Top Coffee Table

MODEL: FLT-CH4111LTM-RUOK (41" RUSTIC OAK)

Introduction

Thank you for choosing the CAPHAUS Lift Top Coffee Table. This manual provides detailed instructions for the assembly, operation, and maintenance of your new coffee table. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The CAPHAUS Lift Top Coffee Table in Rustic Oak, positioned in a modern living room with a sofa and laptop on the table.

Safety Information

- **Read all instructions:** Ensure you understand all assembly steps and safety warnings before proceeding.
- **Two-person assembly recommended:** Some steps may require assistance to prevent injury or damage to the product.
- **Weight Limits:** Do not exceed the specified weight capacities:
 - Tabletop (when down): 110 lbs (50 kg)
 - Tabletop (when lifted): 11 lbs (5 kg)
 - Hidden Compartment: 22 lbs (10 kg)
 - Bottom Shelf: 22 lbs (10 kg)

- **Keep children away:** During assembly, keep small parts and packaging materials away from children.
- **Stable surface:** Assemble the table on a clean, flat, and stable surface to prevent scratches or damage.
- **Proper use:** Use the table only for its intended purpose. Avoid standing or sitting on the table.
- **Pinch points:** Be aware of pinch points when operating the lift-top mechanism. Keep hands clear.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Tabletop panels
- Side and bottom panels for storage compartment
- Metal frame legs
- Lift-top mechanism hardware
- Assembly hardware (screws, bolts, nuts, etc.)
- Instruction manual

Tools Required (Not Included): Phillips head screwdriver, Allen wrench (if not provided with hardware).

Setup and Assembly Instructions

Follow these steps carefully to assemble your CAPHAUS Lift Top Coffee Table. It is recommended to have a second person assist with assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a soft, clean surface. Compare them with the parts list in your manual to ensure everything is present.
2. **Assemble the Base Frame:** Attach the metal frame legs and crossbars using the provided hardware. Ensure all connections are secure but do not overtighten until the frame is fully assembled.
3. **Construct the Storage Box:** Assemble the side and bottom panels of the hidden storage compartment. Pay attention to the orientation of the panels as indicated in the manual.
4. **Attach Lift Mechanism:** Secure the metal gas lift mechanism to the inside of the storage box and to the underside of the lift-top panel. Follow the specific diagrams in your manual for correct placement and screw types.
5. **Mount Tabletop:** Carefully attach the lift-top panel to the lift mechanism. Ensure it operates smoothly before fully tightening all screws.
6. **Install Bottom Shelf:** Place and secure the bottom open shelf to the assembled metal frame.
7. **Final Check:** Once assembled, gently test the lift-top mechanism and ensure all connections are tight and stable.

Assembly Video Guide

Your browser does not support the video tag.

Video: A detailed assembly guide for the CAPHAUS Lift Top Coffee Table, demonstrating each step of the construction process.



Image: A close-up view of the lift-top mechanism and the organized hidden storage space within the coffee table.

Operating Instructions

Lift-Top Mechanism

The coffee table features a high-quality metal gas lift mechanism for smooth operation.

- To Lift:** Gently pull the front edge of the tabletop upwards. The gas lift mechanism will assist in raising the tabletop smoothly and quietly to a comfortable height for working or dining.
- To Lower:** Apply gentle downward pressure on the tabletop. The mechanism will slowly and safely lower the tabletop back into its original coffee table position. Ensure hands and fingers are clear of the mechanism during operation.

Storage Access

- **Hidden Compartment:** When the tabletop is lifted, a spacious hidden compartment is revealed, ideal for storing laptops, remote controls, books, or other items you wish to keep out of sight.
- **Bottom Open Shelf:** The lower shelf provides additional open storage space for decorative items, magazines, or storage bins.

LIFT-TOP DESIGN

Multiple Usage To Satisfy Your Different Needs



1 Computer Table
Writing Table

2 Coffee Table

CAPHAUS

Image: The CAPHAUS coffee table shown in two states: lifted for use as a computer or writing table, and lowered as a standard coffee table.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining, especially on the rustic oak finish.

- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Avoid Excessive Moisture:** Do not place hot items directly on the surface without protection. Avoid prolonged exposure to moisture.
- **Sunlight Exposure:** Avoid direct and prolonged exposure to sunlight to prevent fading or discoloration of the wood finish.

Troubleshooting

- **Table is wobbly:** Ensure all screws and bolts are securely tightened. Check that the table is on a level surface.
- **Lift mechanism is stiff or uneven:** Ensure all components of the lift mechanism are correctly installed and free from obstructions. If the issue persists, contact customer support.
- **Missing parts:** If any parts were missing upon delivery, please contact CAPHAUS customer support with your purchase details.
- **Scratches or damage:** For minor cosmetic damage, touch-up pens or furniture repair kits matching the rustic oak finish may be used. For significant damage, contact customer support.

Specifications

Feature	Detail
Brand	CAPHAUS
Model Number	FLT-CH4111LTM-RUOK
Color	Rustic Oak
Dimensions (Collapsed)	19.7"D x 41.3"W x 18"H
Height (Lifted)	Up to 23"H
Tabletop Capacity (Down)	110 lbs (50 kg)
Tabletop Capacity (Lifted)	11 lbs (5 kg)
Hidden Compartment Capacity	22 lbs (10 kg)
Bottom Shelf Capacity	22 lbs (10 kg)
Frame Material	Solid Steel
Top Material Type	Engineered Wood (P2 Grade MDF)
Assembly Required	Yes
Includes Assembly Tools	No



Image: A diagram illustrating the dimensions and weight capacities of the CAPHAUS Lift Top Coffee Table, including the lifted tabletop, hidden compartment, and bottom shelf.

Warranty and Support

For any questions, concerns, or issues regarding your CAPHAUS Lift Top Coffee Table, please contact the seller or CAPHAUS customer support directly. Provide your purchase details and model number (FLT-CH4111LTM-RUOK) for efficient assistance.

CAPHAUS is committed to providing high-quality products and customer satisfaction. Please refer to your purchase documentation for specific warranty terms and conditions.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question