

[Manuals.plus](#) /

› [CRONY](#) /

› CRONY SQ-102 PLUS LED Quran Speaker Bluetooth With Lamp User Manual

CRONY SQ-102 PLUS

CRONY SQ-102 PLUS LED Quran Speaker Bluetooth With Lamp User Manual

Model: SQ-102 PLUS

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your CRONY SQ-102 PLUS LED Quran Speaker with Bluetooth and Lamp. Please read this manual carefully before using the product to ensure proper function and longevity.



KEY FEATURES

- **Quran Playback:** Play any Quran surah, word by word, or with translation.
- **Multiple Translations:** Supports numerous translation languages (e.g., English, French, German, Indonesian, Russian, Spanish, and many others).
- **MP3 Audio Playback:** Supports playback of any MP3 audio files.
- **Bluetooth Connectivity:** Connect wirelessly to compatible devices.
- **Integrated LED Lamp:** Provides illumination.
- **FM Radio:** Built-in FM radio function.
- **Intelligent Remote Control:** For easy navigation and function selection.
- **Combine/Single Mode:** Option to listen to Quran audio and translation simultaneously or separately.
- **Auto Sleep Function:** For energy saving.

SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove the speaker and all accessories from the packaging. Ensure all components are present: the speaker unit, remote control, and any included connectors (e.g., E27 to E14, E27 to B22).

2. **Power Connection:**

The CRONY SQ-102 PLUS is designed to be screwed into a standard light bulb socket. It supports E27, E14 (with adapter), and B22 (with adapter) sockets.

- For E27 sockets, screw the speaker directly into the socket.
- For E14 or B22 sockets, attach the appropriate connector (if provided) to the speaker first, then screw it into the socket.



Image 2: The base of the CRONY SQ-102 PLUS speaker, showing the integrated power plug for light bulb sockets.

3. **Initial Power On:** Once securely connected to a powered socket, locate the physical power switch on the speaker unit (if present) and turn it on. The LED lamp should illuminate, and the speaker will indicate it is ready for operation.
4. **Remote Control:** Insert batteries into the remote control (if not pre-installed). The remote is essential for accessing

all features.

OPERATING INSTRUCTIONS

1. Basic Functions

- **Power On/Off:** Use the power button on the remote control or the physical switch on the unit.
- **Volume Control:** Use the **VOL+** and **VOL-** buttons on the remote.
- **Lamp Control:** Use the dedicated lamp button on the remote to turn the LED lamp on or off.

2. Quran Playback

1. **Select Surah:** Press the number keys on the remote control corresponding to the desired Surah number. For example, to play Surah Al-Fatiha (Surah 1), press "1".
2. **Reciter Selection:** Use the "Qari" or "Reciter" button on the remote (if available) to cycle through different Quran reciters.
3. **Translation Mode:** Press the **MODE** button to switch between:
 - Quran audio only.
 - Quran audio with translation.
 - Translation only.

To select your preferred translation language, refer to the remote control's specific buttons or menu options, if available. The device supports multiple languages including English, French, German, Indonesian, Russian, Spanish, and others.

4. **Word-by-Word Playback:** Activate the word-by-word function (if available on remote) to listen to the Quran verse by verse, with each word pronounced individually, followed by its translation.
5. **Combine Feature:** This feature allows you to listen to your chosen Qari/Reciter's Arabic recitation simultaneously with a selected translation. Activate this via the **MODE** button or a dedicated "Combine" button.

3. Bluetooth Connectivity

1. **Activate Bluetooth:** Press the **Bluetooth** button on the remote control. The speaker will enter pairing mode, indicated by an audible prompt or flashing LED.
2. **Pairing:** On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings and search for available devices. Select "CRONY SQ-102 PLUS" (or similar name) from the list.
3. **Connection:** Once paired, the speaker will confirm the connection. You can now play audio from your device through the speaker.

4. MP3 Playback

The speaker supports playing MP3 audio files. If the device has a USB port or SD card slot (check specifications), insert your storage device with MP3 files. Use the remote control to navigate and play tracks.

5. FM Radio

Press the **FM** button on the remote control to activate the FM radio. Use the **Previous/Next** buttons to scan for stations or input frequencies directly if the remote supports it.

6. Auto Sleep

The device features an auto-sleep function to conserve energy. It will automatically enter a low-power state after a period of inactivity. Press any button on the remote to wake it up.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use liquid cleaners or abrasive materials.
- **Power Off:** Always turn off the speaker and disconnect it from the power source before cleaning or performing any maintenance.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Remote Control Batteries:** Replace remote control batteries when performance degrades. Ensure correct polarity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/Speaker not turning on.	Not properly screwed into socket; socket not powered; physical switch off.	Ensure speaker is fully screwed in; check power to the socket; turn on the physical switch on the unit.
No sound from speaker.	Volume too low; muted; incorrect mode selected; Bluetooth not connected.	Increase volume; check mute status; ensure correct playback mode (Quran, Bluetooth, FM); re-pair Bluetooth device.
Remote control not working.	Batteries depleted or incorrectly inserted; obstruction between remote and speaker.	Replace batteries, ensuring correct polarity; remove any obstructions; ensure remote is pointed at the speaker.
Bluetooth pairing issues.	Speaker not in pairing mode; device too far; interference.	Ensure speaker is in Bluetooth pairing mode; bring devices closer; restart both devices.
LED lamp not working.	Lamp function turned off; power issue.	Press the lamp button on the remote; check power connection.

SPECIFICATIONS

Brand Name	CRONY
Model Number	SQ-102 PLUS
Connectivity Technology	Bluetooth
Audio Output Mode	Mono
Mounting Type	Tabletop Mount (<i>Note: Designed for light bulb sockets, functions as a tabletop unit when placed in a compatible base</i>)
Speaker Type	Multimedia
Special Features	Bass Boost, Hi Res Audio, USB Port (<i>if applicable, check physical unit</i>)
Recommended Uses	For Music Players, For Smartphones or Tablets, For Surround Sound Systems
Compatible Devices	Laptop, Smartphone, Tablet

Unit Count	1.00 Count
Surround Sound Channel Configuration	2

Note: Specifications are subject to change without prior notice.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact CRONY customer service directly. Keep your proof of purchase for warranty claims.

Manufacturer: CRONY

Date First Available: 25 June 2023

© 2023 CRONY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question