Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fagor Commercial FG945

Fagor FG945 210W 4-in-1 Bottle Warmer Instruction Manual

Model: FG945

Introduction

Thank you for choosing the Fagor FG945 4-in-1 Bottle Warmer. This appliance is designed to safely and efficiently warm baby bottles, defrost milk, heat baby food jars, and sterilize small items. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

Key Features:

- **4-in-1 Functionality:** Reheats, defrosts, warms baby food jars, and sterilizes.
- **Wide Compatibility:** Suitable for glass and plastic bottles, baby food jars, and breast milk bags.
- **Precise Temperature Control:** Ensures an appropriate and consistent temperature for your baby's food.
- **Easy Cleaning:** The lid and basket are dishwasher safe up to 75°C.

Safety Information

Please read and follow all safety instructions carefully to prevent injury or damage.

- Always keep the appliance out of reach of children.
- Do not immerse the main unit in water or any other liquid.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance if it has a damaged cord or plug, or if it malfunctions or has been damaged in any way.
- Always check the temperature of the warmed milk or food before feeding your baby.
- Hot water and steam can cause severe burns. Exercise caution when handling the appliance during and after operation.
- Use only distilled water for optimal performance and to prevent mineral buildup.
- Do not use abrasive cleaning agents or harsh chemicals on the appliance.

Product Components

Familiarize yourself with the parts of your Fagor FG945 Bottle Warmer:

1. Main Unit with Heating Plate
2. Control Knob (OFF / Defrost / Warm / Heat / Sterilize)
3. Indicator Light
4. Lid
5. Basket (for bottles/jars/sterilization)



Image: The Fagor FG945 Bottle Warmer main unit, separate lid, and basket for holding items.

Setup

Before using the Fagor FG945 Bottle Warmer for the first time:

1. Unpack all components and remove any packaging materials.
2. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
3. Wash the lid and basket in warm soapy water, rinse thoroughly, and dry. These parts are also dishwasher safe (top rack, up to 75°C).
4. Place the bottle warmer on a stable, flat, heat-resistant surface, away from direct sunlight or heat sources.
5. Ensure the power cord is not tangled and is placed safely to avoid tripping hazards.



Image: The Fagor FG945 Bottle Warmer with its protective lid in place, ready for use.

Operating Instructions

Always ensure the appliance is plugged into a suitable power outlet before operation.

1. Reheating Bottles (Milk/Formula)

1. Place the basket into the main unit.
2. Pour distilled water into the main unit, ensuring the water level is below the rim of the basket and covers the base of the bottle. Do not overfill.
3. Place the baby bottle (with cap removed) into the basket.
4. Place the lid on the unit.
5. Turn the control knob to the 'Heat' setting (usually indicated by a bottle icon).
6. The indicator light will illuminate, signifying the heating process has begun.
7. Heating time varies based on the initial temperature and volume of the liquid. Monitor the process.
8. Once warmed, carefully remove the bottle using the basket handle or tongs.
9. Always shake the bottle gently and check the milk temperature on your wrist before feeding.
10. Turn the control knob to 'OFF' after use.



Image: The Fagor FG945 Bottle Warmer with a baby bottle placed inside the warming chamber.

2. Defrosting

1. Place the frozen breast milk bag or bottle into the basket within the main unit.
2. Add distilled water to the main unit, ensuring it covers the frozen item.
3. Place the lid on the unit.
4. Turn the control knob to the 'Defrost' setting (usually indicated by a snowflake icon).
5. The indicator light will turn on.
6. Defrosting time will vary. Monitor the process until the milk is thawed.
7. Once defrosted, you may proceed to warm the milk if desired, or store it according to guidelines.
8. Turn the control knob to 'OFF' after use.

3. Warming Baby Food Jars

1. Place the baby food jar (without lid) into the basket within the main unit.
2. Add distilled water to the main unit, ensuring it reaches the level of the food in the jar.
3. Place the lid on the unit.
4. Turn the control knob to the 'Warm' setting (usually indicated by a food jar icon).
5. The indicator light will turn on.
6. Monitor the food until it reaches the desired temperature. Stir the food to ensure even heating.
7. Carefully remove the jar using the basket handle or tongs.
8. Always stir and check the food temperature before feeding your baby.
9. Turn the control knob to 'OFF' after use.

4. Sterilizing

1. Place small items like pacifiers, bottle nipples, or small bottle parts into the basket.
2. Pour approximately 50-80ml of distilled water into the main unit.
3. Place the lid on the unit.
4. Turn the control knob to the 'Sterilize' setting (usually indicated by a steam icon).
5. The indicator light will turn on, and steam will be generated.
6. Allow the cycle to complete (typically a few minutes) until the water has evaporated or the indicator light turns off.
7. Carefully remove the lid, being mindful of hot steam. Use tongs to remove sterilized items.
8. Turn the control knob to 'OFF' after use.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene.

- Always unplug the appliance and allow it to cool completely before cleaning.
- **Main Unit:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners. Never immerse the main unit in water.
- **Lid and Basket:** These parts can be washed in warm soapy water, rinsed, and dried. They are also dishwasher safe (top rack, maximum temperature 75°C).
- **Descaling:** Mineral deposits (limescale) may build up on the heating plate over time, especially with hard water. To descale, mix 50ml of white vinegar with 100ml of cold water and pour it into the main unit. Let it stand for 30 minutes to 1 hour (or longer for heavy buildup). Do not turn on the appliance during descaling. Pour out the solution and rinse the heating plate thoroughly with clean water. Repeat if necessary.
- Store the appliance in a clean, dry place when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; control knob not set.	Ensure the appliance is securely plugged in. Check the power outlet with another device. Turn the control knob to a desired function (e.g., Heat).
Milk/food is not warming sufficiently.	Insufficient water; incorrect setting; heavy limescale buildup.	Ensure adequate water level. Select the correct heating setting. Descale the appliance if necessary.

Problem	Possible Cause	Solution
Limescale buildup on heating plate.	Use of tap water; infrequent cleaning.	Use distilled water for operation. Perform descaling as per maintenance instructions.
Water boils too quickly during sterilization.	Too little water added for sterilization.	Ensure approximately 50-80ml of distilled water is used for sterilization.

Specifications

- **Model:** FG945
- **Manufacturer:** FAGOR
- **Power:** 210W (as per product title)
- **Package Dimensions:** 24.1 x 15.7 x 15.7 cm
- **Weight:** 770 grams
- **ASIN:** B0BH7XP33X
- **Dishwasher Safe Parts:** Lid and basket (up to 75°C)

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your purchase or contact Fagor Commercial customer service directly. Keep your proof of purchase for warranty claims.
For further assistance, please visit the official Fagor Commercial website or contact their authorized service centers.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BH7XP33X

More documents and user manuals: **https://manuals.plus/**