

Disney 062240

Instruction Manual

DISNEY PRINCESS LIGHT N' SOUNDS ACTIVITY RIDE ON

Brand: Disney | Model: 062240

1. Introduction and Overview

The Disney Lights N' Sounds Princess Activity Ride-on is designed to provide an enchanting and interactive play experience for young children. This foot-to-floor ride-on features engaging lights and sounds, an interactive dashboard, and a steering wheel, encouraging active play and development of motor skills.

This manual provides essential information for the safe and proper use, assembly, and maintenance of your Disney Princess Activity Ride-On.

2. Safety Information

WARNING: Adult assembly required. Adult supervision is required at all times during use.

- Recommended for ages 12-36 months.
- Ensure all parts are securely fastened before each use.
- Do not use near stairs, swimming pools, or on sloped surfaces.
- Only use on flat, level surfaces.
- Keep small parts away from children during assembly to prevent choking hazards.
- Batteries should be installed and replaced by an adult. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

3. What's in the Box

Please check the contents of the package to ensure all parts are present:

- 1 x Disney Princess Light N' Sounds Activity Ride On

Note: Batteries are not included and must be purchased separately. Refer to the battery compartment for required battery type and quantity.

4. Setup and Assembly

The Disney Princess Activity Ride-On comes mostly pre-assembled. Follow these steps for final setup:

1. Steering Wheel Attachment:

Align the steering wheel with the steering column on the main body of the ride-on. Push down firmly until it clicks into place. Ensure it is securely attached and rotates freely.



Figure 4.1: Fully assembled ride-on with steering wheel and handle.

2. Battery Installation:

Locate the battery compartment, typically on the dashboard or under the seat. Using a screwdriver, open the compartment. Insert the required batteries (e.g., AA or AAA, refer to product labeling) ensuring correct polarity (+/-). Close the compartment securely.



Figure 4.2: Dashboard with battery compartment.

3. Handle Attachment (if separate):

If the rear push handle is separate, insert it into the designated slot at the back of the ride-on. Push down firmly until it locks into position. This handle assists parents or older siblings in pushing the ride-on.



Figure 4.3: Rear push handle for assistance.

5. Operating Instructions

Once assembled and batteries are installed, the ride-on is ready for use:

- **Riding:**

Children can sit on the seat and use their feet to push the ride-on forward or backward. The low-to-the-ground design allows for easy foot-to-floor action, promoting balance and coordination.



Figure 5.1: Child demonstrating foot-to-floor riding.

- **Steering:**

The steering wheel allows children to control the direction of the ride-on. Encourage them to practice turning left and right to develop steering skills.

- **Interactive Dashboard:**

Press the various buttons on the dashboard to activate flashing lights, revving engine sounds, horn sounds, and other fun electronic activities. These features enhance the play experience and

stimulate sensory development.



Figure 5.2: Close-up of the interactive dashboard.

- **Push Handle Use:**

For younger children or for parental assistance, use the rear push handle to guide the ride-on. This allows for controlled movement and helps children learn to steer before they can fully propel themselves.

6. Features

- **Lights & Sounds:** The ride-on features enchanting sounds and flashing lights for an immersive play experience.
- **Interactive Dashboard:** Equipped with electronic activities, including a revving engine sound, horn, and other engaging sounds.
- **Balance & Coordination:** Designed for foot-to-floor action, promoting the development of balance, coordination, and gross motor skills.
- **Push & Steer:** Includes a convenient push handle at the rear and a functional steering wheel for easy maneuverability by both child and parent.
- **Durable Construction:** Made with safe and durable materials to withstand active play.
- **Disney Princess Theme:** Adorned with colorful graphics of beloved Disney Princesses,

enhancing imaginative play.



Figure 6.1: Front view highlighting Disney Princess graphics and interactive elements.

7. Maintenance

- **Cleaning:** Wipe the ride-on with a damp cloth and mild soap. Do not immerse in water. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the ride-on in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.
- **Inspection:** Regularly check for loose parts, damaged components, or excessive wear. Discontinue use if any damage is found and contact customer support.

8. Troubleshooting

Problem	Possible Cause	Solution
No lights or sounds.	Batteries are dead or incorrectly installed.	Replace batteries with new ones, ensuring correct polarity.
Sounds are distorted or weak.	Low battery power.	Replace batteries.
Wheels do not roll smoothly.	Debris caught in wheels or damaged wheels.	Check and remove any debris. If wheels are damaged, contact customer support.

9. Specifications

- **Model Number:** 062240
- **Product Dimensions:** 20.5 x 10 x 15 inches
- **Item Weight:** 5.09 pounds
- **Recommended Age:** 12 months - 3 years
- **Manufacturer:** Kiddieland
- **Country of Origin:** China

10. Product Overview Video

Watch this official product overview video for a visual guide on the features and operation of the Disney Princess Light N' Sounds Activity Ride On.

Your browser does not support the video tag.

Video 10.1: Official Product Overview of the Disney Princess Ride-On. This video demonstrates the flashing lights, interactive dashboard sounds (revving engine, horn), and the push-pull handle with steering wheel. It also highlights the durable construction and suitability for ages 12-36 months, emphasizing balance and coordination development.

11. Warranty and Support

For warranty information or customer support, please refer to the packaging or contact the manufacturer, Kiddieland, directly. Keep your purchase receipt as proof of purchase.

For additional assistance, you may also visit the [Disney Store on Amazon](#).