

JBL JBLWBUDSBLK

JBL Wave Buds True Wireless Earbuds User Manual

Model: JBLWBUDSBLK

INTRODUCTION

This manual provides comprehensive instructions for the JBL Wave Buds True Wireless Earbuds. It covers product setup, operation, features, maintenance, and troubleshooting to ensure optimal performance and user experience. Please read this manual thoroughly before using your earbuds.



Image: JBL Wave Buds earbuds and their charging case.

WHAT'S IN THE BOX

Your JBL Wave Buds package includes the following items:

- JBL Wave Buds True Wireless Earbuds
- Charging Case
- USB Charging Cable (Type-C)
- Multiple sizes of ear tips for a comfortable fit
- Quick Start Guide
- Safety Sheet
- Warranty Card

SETUP

1. Initial Pairing

1. **Charge the Earbuds:** Before first use, place both earbuds into the charging case and connect the case to a power source using the provided USB cable. Ensure the earbuds and case are fully charged.

2. **Activate Pairing Mode:** Open the charging case. The earbuds will automatically enter pairing mode. The LED indicator on the earbuds will flash.
3. **Connect via Bluetooth:** On your mobile device, go to Bluetooth settings and select "JBL Wave Buds" from the list of available devices. For Android users, Google Fast Pair will simplify this process by automatically detecting the earbuds when the case is opened near your device.
4. **Confirmation:** Once connected, the LED indicator on the earbuds will turn solid blue or white, and you will hear an audible confirmation.

2. JBL Headphones App

Download the [JBL Headphones App](#) from your device's app store (Google Play Store or Apple App Store) to unlock full features, customize sound settings, and manage your earbuds.



Image: Screenshot of the JBL Headphones App showing equalizer settings.

The app allows for personalized equalizer adjustments, enabling you to fine-tune the audio experience, including enhancing the JBL Deep Bass sound.

3. Fitting the Earbuds

For optimal sound quality and comfort, select the ear tips that provide the best seal in your ear canal. Gently insert the earbuds and twist them slightly to secure a snug fit.




Image: Diagram illustrating the ergonomic design and proper fit of the earbuds with oval ear tips.

OPERATING THE EARBUDS

Touch Controls

The JBL Wave Buds feature intuitive touch controls on each earbud. Specific functions can be customized via the JBL Headphones App.

- **Music Playback:** Tap to play/pause, double-tap for next track, triple-tap for previous track.
- **Call Management:** Tap to answer/end a call, double-tap to reject a call.
- **Voice Assistant:** Long press (duration customizable in app) to activate your device's voice assistant.
- **Volume Control:** Typically, a single tap on the left or right earbud can adjust volume, configurable in the app.

Ambient Aware & TalkThru

These features allow you to stay connected to your surroundings without removing your earbuds.

- **Ambient Aware:** Enhances ambient sounds, allowing you to hear your surroundings while listening to audio. Useful for safety in public spaces.
- **TalkThru:** Lowers music volume and amplifies voices, enabling quick conversations without removing the earbuds.



Image: A person wearing earbuds, demonstrating the Ambient Aware feature for situational awareness.



Image: Two individuals engaged in conversation, with one wearing earbuds, highlighting the TalkThru function.

Mono and Stereo Modes

You can use both earbuds together for a stereo experience or use a single earbud independently in mono mode. Simply remove one earbud from the case to use it alone.

FEATURES

JBL Deep Bass Sound

Equipped with 8mm dynamic drivers, the JBL Wave Buds deliver a rich audio experience with enhanced bass. This can be further customized using the JBL Headphones App's equalizer settings.




Image: A woman smiling while listening to music with JBL earbuds, representing the JBL Extra Bass Sound feature.

Battery Life and Quick Charge

Enjoy extended listening with up to 32 hours of combined battery life. The earbuds provide 8 hours of playback, and the charging case holds an additional 24 hours of charge.



Image: Graphic illustrating the total 32 hours of playtime, broken down into 8 hours for the earbuds and 24 hours provided by the charging case.

The quick charge feature allows for 2 hours of additional playtime with just a 10-minute charge.



Image: The charging case connected via a USB-C cable, highlighting the quick charge capability.

IP54 Water and Dust Resistance

The JBL Wave Buds are IP54-certified, making them resistant to dust and splashes of water. This ensures durability for various activities and environments.



Image: JBL Wave Buds on a sandy surface with water splashing, demonstrating their IP54 dust and water resistance.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Ear Tips:** Remove ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- **Charging Contacts:** Periodically clean the charging contacts on both the earbuds and the case with a dry cotton swab to ensure proper charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then reopen. Check your device's Bluetooth settings and forget/remove "JBL Wave Buds" then try pairing again.
No sound or low volume	Check device volume and earbud volume. Ensure earbuds are properly seated in your ears. Try different ear tip sizes. Clean earbud grilles.
Charging issues	Clean charging contacts on earbuds and case. Ensure USB cable is securely connected and power source is active. Try a different USB cable or power adapter.
Intermittent connection	Ensure your device is within Bluetooth range (up to 10 meters). Avoid obstructions between your device and earbuds. Minimize interference from other wireless devices.
Microphone not working	Ensure earbuds are connected and selected as the audio input device. Clean microphone openings.

SPECIFICATIONS

Model Name	Wave Series
Model Number	JBLWBUDSBLK
Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Range	10 Metres
Audio Driver Type	Dynamic Driver (8mm)
Frequency Range	20 Hz - 20,000 Hz
Impedance	16 Ohm
Sensitivity	100 dB
Battery Life (Earbuds)	Up to 8 Hours
Battery Life (Charging Case)	Up to 24 Hours (Total 32 Hours)
Charging Time	2 Hours (Full Charge)
Quick Charge	10 minutes charge for 2 hours playtime

Water Resistance Level	IP54 (Earbuds)
Item Weight	43 Grams (Total)
Control Type	Touch (Media, Voice, Volume, Call)
Microphone Format	Built-In
Special Features	JBL Deep Bass, Smart Ambient, Ergonomic Design, Google Fast Pair with Bluetooth 5.2, Mono and Stereo modes, Voice Assistant Support, Hands-free calls with VoiceAware, JBL Headphones App

WARRANTY AND SUPPORT

The JBL Wave Buds come with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures repair or replacement of the product under specified conditions.

For warranty claims, technical support, or further assistance, please contact JBL customer service or visit the official JBL support website. Keep your proof of purchase for warranty validation.

You can find more information and support resources on the [JBL Support Website](#).