

Silvercrest SDBK 2400 E1

SILVERCREST Steam Iron SDBK 2400 E1 User Manual

Model: SDBK 2400 E1 | Brand: Silvercrest

1. INTRODUCTION

This user manual provides important information for the safe and efficient operation of your SILVERCREST SDBK 2400 E1 Steam Iron. Please read these instructions carefully before first use and keep them for future reference. This appliance is designed for domestic use only.



Image 1.1: The Silvercrest SDBK 2400 E1 Steam Iron, showcasing its sleek design and yellow water tank.

2. SAFETY INSTRUCTIONS

Always observe the following safety precautions to prevent injury or damage to the appliance:

- Ensure the voltage indicated on the rating plate matches your mains voltage.
- Do not immerse the iron, charging base, or power cord in water or other liquids.
- Keep the iron out of reach of children and pets.
- Always unplug the iron from the power outlet before filling or emptying the water tank, and when not in use.

- Never leave a hot iron unattended.
- Place the iron on a stable, heat-resistant surface when not in use.
- Do not operate the iron if it has a damaged cord or plug, or if it has been dropped or damaged.
- Only use the iron for its intended purpose of ironing fabrics.
- The soleplate can become extremely hot. Avoid direct contact with skin.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your steam iron:

1. Water spray nozzle
2. Water tank filling inlet
3. Steam control dial (Dry, Min Steam, Max Steam)
4. Spray button
5. Steam shot button (for horizontal and vertical steam)
6. Temperature control dial
7. Indicator light (for heating status)
8. Handle
9. Ceramic soleplate
10. Cordless base station
11. Power cord
12. Measuring cup



Image 3.1: The Silvercrest SDBK 2400 E1 Steam Iron detached from its 360° cordless base station.

4. SETUP

Before using your iron for the first time:

1. **Unpacking:** Remove all packaging materials and labels from the iron and its accessories.
2. **First Use Preparation:** It is normal for a slight odor or smoke to occur during the first few uses as manufacturing residues burn off. This is harmless and will disappear quickly.
3. **Filling the Water Tank:**
 - Ensure the iron is unplugged and cooled down.

- Set the steam control dial to the "Dry" position.
- Open the water tank filling inlet.
- Using the provided measuring cup, fill the water tank with clean tap water up to the "MAX" mark (320 ml capacity). Do not overfill.
- Close the filling inlet securely.

4. **Connecting to Power:** Place the cordless base station on a stable, heat-resistant surface. Plug the power cord into a suitable wall outlet.

5. OPERATING INSTRUCTIONS

Your SILVERCREST SDBK 2400 E1 iron offers both cordless and corded operation for maximum flexibility.

5.1. Temperature Setting

1. Place the iron onto the cordless base station.
2. Turn the temperature control dial to the desired setting according to the fabric type (refer to garment care labels).
3. The indicator light will illuminate, indicating the iron is heating. It will turn off when the set temperature is reached.
4. For optimal results, allow the iron to reheat on the base station briefly between ironing passes, especially during steam ironing.



Image 5.1: The Silvercrest SDBK 2400 E1 Steam Iron positioned on an ironing board, ready for use.

5.2. Dry Ironing

- Ensure the water tank is empty or the steam control dial is set to the "Dry" position.
- Set the desired temperature.
- Once the indicator light turns off, the iron is ready for dry ironing.

5.3. Steam Ironing

- Fill the water tank as described in Section 4.
- Set the temperature control dial to a setting suitable for steam (usually between "••" and "•••" or MAX, depending on the fabric).
- Once the indicator light turns off, set the steam control dial to the desired steam level (Min Steam or Max Steam).
- The iron will now produce continuous steam.
- The anti-drip system prevents water from dripping from the soleplate at low temperatures.




Image 5.2: A user demonstrating the steam ironing function of the Silvercrest SDBK 2400 E1, showing steam emanating from the soleplate.

5.4. Steam Shot Function

- This function provides an extra burst of steam for stubborn wrinkles.
- Ensure the iron is at maximum temperature and the water tank is sufficiently filled.
- Press the steam shot button. Wait a few seconds between shots to allow the steam to regenerate.

5.5. Vertical Steam

- The steam shot function can also be used for vertical steaming of hanging garments or curtains.
- Hold the iron vertically, about 10-20 cm away from the fabric.
- Press the steam shot button repeatedly.

5.6. Spray Function

- For dampening stubborn creases, press the spray button.
- Ensure the water tank has water.



Image 5.3: A close-up view of the Silvercrest SDBK 2400 E1 Steam Iron in action, highlighting the steam output from the soleplate.

5.7. Corded Operation

While primarily designed for cordless use, the iron can also be used with the power cord directly connected for continuous heating, if preferred. Simply attach the iron to the base and ensure the cord is plugged in.

6. MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and performance of your iron.

- **Cleaning the Soleplate:** If the soleplate becomes dirty, clean it with a damp cloth and a non-abrasive cleaner. Do not use metal scouring pads or abrasive cleaners.
- **SelfClean Function:** Your iron is equipped with a SelfClean function to remove scale and impurities from the steam chamber.
 - Fill the water tank to the MAX level.
 - Set the steam control to "Dry" and the temperature to MAX.

- Once the iron reaches maximum temperature, unplug it.
- Hold the iron horizontally over a sink.
- Press and hold the SelfClean button (if available, otherwise use the steam shot button repeatedly while shaking the iron gently). Hot water and steam will be expelled from the soleplate, carrying impurities.
- Continue until the water tank is empty.
- Reheat the iron and iron an old cloth to dry the soleplate.

- Anti-Calc System:** The integrated anti-calc system helps reduce limescale build-up. However, regular SelfClean is still recommended, especially in hard water areas.
- Emptying and Storage:** After use, empty any remaining water from the tank. Allow the iron to cool completely before storing it upright on its base station or heel rest.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron not heating up.	Not plugged in; temperature dial set to MIN; iron not on base station (for cordless).	Check power connection; turn temperature dial to desired setting; ensure iron is correctly placed on the base.
No steam or insufficient steam.	Water tank empty; temperature too low; steam control set to "Dry"; calc build-up.	Fill water tank; set temperature higher (to steam range); set steam control to desired steam level; perform SelfClean.
Water dripping from soleplate.	Temperature too low for steam; water tank overfilled.	Increase temperature; do not overfill water tank. The anti-drip system should prevent this at correct temperatures.
White flakes coming from soleplate.	Limescale build-up.	Perform SelfClean function. Use distilled or demineralized water in hard water areas.

8. SPECIFICATIONS

- Model:** SDBK 2400 E1
- Brand:** Silvercrest
- Power Consumption:** 2000 – 2400 W
- Voltage:** 220 – 240 V ~
- Frequency:** 50 Hz
- Water Tank Capacity:** 320 ml
- Soleplate Material:** High-quality Ceramic
- Special Features:** Cordless operation, Steam shot, Vertical steam, Spray function, Anti-drip system, SelfClean function, 360° base station.
- Item Weight:** Approximately 980 g
- Package Dimensions:** 35 x 16.7 x 15.2 cm

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or contact Silvercrest customer service. Keep your proof of purchase for warranty claims.

For further assistance, please visit the official Silvercrest website or contact their authorized service centers.

© 2024 Silvercrest. All rights reserved.
This manual is subject to change without prior notice.

Documents - Silvercrest – SDBK 2400 E1



[\[pdf\]](#) User Manual Guide

SILVERCREST® Stoomstrijkijzer online kopen LIDL 92474501 714b 4206 b6f3 16e1bdcb39c2 manuals sit connect public articlemanual |||

KURZANLEITUNG SHORT MANUAL GUIDE DE DMARRAGE RAPIDE

KABELLOSES DAMPFBÜGELEISEN/CORDLESS STEAM IRON/FER REPASSER

VAPEUR SANS FIL **SDBK 2400 E1** KABELLOSES DAMPFBÜGELEISEN BEZKBLOV

NAPAROVACIA Kurzanleitung ZEHICKA Krtky nvod CORDLESS STEAM IRON

Short manual PLANCHA DE VAPOR SIN CABLE Gua rpida...

lang:de score:16 filesize: 3.7 M page_count: 99 document date: 2023-11-15