

[manuals.plus](#) /

› [CkeyiN](#) /

› [CkeyiN Electric Razor for Men User Manual](#)

**CkeyiN 316L-JRYCA-RC**

# CkeyiN Electric Razor for Men User Manual

Model: 316L-JRYCA-RC

## 1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your CkeyiN Electric Razor. Please read this manual thoroughly before first use and retain it for future reference. This electric foil shaver is designed for men's beard shaving, trimming, and grooming, offering both wet and dry shaving capabilities.

# CLASSIC RECIPROCATING DOUBLE-HEADED ELECTRIC SHAVER

Portable and easy to carry Free to shave



Image 1.1: The CkeyiN Electric Razor, highlighting its classic reciprocating double-headed design for portable and easy shaving.

## 2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Always unplug the shaver before cleaning or if not in use for an extended period.
- Do not use the shaver while it is charging.
- Exercise caution when using the shaver near water, even though it is designed for wet use. Ensure the charging port is dry before connecting the USB cable.
- For optimal results and to minimize skin irritation, consider using shaving cream or gel during wet shaving.
- Avoid applying excessive pressure to the skin, as this may lead to irritation or minor cuts.
- Clean and dry the shaver thoroughly after each use to prevent bacterial growth and maintain hygiene.
- Keep the appliance out of reach of children.
- Do not disassemble or attempt to repair the shaver yourself. Contact customer support for assistance.

### 3. PRODUCT OVERVIEW AND PACKAGE CONTENTS

The CkeyiN Electric Razor is a compact and portable foil shaver designed for efficient grooming. It features a double-headed foil system for a close shave.



Image 3.1: The CkeyiN Electric Razor shown with its protective cap, replaceable foil head, USB charging cable, cleaning brush, and carrying bag.

#### Package Contents:

- 1 x CkeyiN Electric Shaver
- 1 x USB Charging Cable
- 1 x Replaceable Foil Head
- 1 x Protective Cap
- 1 x Cleaning Brush
- 1 x Carrying Bag
- 1 x User Manual (this document)



Image 3.2: Exploded view diagram illustrating the main components of the shaver, including the body, blade, head, protector, on/off switch, and charging socket.

## 4. SETUP AND CHARGING

---

### Initial Charge:

Before using your CkeyiN Electric Razor for the first time, ensure it is fully charged. A full charge provides approximately 60 minutes of cordless run time.

1. Locate the USB charging port on the shaver.
2. Connect the provided USB charging cable to the shaver's port.
3. Connect the other end of the USB cable to a compatible power source, such as a computer, power bank, or a USB power adapter (not included).
4. The charging indicator will illuminate to show that the device is charging. Once fully charged, the indicator may change color or turn off, depending on the model.

## Multiple ways to charge, convenient and quick charge



Adapter



Power Bank



Computer



Laptop



Image 4.1: The electric razor being charged via a USB cable connected to a laptop, demonstrating multiple convenient charging methods.

## 5. OPERATING INSTRUCTIONS

The CkeyiN Electric Razor supports both dry and wet shaving for your convenience.

### General Shaving Tips:

- For best results, ensure your beard length is below 2mm. If you have a longer beard, it is recommended to trim it down to 1-2mm using a professional electric shaver or trimmer before using this foil shaver for a precise finish.
- Hold the shaver at a right angle (90 degrees) to your skin.
- Move the shaver against the direction of hair growth using gentle, straight strokes. Avoid circular motions.
- Stretch your skin with your free hand to make the hairs stand upright and ensure a closer shave.

## Suitable for shaving beard below 2mm.

If you want to trim long beard, please use a professional electric shave to cut short hair to leave only 1-2mm in length, then use our electric foil shaver to trim precisely.




Image 5.1: Illustration showing the recommended process for shaving, starting with trimming longer beards to below 2mm before using the foil shaver for a precise shave.

### Dry Shaving:

For a quick and convenient shave, use the shaver on dry skin. Ensure your face is clean and dry before starting.

### Wet Shaving:

For a more comfortable and smoother shave, apply shaving foam or gel to your face before using the shaver. The shaver is designed to be waterproof for wet use.

# DRY AND WET DUAL USE INTELLIGENT AND COMFORTABLE

**NOTE:** Long beards need to be shaved short below 2mm before using our razor.



**Dry shaving**



**Wet shaving**

Image 5.2: A visual comparison demonstrating the use of the shaver for both dry shaving and wet shaving with foam, highlighting its dual-use capability.

## Areas of Use:

The shaver is suitable for various facial areas including the cheeks, neck, lower lip, and corner of the mouth. Always ensure proper technique for each area.



Image 5.3: Examples of shaving different facial areas such as the corner of the mouth, lower lip, neck, and cheek, illustrating the shaver's versatility.




Image 5.4: A visual guide demonstrating the correct shaving angle and technique for optimal results and comfort.

## 6. MAINTENANCE

### Cleaning the Shaver:

Regular cleaning ensures optimal performance and hygiene. The shaver head is detachable and washable.

1. Turn off the shaver and disconnect it from any power source.
2. Gently detach the shaver head from the body.
3. Use the provided cleaning brush to remove loose hairs from the foil and cutter blades.
4. Rinse the detached shaver head under running water. Ensure all hair residue is removed.
5. Allow the shaver head to air dry completely before reattaching it to the shaver body.
6. Do not immerse the entire shaver body in water, only the detachable head is designed for rinsing.



Image 6.1: A hand demonstrating the correct way to rinse the detachable shaver head under running water for easy cleaning.

### Replacing the Foil Head:

For continued optimal shaving performance, the foil head should be replaced periodically, typically every 6-12 months, depending on usage.

1. Ensure the shaver is turned off and unplugged.
2. Carefully detach the old foil head.
3. Align the new replaceable foil head with the shaver body and gently press it into place until it clicks

securely.

## 7. TROUBLESHOOTING

If you encounter any issues with your CkeyiN Electric Razor, refer to the following common problems and solutions:

- **Shaver not turning on:** Ensure the shaver is fully charged. If the battery is depleted, connect it to a power source and allow it to charge for at least 30 minutes before attempting to turn it on again.
- **Poor shaving performance / pulling hair:**
  - Check if the foil head is clean and free of hair buildup. Clean it as described in the Maintenance section.
  - Ensure the foil head is not damaged or worn out. Replace it if necessary.
  - Make sure your beard length is appropriate (below 2mm) for the foil shaver. Trim longer hair first.
  - Apply gentle pressure and shave against the direction of hair growth.
- **Battery not holding charge:** Ensure the charging cable and adapter are working correctly. If the issue persists after trying a different cable/adapter, the battery may need servicing.
- **Excessive skin irritation:** Reduce pressure during shaving. Consider using wet shaving with foam/gel. Ensure the foil head is clean and not damaged.

If the problem persists after attempting these solutions, please contact customer support.

## 8. SPECIFICATIONS

Feature	Specification
Brand	CkeyiN
Model Number	316L-JRYCA-RC
Head Type	Foil
Blade Material	Stainless Steel
Power Source	Battery Powered (USB Rechargeable)
Battery Life	Approximately 60 minutes
Special Features	Cordless, Dry Shave, Rechargeable, Wet Shave
Color	Emerald
Item Weight	169 Grams
Parcel Dimensions	15.8 x 14.4 x 4.2 cm

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

For further assistance or inquiries, please visit the official CkeyiN website or contact their customer service department.