

[Manuals.plus](#) /

> [Iseyyox](#) /

> User Manual: Iseyyox 3-in-1 Foldable Magnetic Wireless Charging Station

Iseyyox CW340

Iseyyox 3-in-1 Foldable Magnetic Wireless Charging Station

Model: CW340

INTRODUCTION

Thank you for choosing the Iseyyox 3-in-1 Foldable Magnetic Wireless Charging Station. This versatile device is designed to efficiently charge your iPhone (12 series and above), Apple Watch, and AirPods simultaneously. Its compact and foldable design makes it ideal for both home use and travel. Please read this manual carefully to ensure proper setup and operation.




Figure 1: The Iseyyox 3-in-1 Foldable Magnetic Wireless Charging Station with its power adapter.

PACKAGE CONTENTS

- 1 x Iseyyox 3-in-1 Wireless Charging Station
- 1 x 18W QC Adapter
- 1 x Charging Cable (USB Type-C)
- 1 x User Manual

Magnetic & Auto-alignment

- ✓ Magnetic Adsorption
- ✓ Automatic Alignment



Other Similar Wireless Charger

- ✗ Non-magnetic
- ✗ Manual Adjustment




Figure 2: All components included in the product package.

SETUP INSTRUCTIONS

1. **Connect the Power Adapter:** Insert the USB Type-C end of the charging cable into the charging station and the USB-A end into the provided 18W QC adapter.
2. **Plug into Power Outlet:** Plug the 18W QC adapter into a wall power outlet. Ensure the outlet is functioning correctly.

3. **Prepare for Charging:** Unfold the charging station to its desired configuration (flat or stand mode) depending on your charging needs.



Figure 3: Placing a device on the magnetic charging pad for automatic alignment.

OPERATING INSTRUCTIONS

Charging Your Devices

This charging station features three dedicated charging areas for your Apple devices:

- **iPhone Charging Area:** The magnetic charging pad is designed for iPhone 12 series and above (iPhone 16/16 Plus/16Pro/16 Pro max, 15/15 Plus/15Pro/15 Pro max, 14/14 Pro/14 Plus/14 Pro Max, 13/13 Pro/13 Pro Max, 12/12 Pro/12 Pro Max). Simply place your iPhone on the magnetic surface; it will automatically align for optimal charging.
- **Apple Watch Charging Area:** Place your Apple Watch (Ultra 10 9 8 7 6 5 4 3 2 & SE) on the designated watch charging stand.
- **AirPods Charging Area:** Place your AirPods (2/3/Pro/Pro 2) with a wireless charging case on the central charging pad.

Universal Compatibility

10W for Phone



iPhone 16 Series

iPhone 16
iPhone 16 Pro
iPhone 16 Plus
iPhone 16 Pro max



iPhone 15 Series

iPhone 15
iPhone 15 Pro
iPhone 15 Plus
iPhone 15 Pro max



iPhone 14 Series

iPhone 14
iPhone 14 Pro
iPhone 14 Plus
iPhone 14 Pro max



iPhone 13 Series

iPhone 13
iPhone 13 mini
iPhone 13 Pro
iPhone 13 Pro max



iPhone 12 Series

iPhone 12
iPhone 12 mini
iPhone 12 Pro
iPhone 12 Pro max

2.5W Smart Watch



Compatible with Apple Watch 2/3/4/5/6/7/8/9/10/ Ultra / SE

5W for Earphone



AirPods 4/3/2 AirPods Pro/ Pro 2

Only Support
Mag-Safe
Charging Case



Figure 4: Charging an iPhone, Apple Watch, and AirPods simultaneously.

Foldable Design and Stand Functionality

The charging station can be folded into a compact form for easy portability or configured as a phone stand. In stand mode, you can place your iPhone horizontally or vertically for viewing content while it charges.



Figure 5: The charging station configured as a phone stand.



Figure 6: The charging station's compact, foldable design for travel.

MAINTENANCE

To ensure the longevity and optimal performance of your charging station, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the charging station. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Avoid Liquids:** Keep the device away from water and other liquids. If it comes into contact with liquid, disconnect it immediately and allow it to dry completely before reuse.
- **Temperature Control:** Avoid exposing the charging station to extreme temperatures (below 32°F / 0°C or above 122°F / 50°C).
- **Storage:** When not in use, store the charging station in a cool, dry place, away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging	Incorrect placement; device not wireless charging compatible; power adapter issue; thick phone case.	Ensure device is centered on the charging pad. Verify device supports wireless charging. Use the included 18W QC adapter and cable. Remove phone cases thicker than 2mm.
Slow charging	Using a non-18W QC adapter; background apps; device overheating.	Ensure you are using the provided 18W QC adapter. Close unnecessary background applications on your device. Allow the device to cool down if it feels warm.
Charging interrupted	Over-temperature protection activated; foreign object detection.	If the working temperature exceeds 122°F (50°C), charging will pause. Remove any metal objects or foreign materials from the charging surface.
Magnetic alignment not working	Device not MagSafe compatible; phone case interference.	Ensure your iPhone is a 12 series or newer. Use a MagSafe-compatible case or remove the case for optimal magnetic connection.

Both Charger and Stand

Support horizontal and vertical installation



Figure 7: Understanding magnetic auto-alignment for efficient charging.

3 in 1 Wireless Charger



Figure 8: The improved design for stable charging with various phone models.

SPECIFICATIONS

Feature	Detail
Model Number	CW340
Product Dimensions	4.4 x 2.5 x 3.6 inches (unfolded)
Item Weight	8.6 ounces
Connectivity Technology	Wireless
Connector Type	USB Type C
Input Voltage	9 Volts
Special Features	Travel, Magnetic, Fast Charging, Foldable
Color	Black
Included Components	Wireless charger, 18W QC adapter, charging cable, user manual
Safety Certifications	FCC certified (includes temperature control, overvoltage protection, short circuit protection, overcurrent protection)



Figure 9: Internal coil design and integrated safety features.



Figure 10: Comprehensive compatibility list for various Apple devices.

WARRANTY AND SUPPORT

Your Iseyyox 3-in-1 Foldable Magnetic Wireless Charging Station comes with a user manual and all necessary accessories. For any issues encountered during use, or for warranty information, please do not hesitate to contact our customer support team. We are committed to ensuring your satisfaction.

Contact Information: Please refer to the contact details provided on the product packaging or the official Iseyyox website for support.

