

[Manuals.plus](#) /

› [ROYMELO](#) /

› ROYMELO Double 18"x84" Barn Door with Hardware Kit Instruction Manual

ROYMELO SH-WD-03H-18K-X2

ROYMELO Double 18"x84" Barn Door with Hardware Kit Instruction Manual

Model: SH-WD-03H-18K-X2

INTRODUCTION

Thank you for choosing the ROYMELO Double 18"x84" Barn Door with Hardware Kit. This manual provides essential information for the safe and efficient assembly, installation, operation, and maintenance of your new barn door. Please read these instructions carefully before beginning installation and retain them for future reference.



Image: The ROYMELO Double Barn Door installed, showcasing its aesthetic appeal and functionality in a living space.

Product Features

- **Solid Spruce Wood:** Crafted from high-quality spruce wood, ensuring durability and resistance to cracking. The natural wood grain is clear and beautiful, providing a fresh aesthetic.
- **Pre-Colored Finish:** The barn door comes pre-colored, saving time and effort on staining.
- **DIY Assembly:** Designed for straightforward assembly with pre-cut and pre-drilled planks, making the process similar to building blocks.
- **Versatile Application:** Ideal for various interior spaces such as bedrooms, bathrooms, storage rooms, pantries, and walk-in closets.



Image: Detail of the solid spruce wood planks, highlighting the pre-cut tongue and groove design for easy assembly and durability.

SETUP AND ASSEMBLY

Before you begin, ensure you have all necessary tools and that the installation area is clear and prepared. This kit requires DIY assembly.

Package Contents



How to Choose the Size?

Track Length	Door Size (W+H)	Door Thickness	Fit Opening Width	Fit Opening Height
79"(6.6ft)	double 18"x84"	1-3/8"	≤34"	≤82"

Image: Visual representation of the packing list, including two barn doors, a 6.6FT hardware kit, and two handles.

- 2 x Barn Door Slabs (each 18" W x 84" H x 1-3/8" T)
- 1 x 6.6 FT Hardware Kit (includes 2m rail, 4 hangers, 5 spacers, 2 door stoppers, 2 floor guides, 2 handles)
- Necessary Screws
- Detailed Assembly Instructions

Assembly Steps

The wood planks are pre-cut and pre-drilled for easy assembly. Follow the detailed instructions provided in the package to assemble each door slab. The process is designed to be straightforward, similar to building blocks.



Spruce Wood

wood grain is clear & beautiful



High Quality Solid Wood



Upgraded Workmanship

Image: A diagram illustrating the quick assembly process, from individual planks to a fully assembled door and installed hardware.

Installation Considerations

- Ensure your wall can support the weight of the door and hardware.
- If your doorway trim is deeper than 2 inches, a headboard (not included) may be required for proper installation.
- It is recommended to have an additional person assist during installation due to the size and weight of the doors.

OPERATION

Once properly installed, your ROYMELO barn door will slide smoothly along the track. To open or close the door, gently push or pull the handle in the desired direction. The door stoppers on the rail prevent the door from sliding off the track, and the floor guides keep the door stable during movement.

Ensure there are no obstructions in the door's path before operating. Avoid forcing the door if it encounters resistance.

MAINTENANCE

Regular maintenance will ensure the longevity and smooth operation of your barn door.

- **Cleaning:** Wipe the door surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the wood finish.
- **Hardware Check:** Periodically inspect all screws and fasteners on the track, hangers, and handles. Tighten any loose components to prevent sagging or misalignment.
- **Track Lubrication:** If the door does not slide smoothly, apply a silicone-based lubricant to the top of the rail where the hangers roll. Do not use oil-based lubricants as they can attract dust and debris.
- **Wood Care:** While the door is pre-colored, avoid prolonged exposure to direct sunlight or extreme humidity, which can affect the wood over time.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Door does not slide smoothly:**
 - Check the track for any obstructions or debris.
 - Ensure all hangers are properly aligned on the track.
 - Apply a silicone-based lubricant to the top of the rail.
- **Door is wobbly or loose:**
 - Verify that all mounting screws for the track and hangers are securely tightened.
 - Ensure the floor guides are properly installed and adjusted.
- **Door does not close completely:**
 - Adjust the position of the door stoppers on the rail.
 - Check for any obstructions preventing full closure.

If you encounter issues not listed here or require further assistance, please contact customer support.

SPECIFICATIONS

Quick Assembly

in **30** mins




Image: A visual guide to door dimensions and recommended opening sizes for proper fit.

Feature	Detail
Brand	ROYMELO
Model Number	SH-WD-03H-18K-X2
Product Dimensions (L x W x H)	3.48 x 45.72 x 213.36 cm (each door)
Weight	32.66 kg
Material	Spruce Wood
Color	Coffee
Style	Country Style
Assembly Required	Yes
Track Length	6.6 FT (2 meters)

Feature	Detail
---------	--------

Door Size (W+H)	Double 18"x84"
Door Thickness	1-3/8"
Fit Opening Width	≤34"
Fit Opening Height	≤82"

WARRANTY

Specific warranty details are not provided in the product information. Please refer to your purchase documentation or contact ROYMELO customer support for warranty information.

CUSTOMER SUPPORT

For any missing or damaged parts, or if you have questions regarding installation, specifications, or general product inquiries, please contact ROYMELO customer support. We are available online to assist you.
Please have your model number (SH-WD-03H-18K-X2) and purchase details ready when contacting support.

© 2023 ROYMELO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BHLXSXW2>

More documents and user manuals: **<https://manuals.plus/>**