

Oakcastle DAB500

Oakcastle DAB500 Remote Control User Manual

Model: DAB500

INTRODUCTION

This user manual provides comprehensive instructions for the operation and maintenance of your Oakcastle DAB500 Remote Control. Please read this manual thoroughly before using the remote control to ensure proper functionality and to maximize its lifespan. This remote is designed as a replacement for the Oakcastle DAB500 audio system.

PRODUCT OVERVIEW

The Oakcastle DAB500 remote control is an infrared device designed to provide full control over your Oakcastle DAB500 audio system. It features a logical button layout for intuitive operation.




Figure 1: Front view of the Oakcastle DAB500 Remote Control. The remote is black with clearly labeled grey buttons. It features power buttons for soundbar and surround, individual volume controls for front, side, center, and subwoofer, bass and treble adjustments, media playback controls (play/pause, skip), main volume, mute, and input selection buttons (BT, ARC, LINE, USB, OPTICAL, AUX). There are also dedicated sound mode buttons (MUSIC, NEWS, MOVIE) and a PAIRING button.

Button Functions:

SOUNDBAR POWER (Top Left Button): Press to turn the soundbar power ON or OFF.

SURROUND POWER (Top Right Button): Press to turn the surround sound system power ON or OFF.

F.VOL / S.VOL / CEN.VOL / SUB.VOL (Individual Volume Controls): Adjust the volume levels for Front, Side, Center, and Subwoofer channels independently. Each has an UP (▲) and DOWN (▼) button.

BASS+ / BASS- (Bass Adjustment): Increase or decrease the bass level of the audio output.

TREBLE+ / TREBLE- (Treble Adjustment): Increase or decrease the treble level of the audio output.

Main Volume Up/Down (Large Central Circle, Up/Down Arrows): Adjust the overall master volume of the audio system.

Mute (Large Central Circle, Mute Icon): Toggle audio output ON or OFF.

Previous / Next Track (Large Central Circle, Left/Right Arrows): Skip to the previous or next track during media playback.

Play/Pause (Large Central Circle, Center Button): Play or pause media playback.

BT (Input Selection): Select Bluetooth input mode.

ARC (Input Selection): Select Audio Return Channel input mode.

LINE (Input Selection): Select Line In input mode.

USB (Input Selection): Select USB input mode.

OPTICAL (Input Selection): Select Optical input mode.

LED (Function Button): Controls the LED indicator on the audio system (e.g., turn on/off, change brightness).

MUTE (Function Button): Another Mute button, typically for quick access.

AUX (Input Selection): Select Auxiliary input mode.

PAIRING (Function Button): Initiate Bluetooth pairing mode for new devices.

MUSIC / NEWS / MOVIE (Sound Modes): Select pre-set equalizer modes optimized for Music, News, or Movie content.

SETUP

Inserting Batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two AAA batteries (not included), ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery cover securely.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

OPERATING INSTRUCTIONS

To operate your Oakcastle DAB500 audio system using this remote control, ensure the remote is pointed directly at the infrared receiver on your audio system. The maximum effective range is approximately 10 meters.

Basic Operation:

- **Power On/Off:** Press the **SOUNDBAR POWER** or **SURROUND POWER** button to turn the respective components on or off.
- **Volume Control:** Use the main volume **Up/Down** buttons in the central circle to adjust the overall volume. For specific channel volume adjustments, use the **F.VOL**, **S.VOL**, **CEN.VOL**, and **SUB.VOL** buttons.
- **Mute Function:** Press the **Mute** button (speaker icon) in the central circle or the dedicated **MUTE** button to silence the audio. Press again to unmute.
- **Input Selection:** Press the desired input button (**BT**, **ARC**, **LINE**, **USB**, **OPTICAL**, **AUX**) to switch between audio sources.
- **Sound Modes:** Select a pre-defined sound profile by pressing **MUSIC**, **NEWS**, or **MOVIE**.

- **Bass/Treble Adjustment:** Use **BASS+/BASS-** and **TREBLE+/TREBLE-** to fine-tune audio characteristics.

Bluetooth Pairing:

1. Ensure your audio system is powered on and set to Bluetooth mode by pressing the **BT** button.
2. Press and hold the **PAIRING** button on the remote control for a few seconds until the system enters pairing mode (indicated by a flashing LED or audible prompt).
3. On your Bluetooth device (e.g., smartphone, tablet), search for available Bluetooth devices and select "Oakcastle DAB500" from the list.
4. Once connected, the system will indicate successful pairing.

MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.
- **Battery Replacement:** Replace batteries when the remote's range decreases or it becomes unresponsive. Always replace with new batteries of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote control to direct sunlight, heat sources, or excessive moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control is not working.	<ul style="list-style-type: none">• Batteries are dead or inserted incorrectly.• Obstruction between remote and audio system.• Remote control is too far from the audio system.• Infrared sensor on audio system is blocked.	<ul style="list-style-type: none">• Replace batteries with new ones, ensuring correct polarity.• Remove any objects blocking the line of sight.• Move closer to the audio system (within 10 meters).• Ensure the audio system's IR sensor is clean and unobstructed.
Specific buttons are not responding.	<ul style="list-style-type: none">• Button may be stuck or damaged.• System is not in the correct mode for the button's function.	<ul style="list-style-type: none">• Gently press the button multiple times. If still unresponsive, the remote may need replacement.• Ensure the audio system is in the appropriate input mode (e.g., Bluetooth for pairing button).

SPECIFICATIONS

- Brand:** Oakcastle
- Model Number:** DAB500
- Color:** Black
- Connectivity Technology:** Infrared
- Maximum Supported Devices:** 1
- Number of Buttons:** 15 (excluding directional pad and central button, but including all labeled buttons)

Maximum Range: 10 Meters

Power Source: 2 x AAA Batteries (not included)





WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your original Oakcastle DAB500 audio system or visit the official Oakcastle website. This remote control is designed as a direct replacement and typically falls under the same warranty terms as the original product it replaces.

If you encounter issues not covered in this manual, please contact Oakcastle customer support for assistance.

© 2023 Oakcastle. All rights reserved.

Related Documents

	<p>Oakcastle DWD 175 Portable DVD Player User Manual</p> <p>Comprehensive user manual for the Oakcastle DWD 175 portable DVD player, covering setup, controls, troubleshooting, specifications, and safety information.</p>
	<p>Oakcastle DVD100 User Manual - Setup, Operation & Troubleshooting Guide</p> <p>Comprehensive user manual for the Oakcastle DVD100 DVD player. Learn how to set up, operate, and troubleshoot your device. Includes details on DVD and USB playback, system settings, and product support.</p>
	<p>Oakcastle MP200 MP3 Player User Manual</p> <p>Comprehensive user manual for the Oakcastle MP200 MP3 Player, covering setup, controls, music playback, radio, recording, Bluetooth connectivity, settings, specifications, and safety information.</p>
	<p>Oakcastle MP-200 User Manual</p> <p>Comprehensive user manual for the Oakcastle MP-200 MP3 player, covering setup, features like music playback, radio, recording, Bluetooth connectivity, settings, specifications, and safety information.</p>



[\[pdf\]](#) User Manual Instructions

Max Cubitt View Product Instructions DAB500 DAB FM Bluetooth CD Player Oakcastle Manual Collection
2025 oakcastle co uk 01 |||

DAB500 USER MANUAL EN Contents What s In the Box
..... 3 Controls And
Functions..... 4
Instructi...

lang:tl **score:60** filesize: 1.51 M page_count: 116 document date: 2025-01-16



[\[pdf\]](#) User Manual Instructions

PowerPoint Presentation Max Cubitt DAB500 Majority 2024 01 17 — *Please note that the instructions
within this manual will refer to remote button number e g Rem*number* or radio buttons Ref* number* in
Manual EN corrected FINAL Jan majority co uk |||

DAB500 USER MANUAL EN Contents What s In the Box
..... 3 Controls And
Functions..... 4 Inst...

lang:tl **score:49** filesize: 454.37 K page_count: 24 document date: 2024-01-17



[\[pdf\]](#) User Manual Instructions

PowerPoint Presentation Max Cubitt DAB500 Manual EN SEPT 2024 1 oakcastle co uk 09 |||

DAB500 USER MANUAL EN Contents What s In the Box
..... 3 Controls And
Functions..... 4
Instructi...

lang:tl **score:49** filesize: 314.71 K page_count: 26 document date: 2024-09-09



[\[pdf\]](#) User Manual Instructions

PowerPoint Presentation Max Cubitt v1oakcastle co uk 2024 09 DAB500 Manual EN SEPT 1 |||

DAB500 USER MANUAL EN Contents What s In the Box

..... 3 Controls And
Functions..... 4
Instructi...

lang:tl **score:42** filesize: 314.71 K page_count: 26 document date: 2024-09-09



[\[pdf\]](#) User Manual Instructions

PowerPoint Presentation Max Cubitt DAB500 Manual EN corrected FINAL Jan 2024oakcastle co uk 2024 01 |||

DAB500 USER MANUAL EN Contents What s In the Box

..... 3 Controls And
Functions..... 4 Inst...

lang:tl **score:41** filesize: 454.37 K page_count: 24 document date: 2024-01-17



[\[pdf\]](#) User Manual Instructions

Max Cubitt Manuale utente60W Impianot Stereo Casa Lettore CD HIFI con doppio allarme e 20
preselezioni Hi Fi Altoparlanti Integrati Display a LED USB MP3 AUX Telecomando Oakcastle DAB500
Amazon it ElettronicaA1C0qkVq rLm media amazon images I A1C0qkVq rL ref dp product quick view |||

DAB500 USER MANUAL EN Contents What s In the Box

..... 3 Controls And
Functions..... 4
Instructi...

lang:tl **score:39** filesize: 1.83 M page_count: 116 document date: 2025-01-14



[\[pdf\]](#) Borchure Catalog

Untitled OAKCASTLE 2024 9 set — Oakcastle products are designed with user convenience in mind offering a seamless experience across their range of electronics Brochure August majority co uk 09 ||| OAKCASTLE Product Catalogue. 2024 Contents. An intro to Oakcastle The Oakcastle Promise Speakers D ... ogy via Bluetooth. DAB FM Radio Bluetooth CD Player USB AUX Multi Language Dual Alarm **DAB500**. RRP 109.95 / 129.95 The **DAB500** is an all in one solution with complete music connectivity. P... lang:en score:31 filesize: 5.16 M page_count: 27 document date: 2024-09-06



[\[pdf\]](#) User Manual Instructions Diagram

491 DC94803 DC948B 148X210mm 80g 24P ZLD23015 10 2023 04 21 148X210mm 80g 24P
21 DAB500 UM FINAL PRINT COPY APRIL majority co uk |||
CONTENTS 6 9 DAB Radio 10 FM Radio 13 AUX IN 15 20 21 22 2 3 4 CONTROLS
FUNCTIO ... onnect your device to the radio via Bluetooth. The internet radio device
will display as Oakcastle **DAB500** . Select this radio to connect and your radio should
make a short sound, meaning that it is c...
lang:en score:21 filesize: 2.69 M page_count: 24 document date: 2023-10-06