

## Logitech G G240

# Logitech G240 Cloth Gaming Mouse Pad

Model: G240 | Brand: Logitech G

## INTRODUCTION

The Logitech G240 Cloth Gaming Mouse Pad is engineered to provide a performance-tuned surface for precise and consistent tracking. Its design focuses on optimizing sensor accuracy and precision for Logitech G mice, ensuring peak gaming performance. The mouse pad features a moderate surface friction, a non-slip rubber base, and a thin profile for enhanced comfort and stability during use.

## KEY FEATURES

- **Moderate Surface Friction:** Provides the optimal amount of resistance for mouse feet, aiding in precise control during rapid or sudden movements common in low DPI gaming.
- **Consistent Surface Texture:** Offers optimal imagery for mouse sensors, translating movement into accurate cursor control during high-speed gaming.
- **Optimized for Performance:** Designed to match the optimal testing environment for Logitech G mice, ensuring full sensor accuracy and precision.
- **Non-Slip Rubber Base:** Prevents the mouse pad from bunching or slipping, maintaining stability during intense gaming sessions.
- **Strong, Flexible, and Portable:** Constructed with durable materials, the mouse mat can be rolled up for easy transport without damage.

## SETUP

Setting up your Logitech G240 Cloth Gaming Mouse Pad is straightforward:

1. Unroll the mouse pad onto a clean, flat surface.
2. Ensure the rubberized base is in full contact with the desk surface to prevent slipping.
3. Place your gaming mouse on the cloth surface.




Image: The Logitech G240 Cloth Gaming Mouse Pad laid flat on a desk with a gaming mouse, ready for use.

## OPERATING INSTRUCTIONS

---

The Logitech G240 mouse pad is designed for immediate use with any optical or laser gaming mouse. Its optimized surface ensures accurate sensor tracking for precise cursor movements. Simply place your mouse on the pad and begin your tasks or gaming session.

# CONSISTENT TEXTURE



KEEP PLAYING — ●●●

FOR SUPERIOR SENSOR  
PERFORMANCE

Image: A close-up view of the fine texture on the Logitech G240 cloth surface, designed for optimal sensor performance.

## MAINTENANCE

To maintain the performance and longevity of your Logitech G240 Cloth Gaming Mouse Pad:

- **Cleaning:** Wipe the surface with a damp cloth to remove dust and debris. Avoid harsh chemicals or abrasive cleaners, as these can damage the cloth surface.
- **Storage:** When not in use or for transport, roll the mouse pad loosely to prevent creases. Store it in a cool, dry place.
- **Avoid Extreme Conditions:** Do not expose the mouse pad to direct sunlight for extended periods or extreme temperatures, which could affect the material.

## TROUBLESHOOTING

If you encounter any issues with your mouse pad, consider the following:

- **Mouse Tracking Issues:** Ensure the mouse pad surface is clean and free of obstructions. Check your mouse's sensor for any debris.

- **Slipping:** Verify that the rubber base is fully flat and in contact with a clean, dry desk surface.
- **Uneven Surface:** If the mouse pad appears uneven after unrolling, allow it some time to flatten out naturally. Gently rolling it in the opposite direction can also help.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	13.39 x 11.02 x 1 inches (340 x 280 x 1 mm)
Item Weight	3.17 ounces
Material	Cloth
Color	Black
Special Feature	Non-slip
Recommended Uses	Gaming, Office
Model Number	943-000783

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Logitech G website or contact their customer service directly. Keep your purchase receipt for warranty claims.

You can visit the [Logitech G Store](#) for more product information and support resources.