

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOUCHBeauty](#) /

› [TOUCHBeauty UV LED Nail Lamp TB-0889B Instruction Manual](#)

TOUCHBeauty TB-0889B

TOUCHBeauty UV LED Nail Lamp

MODEL: TB-0889B INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the TOUCHBeauty UV LED Nail Lamp TB-0889B. This compact and portable nail dryer is designed for efficient drying of both regular and gel nail polishes on hands and feet. It combines UV-LED light and air-drying functions to protect your skin and eyes from potential harm associated with older nail drying technologies. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. Key Features

- **2-in-1 Drying Function:** Utilizes both UV-LED light and air for quick and effective drying of regular and gel nail polishes.
- **Skin and Eye Safe:** Equipped with 5 UV-LEDs and low wattage light designed to protect sensitive skin and eyes.
- **Easy Operation:** Features a simple push switch and a specially designed finger plate for user-friendly activation.
- **Portable & Mini Design:** Compact size (4.68 x 4.33 x 2.75 inches) and battery-powered (3 AAA batteries, not included) for convenient use anywhere.
- **Versatile Use:** Suitable for both children and adults.

3. Package Contents

Upon opening the package, please verify that all items are present and in good condition:

- 1 x TOUCHBeauty UV LED Nail Lamp (Model TB-0889B)
- 1 x Instruction Manual



Image: The TOUCHBeauty UV LED Nail Lamp TB-0889B shown with its retail packaging.

4. Setup

The TOUCHBeauty UV LED Nail Lamp is battery-powered for portability. Follow these steps to install the batteries:

1. Locate the battery compartment on the underside of the device.
2. Slide open the battery compartment cover.
3. Insert 3 AAA batteries (not included) into the compartment, ensuring correct polarity (+/-) as indicated.
4. Close the battery compartment cover securely.



Image: Underside view of the nail lamp, illustrating the battery compartment for 3 AAA batteries.

5. Operating Instructions

Using your TOUCHBeauty UV LED Nail Lamp is straightforward:

1. After applying your nail polish (regular or gel), ensure your nails are ready for drying.
2. Place your hand or foot into the drying chamber of the device. The device is designed to accommodate up to four fingers comfortably; the thumb may need to be dried separately.
3. Gently press down on the finger plate located inside the drying chamber. This action activates both the UV-LED lights and the air fan.
4. Keep your hand or foot in place until the nail polish is dry. Drying times may vary depending on the type and thickness of the polish.
5. Release pressure on the finger plate to turn off the device.



Air drying



LED lighting



Image: A hand positioned inside the nail lamp, demonstrating the drying process with activated UV-LED lights.

6. Maintenance

To ensure the longevity and optimal performance of your nail lamp, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior of the device with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and moisture. If not in use for an extended period, remove the batteries to prevent leakage.
- **Battery Replacement:** Replace all 3 AAA batteries when the device's performance diminishes (e.g., weaker fan, dimmer lights).

7. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity and replace with fresh AAA batteries.
Nail polish is not drying effectively.	Too many coats of polish; insufficient drying time; old batteries.	Apply thinner coats; extend drying time; replace batteries. Ensure the finger plate is fully pressed.
Fan is weak or lights are dim.	Low battery power.	Replace all 3 AAA batteries.

8. Specifications

Attribute	Detail
Model	TB-0889B
Brand	TOUCHBeauty
Power Source	3 x AAA Batteries (not included)
Material	Plastic
Color	White
Item Weight	0.18 Kilograms (approx. 6.38 ounces)
Dimensions (LWH)	4.68 x 4.33 x 2.75 inches (approx. 11.8 x 11.0 x 7.0 cm)

MINI Size

Light weight, easy to carry



Image: Visual representation of the compact dimensions of the nail lamp.

9. Safety Information

- Do not expose the device to water or excessive moisture.
- Keep out of reach of children unless under adult supervision.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if issues arise.
- Use only the specified type and number of batteries.
- Remove batteries if the device will not be used for a long period.
- Dispose of used batteries responsibly according to local regulations.
- This device is intended for drying nail polish only. Do not use for other purposes.

10. Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official TOUCHBeauty website. Keep your purchase receipt as proof of purchase.

11. Product Videos

No official product videos from the seller were found for this model. Please refer to the instructions above for guidance.

© 2024 TOUCHBeauty. All rights reserved.