TELESIN TELESIN Magnetic Mount Backpack Clip

TELESIN Magnetic Mount & Backpack Clip with Phone Holder Instruction Manual

Introduction Package Contents Features Compatibility Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

The TELESIN Magnetic Mount & Backpack Clip with Phone Holder is a versatile accessory designed for action cameras and smartphones. It offers multiple mounting options, including magnetic attachment to metal surfaces and a secure clip for backpack straps. Featuring a 360° rotating ball head, this mount allows for flexible angle adjustments to capture your desired shots with ease. Its robust construction ensures stability and durability for various outdoor activities.



Figure 1: TELESIN Magnetic Mount and Backpack Clip with Phone Holder.

2. Package Contents

Please verify that all items listed below are included in your package:

- 1x 360° Rotation Magnetic Backpack Clip Ball Head
- 1x Locking Screw
- 1x AE Adapter (for phone installation)
- 1x Phone Holder

3. Key Features

3.1. Magnetic Mount, Backpack Clip, and Phone Holder

This accessory combines a magnetic clip for metal surfaces, a backpack strap clip mount, and a phone holder, offering multiple versatile mounting options for action cameras and mobile devices.



Figure 2: Overview of the magnetic and clip functionalities.

3.2. 360° Rotation & Easy Operation

Equipped with a 360° rotation ball head, this mount allows for easy horizontal/vertical shooting and tilting adjustments. The knob connection system enables quick locking and releasing with a single step.



Figure 3: Illustrates the 360° universal adjustment capability.

3.3. Strong Grip and Stable Design

Constructed from high-quality ABS material, the clip features multiple rows of serrations and thick springs for a strong grip. This design ensures a secure fit on various bag backpack straps, ideal for activities like hiking, surfing, skiing, and biking.



Figure 4: The clip's design with skin-friendly material for comfortable use.

4. Wide Compatibility

The TELESIN Magnetic Mount is compatible with a broad range of action cameras and smartphones, including but not limited to:

- DJI Osmo Nano, Osmo Action 5 Pro, Osmo Pocket 2/3
- GoPro Max, Hero 13 Black, Hero 12, 11 Mini, Hero 11, Hero 10, Hero 9, Hero 8, Hero 7, Hero 6, Hero 5, Hero 4/3+/3/2/1, Fusion Session
- Insta360 Ace Pro 2, ONE R, RS, X2, X3, X5, Go 2, Go 3, Ace Pro
- Smartphones (e.g., iPhone 16 Pro Max)
- Other action cameras such as Xiaoyi, Dragon Touch, APEMAN, Crosstour, Apexcam, VEMONT, AKAIRIO.

Note: Maximum camera weight supported is 250g. The basic package does not include a combo cage or mobile phone holder unless specified.



Figure 5: Examples of compatible cameras and smartphones.

5. Setup Instructions

Follow these steps to set up your TELESIN Magnetic Mount:

1. **Attach the Backpack Clip:** Open the clip and securely attach it to your backpack strap or any suitable fabric strap. Ensure the serrated grips are firmly holding the material.
2. **Magnetic Adsorption:** Alternatively, for metal surfaces, simply place the magnetic base onto a flat iron surface. The powerful magnets will hold it in place.
3. **Mount Your Camera/Phone:** Lock your action camera onto the ball mount using the provided locking screw. If using a smartphone, attach the AE adapter to the ball mount, then secure your phone in the phone holder.
4. **Adjust the Angle:** Use the 360° rotation ball head to adjust the camera or phone to your desired shooting angle. Once positioned, tighten the cam switch clockwise to secure the camera firmly.



Figure 6: Visual guide for setup and adjustment.

Setup Video Guide:

Your browser does not support the video tag.

Video 1: A detailed guide on setting up the TELESIN Magnetic Mount Swivel Ball Joint Backpack Clip.

6. Operating Instructions

The TELESIN mount is designed for intuitive use. Once securely attached, you can easily adjust your camera or phone for various perspectives.

- **Angle Adjustment:** Loosen the knob on the ball head counter-clockwise to adjust the angle. Once the desired angle is achieved, tighten the knob clockwise to lock it in place.
- **Quick Release:** The quick-release spanner allows for rapid attachment and detachment of your camera or phone from the ball head.

- **Magnetic Use:** For quick placement on metal surfaces, ensure the surface is clean and flat for maximum magnetic adhesion. Always verify the magnetic hold before leaving your device unattended.

Usage Examples Video:

Your browser does not support the video tag.

Video 2: Demonstrates various uses and angles of the backpack mount or strap mount.

7. Maintenance

To ensure the longevity and optimal performance of your TELESIN Magnetic Mount, follow these maintenance guidelines:

- **Cleaning:** Wipe the mount with a soft, damp cloth to remove dust and dirt. Avoid using harsh chemicals or abrasive materials that could damage the surface or magnetic components.
- **Storage:** Store the mount in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically check all moving parts, screws, and the clip mechanism for any signs of wear or damage. Ensure the magnetic surface is free from debris.

8. Troubleshooting

If you encounter any issues with your TELESIN Magnetic Mount, refer to the following common solutions:

- **Mount is not holding securely:**
    - *For backpack clip:* Ensure the strap material is not too thin or slippery. Adjust the clip to fully engage the serrated teeth.
    - *For magnetic mount:* Verify the metal surface is clean, flat, and ferromagnetic. Some alloys or painted surfaces may reduce magnetic strength. Avoid placing heavy devices if the magnetic hold feels weak.
- **Camera/Phone angle shifts:** Ensure the locking knob on the ball head is tightened sufficiently after adjustment.
- **Difficulty attaching/detaching camera/phone:** Check that the locking screw is properly aligned and not cross-threaded. Ensure the quick-release mechanism is fully engaged or disengaged as intended.

If the problem persists, please contact customer support for further assistance.

9. Specifications

Feature	Detail
Model Number	TELESIN Magnetic Mount Backpack Clip
Item Weight	2.47 ounces
Package Dimensions	8.27 x 3.94 x 3.78 inches
Special Features	360° Rotation, Magnetic

Feature	Detail
Mounting Type	Clip On
Compatible Devices	Smartphones, Action Cameras (GoPro, DJI, Insta360, etc.)
Manufacturer	TELESIN

10. Warranty and Support

TELESIN offers a 90-day free money-back and return warranty for this product. Should you encounter any quality problems or require assistance, please do not hesitate to contact our online customer service for help.

For further support, please visit the official TELESIN website or refer to the contact information provided with your purchase.