

OISE ART STORE Q-A106

OISE ART STORE MXQ Pro 4K Ultra HD TV Box Q-A106 User Manual

Model: Q-A106

1. INTRODUCTION AND SAFETY INFORMATION

This manual provides essential instructions for the safe and efficient operation of your OISE ART STORE MXQ Pro 4K Ultra HD TV Box Q-A106. Please read this manual thoroughly before using the device and retain it for future reference.

Safety Precautions:

- Do not expose the device to water, moisture, or extreme temperatures.
- Avoid placing the device near heat sources or in direct sunlight.
- Use only the provided power adapter. Using unauthorized adapters may damage the device and void the warranty.
- Do not attempt to open or repair the device yourself. Refer all servicing to qualified personnel.
- Ensure proper ventilation around the device to prevent overheating.
- Keep the device and accessories out of reach of children.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- OISE ART STORE MXQ Pro 4K Ultra HD TV Box Q-A106
- Remote Control
- Power Adapter
- HDMI Cable
- User Manual (this document)



Figure 2.1: Included accessories for the MXQ Pro TV Box, featuring the power adapter, remote control, and HDMI cable.

3. PRODUCT OVERVIEW

The OISE ART STORE MXQ Pro 4K Ultra HD TV Box Q-A106 is a high-performance streaming client designed to transform your television into a smart entertainment hub. Running on Android 10.0, it offers access to a wide range of applications and supports 4K Ultra HD video playback. It features 2GB RAM and 16GB internal storage for smooth operation and media storage.



Figure 3.1: The MXQ Pro 4K TV Box and its remote control, illustrating its connection to a television for media streaming.



Figure 3.2: Top view of the MXQ Pro 4K TV Box, highlighting its compact design.

4. SETUP INSTRUCTIONS

4.1 Connecting to Your Television

1. Locate an available HDMI port on your television.
2. Connect one end of the provided HDMI cable to the HDMI OUT port on the MXQ Pro TV Box.
3. Connect the other end of the HDMI cable to the HDMI IN port on your television.
4. Switch your television's input source to the corresponding HDMI port.

4.2 Power Connection

1. Connect the power adapter to the DC 5V port on the MXQ Pro TV Box.
2. Plug the power adapter into a wall outlet. The device should automatically power on or enter standby mode.

4.3 Network Connection

The MXQ Pro TV Box supports both Wi-Fi and Ethernet connections.

Wi-Fi Connection:

1. Once the device is powered on, navigate to **Settings > Network > Wi-Fi**.
2. Select your desired Wi-Fi network from the list.
3. Enter the Wi-Fi password if prompted and select **Connect**.

Ethernet Connection:

1. Connect an Ethernet cable from your router or modem to the LAN port on the MXQ Pro TV Box.
2. The device will automatically detect and connect to the wired network.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Functions

The included remote control allows you to navigate the Android interface and control media playback.

- **Power Button:** Turns the device on/off or puts it into standby.
- **Navigation Buttons (Arrow Keys):** Move cursor or selection.
- **OK Button:** Confirm selection.
- **Back Button:** Return to the previous screen.
- **Home Button:** Return to the main home screen.
- **Menu Button:** Access context-sensitive menus.
- **Volume Buttons:** Adjust audio volume.



Figure 5.1: The MXQ Pro 4K TV Box and its remote control.

5.2 Navigating the Android Interface

The MXQ Pro TV Box runs on Android 10.0, providing a familiar and intuitive user experience. Use the remote control's navigation buttons to browse through apps, settings, and media content.

5.3 Installing Applications

You can download and install various applications from the Google Play Store:

1. Ensure the device is connected to the internet.
2. From the home screen, open the **Google Play Store** app.
3. Sign in with your Google account or create a new one.
4. Search for desired applications and follow the on-screen instructions to install them.

5.4 Media Playback

The device supports 4K Ultra HD and 3D video playback. You can play media from:

- Streaming services (via installed apps).
- USB storage devices (connected to USB ports).
- Network shares (via file manager apps).

6. MAINTENANCE

6.1 Cleaning the Device

- Ensure the device is powered off and unplugged before cleaning.
- Use a soft, dry, lint-free cloth to wipe the exterior of the device.
- Do not use liquid cleaners, aerosols, or solvents.

6.2 Software Updates

Periodically check for software updates to ensure optimal performance and security:

1. Navigate to **Settings > About Device > System Update**.
2. Follow the on-screen prompts to check for and install any available updates.

7. TROUBLESHOOTING

If you encounter issues with your MXQ Pro TV Box, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No Power	Ensure the power adapter is securely connected to the device and a working power outlet. Try a different outlet.
No Signal on TV	Verify the HDMI cable is correctly connected to both the TV Box and the television. Ensure the TV input source is set to the correct HDMI port.
Wi-Fi Connection Issues	Check if your router is working correctly. Re-enter the Wi-Fi password. Try restarting both the TV Box and your router. Ensure the device is within range of your Wi-Fi signal.
Remote Control Not Responding	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV Box.
Applications Crashing or Freezing	Close and restart the application. Clear the app's cache (Settings > Apps > [App Name] > Clear Cache). If the problem persists, try uninstalling and reinstalling the app.

8. SPECIFICATIONS

Feature	Detail
Brand	OISE ART STORE
Model	Q-A106
Operating System	Android 10.0
CPU	H6 Quad-Core Cortex-A53
GPU	Mali-T720MP2
RAM	2 GB
Internal Storage	16 GB eMMC
Resolution	4K Ultra HD





Feature	Detail
Wi-Fi	Dual-band 2.4G/5.8GHZ
HDMI Ports	1
USB Ports	4 (USB 2.0)
Ethernet LAN Ports	1
Special Features	HDMI Output, Quad Core, USB Port, 3D Video Playback
Power Supply	DC 5V/2A


9. WARRANTY AND SUPPORT

This OISE ART STORE product is covered by a standard manufacturer's warranty. Please refer to the warranty card included with your purchase or contact your retailer for specific warranty terms and conditions.

For technical support or further assistance, please contact the seller or manufacturer directly. Provide your model number (Q-A106) and a detailed description of the issue when seeking support.

Related Documents - Q-A106

 <p>Android TV Box User Manual</p> <p>Stream, Watch, Enjoy - Effortlessly</p>	<p>LEFFOT H313 Android TV Box User Manual</p> <p>Comprehensive user manual for the LEFFOT H313 Android TV Box, covering product introduction, features, hardware structure, remote control operation, setup, app management, troubleshooting, safety instructions, and specifications. Learn how to connect, configure, and use your Android TV Box for an enhanced entertainment experience.</p>
 <p>MANUAL DO USUÁRIO</p> <p>Sistema Android com Conectividade 4G na Multimídia Original</p> <p>STREAMING BOX</p> <p>FAAFTECH</p>	<p>Faaftech Streaming Box User Manual: Android 9, 4G Connectivity, Wireless CarPlay & Android Auto</p> <p>This user manual provides comprehensive instructions for the Faaftech Streaming Box, covering installation, features, operation, wireless CarPlay and Android Auto connectivity, mobile network setup, Wi-Fi hotspot functionality, technical specifications, and warranty details.</p>
 <p>MyGica® Streaming</p> <p>ATV 582 Ultra HD TV Box powered by Android</p> <p>Quick Start Guide</p>	<p>MyGica ATV 582 Ultra HD TV Box Quick Start Guide</p> <p>This Quick Start Guide provides instructions for setting up and using the MyGica ATV 582 Ultra HD TV Box, including device connections, remote control operation, initial setup, network configuration, and accessing apps.</p>
 <p>TAUBER TV</p> <p>Bedienungsanleitung Android TV Box, IPTV Plattform</p>	<p>Bedienungsanleitung: Tauber TV Android TV Box und IPTV Plattform</p> <p>Umfassende Anleitung zur Einrichtung und Nutzung der Tauber TV Android TV Box und IPTV Plattform. Erfahren Sie, wie Sie Sender wechseln, Aufnahmen verwalten, Apps installieren und häufige Probleme lösen.</p>

 <p>The image shows the cover of the GARDENA Valve Box V1/V3 Operating Instructions. It features the GARDENA logo at the top left, a technical diagram of the valve box in the center, and a detailed table of contents on the right side. The table of contents lists 27 sections in German, including installation, operation, and troubleshooting.</p>	<p>GARDENA Valve Box V1/V3 Operating Instructions</p> <p>Official operating instructions for the GARDENA Valve Box models V1 (Art. 1254) and V3 (Art. 1255), covering installation, assembly, operation, safety precautions, troubleshooting, and warranty information.</p>
<p>Android TV User Manual</p>	<p>Android TV Box User Manual</p> <p>User manual for an Android TV Box, covering setup, basic operations, storage, network connectivity (Wi-Fi, Ethernet), hotspot functionality, firmware reflashing, and FCC compliance information.</p>