

eufy Clean T2770111

eufy Clean Mach V1 Ultra WetVac Cordless All-in-One Wet Dry Vacuum Cleaner (Model T2770111)

Your comprehensive guide to operating and maintaining your eufy Clean Mach V1 Ultra WetVac.

1. INTRODUCTION

The eufy Clean Mach V1 Ultra WetVac is an advanced all-in-one cordless stick vacuum designed for efficient cleaning of hard floors and carpets. It combines vacuuming, mopping, and steaming functionalities to tackle wet or dry messes and stubborn stains, ensuring a thorough clean for your home.

Key features include:

- **Vacuum, Mop, and Steam All-in-One:** Combines multiple cleaning actions for comprehensive floor care.
- **Effective on Wet or Dry Messes and Stubborn Stains:** Designed to effortlessly clean various types of spills and grime.
- **TÜV Rheinland Certified:** Achieves 99.9% bacteria removal with high-temperature steam and aqueous ozone, certified for hygiene.
- **Eco-Clean Ozone:** Produces aqueous ozone to kill common bacteria and remove odors naturally, safe for pets and children.
- **Always Clean Mop:** Constantly washes the roller brush during operation to prevent recontamination of floors.

2. WHAT'S IN THE BOX

Carefully unpack all components and ensure everything listed below is present. If any items are missing or damaged, please contact customer support.

- Main Vacuum Unit
- Handle
- Multi-Surface Floor Cleaner Solution (500 mL)
- Charging Dock
- Cleaning Brush/Bristle
- Instruction Manual
- Extra Brush Roll

- Self-Cleaning Apparatus Components

Vacuum, Mop, and Steam

At the Same Time




Image: Main eufy Clean Mach V1 Ultra WetVac unit.

Cordless SteamWave™ Technology

Stains Vanish Instantly



Image: Included accessories for the eufy Clean Mach V1 Ultra WetVac.

3. SETUP

Follow these steps for initial assembly and preparation of your Mach V1 Ultra WetVac.

1. **Attach the Handle:** Insert the handle into the designated slot on the top of the main vacuum unit. Push firmly until you hear a click, indicating it is securely locked into place.
2. **Fill the Clean Water Tank:** Locate the clean water tank on the back of the unit. Press the release button and pull the tank out. Open the cap and add 0.3 mL (approximately one cup) of the provided multi-surface floor cleaner solution. Then, fill the tank with clean water up to the MAX line. Securely close the cap and reinsert the tank into the unit until it clicks.

Cordless SteamWave™ Technology

Stains Vanish Instantly



Image: Attaching the handle to the main unit.

Eco-Clean Ozone

Harsh on Germs.
Gentle on Everything Else.



Image: Filling the clean water tank with solution and water.

4. OPERATING INSTRUCTIONS

The Mach V1 Ultra WetVac offers multiple cleaning modes for various needs, adapting to different floor types and mess levels.

Powering On and Mode Selection

To power on the device, press the power button located on the handle. The integrated display will illuminate, showing the current battery percentage and the active cleaning mode. Use the mode selection button to cycle through the available cleaning modes:

- **Auto Mode:** This intelligent mode automatically adjusts the suction power and water flow based on the

detected dirt level on your floor, providing optimized cleaning.

- **Ultra Mode:** Ideal for deep cleaning and sanitization. This mode utilizes the cleaning solution and high-temperature steam to effectively disinfect and tackle tough, built-up grime.
- **Suction Mode:** Use this mode specifically for picking up liquid spills without dispensing any cleaning solution.

Cleaning Performance

The Mach V1 Ultra WetVac features a self-propelled design, making it easy to maneuver across your floors with minimal effort. Simply guide the unit, and it will assist in moving forward.




Image: The Eco-Clean Ozone feature in action, providing deep sanitization.

Download App for Upgrades & More Features



Image: The display showing various modes and battery life, with app integration for firmware updates and features.

5. MAINTENANCE

Regular maintenance is crucial for ensuring the optimal performance and longevity of your eufy Clean Mach V1 Ultra WetVac.

Emptying the Dirty Water Tank

After each cleaning session, the dirty water tank should be emptied and cleaned. Remove the tank from the unit, open the drain plug, and pour the dirty water into a sink. Rinse the tank thoroughly with clean water to prevent any residue buildup, mold, or unpleasant odors. Allow it to air dry before reattaching.

Cleaning the Brush Roll

The brush roll can be easily removed for manual cleaning. Press the brush roll release button on the side of the brush head, then slide the brush roll out. Rinse it under hot water to remove dirt and debris. Use the provided cleaning brush to dislodge any tangled hair or stubborn particles. Ensure the brush roll is completely dry before reinserting it.

Self-Cleaning Function

For convenient and thorough cleaning of the brush roll and internal pathways, utilize the self-cleaning function. Place the Mach V1 Ultra WetVac securely on its charging dock. Ensure the clean water tank has sufficient water and solution. Press the dedicated self-cleaning button on the handle. The device will automatically perform a hot water wash of the brush roll and then initiate a 30-minute hot air drying cycle (at 60°C) to prevent odors and keep the brush fresh.



Image: The 'Always Clean Mop' system ensures the brush roll is clean during operation.

Triple Self-Cleaning System

Clean and Dry After Clean Ups



Image: The Triple Self-Cleaning System for self-washing, self-sterilizing, and self-drying after use.

6. SPECIFICATIONS

- **Brand:** eufy Clean
- **Model Number:** T2770111
- **Colour:** Grey
- **Product Dimensions:** 2.54 x 124.97 x 35.31 cm
- **Item Weight:** 6.35 kg
- **Number of Speeds:** 1
- **Special Features:** Bagless, Cordless, Wet/Dry
- **Filter type:** HEPA Filter

- **Surface recommendation:** Hard Floors and Carpets
- **Power source:** Battery Powered
- **Included components:** Mop
- **Is it cordless?:** Yes
- **Recommended uses for product:** Hard floors, carpets
- **Form factor:** Robotic

7. TROUBLESHOOTING

If you encounter any issues with your Mach V1 Ultra WetVac, please refer to the following common solutions:

- **No Power:** Ensure the unit is fully charged. Check that the charging dock is properly connected to a power outlet and that the vacuum is correctly seated on the dock.
- **Poor Suction:** Verify that the dirty water tank is not full. A full tank can reduce suction power. Also, check if the brush roll is clogged with debris or hair and clean it as per the maintenance instructions.
- **Unpleasant Odor:** This often indicates residue buildup. Perform a self-cleaning cycle. Ensure both the dirty water tank and the brush roll are thoroughly cleaned and allowed to dry completely after each use.
- **Water Leakage:** Check that both the clean and dirty water tanks are correctly installed and securely sealed. Ensure all caps and plugs are tightly closed.

If the problem persists, please contact customer support.

8. WARRANTY AND SUPPORT

For detailed warranty information, technical assistance, or to purchase replacement parts and accessories, please visit the official eufy Clean website or contact their dedicated customer service team. Please retain your proof of purchase for any warranty claims.