

[Manuals.plus](#) /

› [ZACME](#) /

› ZACME Pasta Maker Attachment for KitchenAid Stand Mixers, Model ZA-NSK08 Instruction Manual

ZACME ZA-NSK08

ZACME Pasta Maker Attachment for KitchenAid Stand Mixers

Model: ZA-NSK08

INTRODUCTION

Thank you for choosing the ZACME Pasta Maker Attachment. This accessory is designed to work seamlessly with your KitchenAid stand mixer, allowing you to create fresh, homemade pasta with ease. It features six different pasta shapes to expand your culinary possibilities. Please read this manual thoroughly before use to ensure proper operation and maintenance.

IMPORTANT SAFETY INSTRUCTIONS

- Always unplug your KitchenAid stand mixer before attaching, detaching, or cleaning the pasta maker attachment.
- Keep hands and utensils away from moving parts during operation to prevent injury.
- Ensure all parts are securely assembled before operating the attachment.
- This attachment is designed for household use only. Do not use for commercial purposes.
- Do not immerse the main power center of the attachment in water. Keep the power center dry.
- Supervise children when the appliance is in use.

PACKAGE CONTENTS

Verify that all components are present in the package:

- Power Center
- Input Port
- Squeeze Putter
- Output Port
- Holder
- Cutter
- 6 Replacement Outlets (different shapes)
- Food Push
- Cleaning Brush

ALL ACCESSORIES




Image: All included accessories for the ZACME Pasta Maker Attachment.

SETUP AND INSTALLATION

Follow these steps to correctly assemble and attach the pasta maker to your KitchenAid stand mixer:

1. **Step 1:** Insert the Squeeze Putter into the Power Center.
2. **Step 2:** Connect the Input Port to the Power Center, ensuring it clicks into place.
3. **Step 3:** Place your desired pasta shape outlet into the Output Port, then attach the Holder and Cutter.
4. **Step 4:** Attach the assembled pasta maker to the power hub of your KitchenAid stand mixer. Secure it by tightening the stand mixer's attachment knob.

EASY TO INSTALL



STEP 1



STEP 2



STEP 3



STEP 4



Image: Easy installation steps for the pasta maker attachment.



Image: The ZACME pasta maker attachment connected to a KitchenAid stand mixer.

OPERATING INSTRUCTIONS: MAKING PASTA

This attachment allows you to create six different pasta shapes:

- Spaghetti
- Bucatini
- Three-sided Noodles
- Rigatoni
- Small Macaroni
- Large Macaroni



Image: Six different pasta shapes achievable with the ZACME attachment.

Pasta Making Process:

1. **Prepare Dough:** Ensure your pasta dough is firm and not too sticky. It should be kneaded well and allowed to rest.
2. **Cut Dough:** Cut the dough into small, walnut-sized pieces or strips that can easily fit into the input port. Lightly dust with flour if necessary.
3. **Start Mixer:** Turn on your KitchenAid stand mixer to a low speed (e.g., Speed 4 or 5).
4. **Feed Dough:** Place dough pieces into the input port. Use the Food Push to gently guide the dough towards the Squeeze Putter. Do not force the dough.
5. **Extrude Pasta:** As the pasta extrudes from the chosen die, use the Cutter to cut it to your desired length.
6. **Dry Pasta:** Place the freshly cut pasta on a drying rack or a lightly floured surface to prevent sticking.



Image: Overview of the pasta making process.



Image: Prepared pasta dough balls.

CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your pasta maker attachment.

- **Disassembly:** Unplug the stand mixer. Disassemble the pasta maker attachment by reversing the installation steps.
- **Initial Cleaning:** Allow any residual dough to dry on the parts for about 15-20 minutes. This makes it easier to remove.
- **Brush Cleaning:** Use the provided cleaning brush to remove dried dough from the pasta dies and other components.
- **Dishwasher Safe:** All removable parts of the attachment, except the Power Center, are dishwasher safe. Place them on the top rack.
- **Hand Washing:** For the Power Center, wipe it clean with a damp cloth. Do not immerse it in water. Ensure it remains dry.
- **Drying:** Ensure all parts are completely dry before reassembling or storing to prevent rust or mold.

EASY TO CLEAN



Image: Cleaning instructions, showing dishwasher compatibility and hand cleaning with a brush.



Image: Cleaning steps and dishwasher safety information.

TROUBLESHOOTING

If you encounter issues during operation, refer to these common solutions:

- **Pasta not extruding:** Ensure the dough is firm enough and cut into small pieces. The mixer speed might be too low; try

increasing it slightly. Check for any blockages in the input or output ports.

- **Pasta sticking together:** Lightly dust the freshly extruded pasta with flour to prevent sticking. Ensure the dough is not too wet.
- **Attachment not fitting:** Ensure the attachment is correctly aligned with the power hub of your KitchenAid stand mixer and the attachment knob is fully tightened.
- **Difficulty cleaning:** Allow dough residue to dry completely before attempting to brush or wash. Use the provided cleaning brush for optimal results.

SPECIFICATIONS

Model Number	ZA-NSK08
Brand	ZACME
Material	Stainless Steel
Product Dimensions (L x W x H)	17.8 x 25.4 x 5.1 cm (7 x 10 x 2 inches)
Item Weight	1.18 kg (2.6 lbs)
Number of Pasta Shapes	6
Dishwasher Safe Parts	Yes (excluding Power Center)
UPC	788499920077

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or contact ZACME customer service directly. Contact details can typically be found on the product packaging or the official ZACME website.

© 2026 ZACME. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BHRYTJD2>

More documents and user manuals: <https://manuals.plus/>