

[manuals.plus](#) /

› [BELLEZE](#) /

› [BELLEZE 58" Farmhouse Fireplace TV Stand Instruction Manual](#)

## **BELLEZE 014-HG-41007-HT-WHT**

# **BELLEZE 58" Farmhouse Fireplace TV Stand Instruction Manual**

Model: 014-HG-41007-HT-WHT

Brand: BELLEZE

## **1. INTRODUCTION**

Thank you for choosing the BELLEZE 58" Farmhouse Fireplace TV Stand. This entertainment center is designed to accommodate TVs up to 65 inches and features a 23-inch electric fireplace heater. It combines rustic farmhouse aesthetics with modern functionality, offering both warmth and ample storage for your living space.



*Image 1: Front view of the BELLEZE 58" Farmhouse Fireplace TV Stand, showcasing the electric fireplace and barn door cabinets.*

## **2. SAFETY INFORMATION**

- Read all instructions before using this appliance.
- Do not operate the fireplace with a damaged cord or plug, or if the heater malfunctions.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater.
- Always unplug the fireplace when not in use.
- Ensure the TV stand is placed on a stable, level surface.
- Do not overload the shelves or the top surface of the TV stand.

## **3. ASSEMBLY**

Assembly of the BELLEZE Farmhouse Fireplace TV Stand requires careful attention to the provided instructions. While the process is straightforward, it is recommended to have two people for assembly due to the weight and size of the components. Ensure all parts are present before beginning and follow the step-by-step guide included in the packaging. Tools required typically include a screwdriver.

## Classic Farmhouse Style



Image 2: A diagram illustrating key features such as the built-in 23-inch electric fireplace, capacity for TVs up to 65 inches, wire management cutouts, and barn-style cabinet doors.

## 4. OPERATING INSTRUCTIONS (ELECTRIC FIREPLACE)

The integrated 23-inch electric fireplace heater offers both aesthetic flame effects and functional heating. It can be operated via a convenient control panel located on the unit or using the included remote control.

### 4.1. Basic Operation

- **Power On/Off:** Press the power button on the control panel or remote to turn the unit on or off.
- **Heat Control:** The heater can be activated independently of the flame effect. Adjust the heat settings to your desired comfort level. The infrared heater maintains optimal humidity.
- **Flame Brightness:** Select from multiple flame brightness settings to create the perfect ambiance.
- **Timer Function:** Set a timer for the fireplace to automatically turn off after a specified duration.
- **Sound Feature:** The fireplace includes a fire crackling sound effect, which can be turned on or off to enhance the realistic experience.



*Image 3: Detailed view of the electric fireplace's control panel, showing buttons for power, heat, temperature, and timer, alongside the full-function remote control.*

## 5. STORAGE FEATURES

This TV stand is equipped with ample storage solutions to help keep your living space organized.

- **Barn Style Cabinet Doors:** Two enclosed cabinets with barn-style doors and X-shaped molding provide concealed storage. These are ideal for stowing away items you prefer to keep out of sight.
- **Adjustable Shelves:** Each cabinet contains adjustable shelves, allowing you to customize the storage space to fit various electronics, media accessories, books, or other household items.
- **Open Media Compartments:** Above the fireplace, two open compartments offer easy access and ventilation for media devices such as cable boxes, gaming consoles, or soundbars.



Image 4: A cabinet door opened to reveal adjustable shelving, demonstrating the ample storage capacity for various items like blankets or media.

## 6. MAINTENANCE AND CARE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust the unit with a dry, soft cloth to prevent buildup.
- **Spills:** Immediately blot any spills with a clean, dry cloth to prevent staining.
- **Electric Fireplace:** Ensure the fireplace is unplugged before cleaning. Wipe the glass and exterior with a soft, damp cloth. Do not spray liquids directly onto the unit.

## 7. TROUBLESHOOTING

### 7.1. Common Issues

- **Fireplace Not Turning On:** Check if the unit is properly plugged into a working electrical outlet. Ensure the power button on the unit or remote is pressed.
- **No Heat Output:** Verify that the heat function is activated. Some models allow flame effects without heat. Check temperature settings.

- **Error Codes (e.g., E3):** If an error code appears on the display, consult the specific fireplace insert manual for detailed troubleshooting steps. This may indicate a malfunction requiring professional assistance or a replacement part.
- **Remote Control Not Working:** Replace batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace unit.

## 8. SPECIFICATIONS

Feature	Detail
Brand	BELLEZE
Model Name	014-HG-41007-HT-WHT
Product Dimensions	15.75"D x 58"W x 29.72"H
Material	Engineered Wood
Color	White
Item Weight	100.5 Pounds
Installation Type	Freestanding
Included Components	Electric Fireplace, Manual, Remote Control, TV Stand
Fireplace Size	23 inches
TV Compatibility	Up to 65 inches

## 9. WARRANTY AND SUPPORT

BELLEZE offers a "LOVE-IT OR 30 DAY RETURNS" policy, guaranteeing satisfaction. If you are not completely satisfied with your purchase, you may return it within 30 days. The product also comes with manufacturer coverage. For specific warranty details, claims, or technical support, please refer to the contact information provided in your product packaging or visit the official BELLEZE website.