ALLIMITY YKR-H/102E

Allimity YKR-H/102E Replaced Remote Control User Manual

For AUX Air Conditioner Models YKR-H/002E, YKR-H/101E, YKR-H/006E

Product Overview

This manual provides instructions for the Allimity YKR-H/102E replacement remote control, designed to operate various AUX Air Conditioner models. This remote control offers a direct replacement solution without the need for complex setup or programming.






Figure 1: Allimity YKR-H/102E Remote Control

Key Features:

- Direct compatibility with AUX Air Conditioner models: YKR-H/002E, YKR-H/101E, YKR-H/006E.
- No programming required; ready to use after battery installation.
- Standard button layout for intuitive operation.

Setup

Battery Installation:

The remote control requires two (2) 1.5V AAA alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.

2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: *Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.*

Operating Instructions

This section details the functions of the buttons on your Allimity YKR-H/102E remote control. Refer to the image below for button layout.



Figure 2: Remote Control Button Layout

Button Functions:

- **ON/OFF:** Powers the air conditioner on or off.
- **SET TEMPERATURE (Up/Down Arrows):** Adjusts the desired temperature.

- **MODE:** Cycles through operating modes: AUTO, COOL, DRY, HEAT (if supported by AC unit).
- **FAN:** Adjusts fan speed: AUTO, HIGH, MID, LOW.
- **TURBO:** Activates rapid cooling/heating for quick temperature changes.
- **SPEED:** (Likely duplicates FAN function or offers additional fan speed settings).
- **DISPLAY:** Toggles the display on the air conditioner unit (e.g., temperature display).
- **SLEEP:** Activates sleep mode, which adjusts temperature gradually for comfortable sleep and energy saving.
- **°C/°F:** Switches the temperature display between Celsius and Fahrenheit.
- **SWING (Vertical):** Controls the vertical swing of the air conditioner's louvers.
- **SWING (Horizontal):** Controls the horizontal swing of the air conditioner's louvers.
- **iFEEL:** Activates the "I Feel" function, where the remote's built-in sensor measures the ambient temperature and sends it to the AC unit for more precise temperature control.
- **Anti-F:** (Anti-Fungus/Mold) Likely activates a function to prevent mold growth by drying the indoor unit after cooling.
- **ELE.H:** (Electric Heating) Activates electric heating function, if available on the AC unit.
- **HEALTH:** Activates air purification or health-related functions (e.g., ionizer), if available.
- **TIMER:** Sets a timer for the air conditioner to turn on or off automatically.
- **ECO:** Activates energy-saving mode.
- **iCLEAN:** Initiates a self-cleaning cycle for the indoor unit.

For detailed operation of specific modes and advanced functions, please refer to your AUX Air Conditioner's original user manual, as this remote control replicates its functions.

Maintenance

Cleaning the Remote Control:

To maintain the remote control's appearance and functionality, clean it regularly:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water and a mild detergent, then wipe dry immediately.
- Do not use abrasive cleaners, alcohol, or corrosive liquids, as these can damage the remote's surface or internal components.

Battery Replacement:

Replace batteries when the remote control's range decreases or it becomes unresponsive. Refer to the "Battery Installation" section under Setup for instructions.

Troubleshooting

If you encounter issues with your remote control, try the following troubleshooting steps:

- **Remote not responding:**
  - Check if the batteries are inserted correctly, observing the polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm you are within the effective operating range of the air conditioner.
- **Air conditioner not responding to specific buttons:**

- Some functions (e.g., ELE.H, HEALTH, iCLEAN) may only be available if your specific AUX Air Conditioner model supports them. Refer to your AC unit's original manual.
- Ensure the remote's infrared emitter is clean and unobstructed.

- **Display on remote is dim or blank:**
  - This indicates low battery power. Replace the batteries.

If the problem persists after trying these steps, the remote control may be faulty. Contact customer support for further assistance.

Specifications

Feature	Detail
Model Number	YKR-H/102E
Compatible AC Models	AUX YKR-H/002E, YKR-H/101E, YKR-H/006E
Power Supply	2 x 1.5V AAA Alkaline Batteries (Not Included)
Product Dimensions	5 x 2 x 0.5 inches (12.7 x 5.08 x 1.27 cm)
Item Weight	1.76 ounces (50 grams)
Color	White
Special Feature	No Programming Required

Warranty and Support

Information regarding product warranty and specific customer support contact details is not provided within this manual. Please refer to the product packaging or the retailer's website for warranty information and support contacts.
For general inquiries or troubleshooting beyond the scope of this manual, you may also consult the official website of the brand ALLIMITY or the original manufacturer of your AUX Air Conditioner unit.

© 2024 ALLIMITY. All rights reserved.