

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [SEABIRD](#) /

› SEABIRD 4-in-1 Electric Women's Trimmer and Shaver User Manual

SEABIRD Trimmer Women B0BHSXYMBC

SEABIRD 4-in-1 Electric Women's Trimmer and Shaver User Manual

Model: Trimmer Women B0BHSXYMBC

1. INTRODUCTION

Thank you for choosing the SEABIRD 4-in-1 Electric Women's Trimmer and Shaver. This versatile grooming device is designed for efficient and comfortable hair removal across various body areas. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

2. PRODUCT OVERVIEW

The SEABIRD 4-in-1 Electric Women's Trimmer and Shaver is a multi-functional device featuring interchangeable heads for comprehensive hair removal. Its ergonomic design ensures comfortable handling, and its rechargeable, portable nature makes it ideal for both home and travel use.

What's in the Box?

What's in the Box?



- | | | |
|------------------------|--------------------|----------------------|
| A: Round Rotary Shaver | B: Dust Cover | C: Multi-Use Trimmer |
| D: Eyebrow Comb | E: Eyebrow Trimmer | F: Nose Hair Trimmer |
| G: Small Brushes | H: Storage Bag | |

This image displays the complete contents of the SEABIRD 4-in-1 electric trimmer package. It includes the main trimmer unit, a round rotary shaver head (A), a multi-use trimmer head (C), an eyebrow trimmer head (E), a nose hair trimmer head (F), an eyebrow comb (D), small cleaning brushes (G), a dust cover (B), and a storage bag (H).

- Main Trimmer Unit
- Round Rotary Shaver Head (A)
- Multi-Use Trimmer Head (C)
- Eyebrow Trimmer Head (E)
- Nose Hair Trimmer Head (F)
- Eyebrow Comb (D)
- Small Cleaning Brushes (G)
- Dust Cover (B)
- USB Charging Cable
- Storage Bag (H)
- User Manual

3. COMPONENTS AND FUNCTIONS

The device comes with four specialized heads to address different hair removal needs:

- **Facial Shaver Head:** Designed for delicate facial hair removal, ensuring a smooth finish.
- **Nose Hair Trimmer Head:** Safely and effectively trims unwanted nose and ear hair.
- **Eyebrow Trimmer Head:** Precisely shapes and trims eyebrows. Use the included eyebrow comb for even trimming.
- **Multi-Use Trimmer Head:** Ideal for larger body areas such as arms, legs, bikini line, and underarms.



This image illustrates the versatility of the SEABIRD 4-in-1 electric trimmer, suitable for various body areas including arms, face, bikini lines, back, legs, underarms, eyebrows, and nose hairs.

Your browser does not support the video tag.

This video demonstrates the SEABIRD 4-in-1 electric women's shaver, showcasing its interchangeable heads for facial, nose, eyebrow, and body hair removal, and highlighting its efficient wet/dry shaving capabilities.

4. SETUP

Charging the Device

1. Ensure the device is turned off.
2. Locate the USB charging port at the bottom of the main unit.
3. Connect the provided USB charging cable to the device and a suitable USB power source (e.g., power bank, computer, wall adapter).

4. The charging indicator light will illuminate.
5. A full charge typically takes approximately 35 minutes and provides up to 50 minutes of continuous use.
6. After charging, ensure the bottom cover is securely tightened to prevent water from entering the charging port, especially if using the device in wet conditions.



This diagram illustrates the USB charging process. Remember to tighten the bottom cover to prevent water contact with the charging port. A 35-minute charge provides approximately 50 minutes of shave time.

Attaching/Detaching Trimmer Heads

1. To attach a head: Align the desired trimmer head with the main unit and gently push it down until it clicks into place.
2. To detach a head: Hold the main unit firmly and twist the attached head to the right until it releases.

Easy to Clean



This image demonstrates how to remove and install the blade heads by rotating them. This mechanism is also used for cleaning.

5. OPERATION

General Usage Tips

- Ensure your skin is clean before use.
- For best results, hold the trimmer at a slight angle against the skin and move it gently against the direction of hair growth.
- Do not apply excessive pressure.
- The device supports both wet and dry shaving.

Wet & Dry Safe to Use



The SEABIRD electric trimmer is designed for both wet and dry use, allowing for convenient shaving in the shower or bath, or quick dry shaving.



For a smoother experience, the trimmer can be used with shaving cream on areas like legs.

Specific Head Usage

- **Facial Shaver:** Use on clean, dry skin. Move in small, circular motions or against the direction of hair growth.
- **Nose Hair Trimmer:** Gently insert the trimmer tip into the nostril or ear canal. Move in a circular motion to trim hair. Do not insert too deeply.
- **Eyebrow Trimmer:** Use the eyebrow comb attachment to trim eyebrows to a desired length. Brush eyebrows into place, then gently glide the trimmer against the hair growth.
- **Multi-Use Trimmer:** For body hair, hold the trimmer flat against the skin and move it slowly against the direction of hair growth. Can be used with or without shaving cream/gel.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your trimmer.

1. Turn off the device and detach the trimmer head.
2. Use the small cleaning brush to remove any loose hairs from the blade and inside the head.
3. The trimmer heads are washable. Rinse them under running water. Ensure they are completely dry before reattaching or storing.

4. Wipe the main unit with a damp cloth. Do not submerge the main unit in water.
5. Ensure all parts are dry before storing the device.



This image demonstrates the easy cleaning process, showing how to remove the blade head and rinse it under water.

Storage

Store the trimmer in a cool, dry place, away from direct sunlight and out of reach of children. Use the provided storage bag to protect the device and its accessories.

7. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Check if the power button is pressed correctly.
- **Poor trimming performance:** Clean the blade heads thoroughly to remove any trapped hairs. Ensure the blade head is correctly attached. The battery might be low; recharge the device.
- **Device feels hot:** It is normal for the device to warm up during extended use. If it becomes excessively hot, turn it off and allow it to cool down before resuming use.
- **Excessive noise:** Ensure the trimmer head is securely attached. Clean the head to remove any obstructions.

8. SPECIFICATIONS

Feature	Description
Brand	SEABIRD
Model Name	Trimmer Women
Power Source	Battery Powered (Rechargeable via USB)
Special Features	4-in-1 Interchangeable Heads, Detachable Heads, Ergonomic Design, Hybrid, Pivoting Head, Wet & Dry Safe (IPX7 washable body)
Recommended Uses	Face, Beard, Eyebrow, Leg, Arm, Bikini, Armpit, Pubic Hair, Nose Hair, Back Hair, Chest, Lip, Ear

9. WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support, please refer to the documentation included with your purchase or contact SEABIRD customer service through the retailer where the product was purchased. Keep your proof of purchase for warranty claims.