


[Manuals.plus](#) /

› [MediAcous](#) /

› MediAcous Floor Lamp Accessory Adapter User Manual

MediAcous ME-FL01-Adapter



MediAcous Floor Lamp Accessory Adapter

Model: ME-FL01-Adapter

INTRODUCTION

This user manual provides essential information for the safe and effective use of your MediAcous Floor Lamp Accessory Adapter, specifically designed for the ME-FL01 floor lamp. Please read this manual thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Use this adapter **only** with the MediAcous ME-FL01 floor lamp. Using it with other devices may cause damage or malfunction.
- This is an American standard plug adapter. Do not attempt to use it in regions with different voltage or plug standards without a proper converter.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not disassemble, modify, or attempt to repair the adapter. Refer all servicing to qualified personnel.
- Ensure the power outlet is easily accessible and unplug the adapter during electrical storms or when unused for long periods.
- Keep out of reach of children and pets.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x MediAcous Floor Lamp Accessory Adapter (ME-FL01-Adapter)



Image: The MediAcous Floor Lamp Accessory Adapter, featuring a black power brick with an American standard two-prong plug and an attached DC output cable.

SETUP

Follow these steps to connect your adapter to the MediAcous ME-FL01 floor lamp:

1. Locate the power input port on the base of your MediAcous ME-FL01 floor lamp.
2. Take the DC output plug from the accessory adapter and carefully insert it into the power input port on the lamp base. Ensure it is fully and securely connected.
3. Plug the adapter's two-prong plug into a standard American wall outlet (AC 100-240V, 50/60Hz).
4. Once connected, the floor lamp is ready for operation using its integrated controls.



Image: A MediAcous ME-FL01 floor lamp standing next to a sofa, with the accessory adapter plugged into a wall outlet, demonstrating the connection.

Your browser does not support the video tag.

Video: A demonstration showing how to connect the MediAcous Floor Lamp Accessory Adapter to the ME-FL01 floor lamp, from unboxing the adapter to plugging it into the lamp and then into a wall outlet.

OPERATION

The accessory adapter provides power to your MediAcous ME-FL01 floor lamp. Once connected and plugged into a power source, the lamp can be operated using its built-in controls (e.g., remote control, touch buttons on the lamp itself). Refer to your ME-FL01 floor lamp's specific user manual for detailed operating instructions.

MAINTENANCE

- **Cleaning:** Disconnect the adapter from the power outlet and the lamp before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately and replace the adapter.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on after connecting the adapter.	Adapter not properly plugged into the wall outlet. Adapter not securely connected to the lamp. Power outlet is not functioning. Lamp issue (not adapter).	Ensure the adapter is fully inserted into a live wall outlet. Verify the DC plug is firmly inserted into the lamp's power port. Test the outlet with another device. Consult the ME-FL01 floor lamp's manual for troubleshooting lamp-specific issues.
Adapter feels unusually hot.	Overload or internal malfunction. Poor ventilation.	Immediately unplug the adapter from the wall and the lamp. Allow it to cool down. Do not use if it continues to overheat. Ensure the adapter is in a well-ventilated area.

If the problem persists after trying the above solutions, please contact MediAcous customer support.

SPECIFICATIONS

- **Model:** ME-FL01-Adapter
- **Input:** AC 100-240V ~ 50/60Hz
- **Output:** DC 24V 0.5A
- **Plug Type:** American Standard
- **Weight:** Approximately 3.2 ounces
- **Material:** Acrylonitrile Butadiene Styrene

WARRANTY AND SUPPORT

For information regarding warranty coverage, please refer to the warranty card included with your original MediAcous ME-FL01 floor lamp or visit the official MediAcous website. For technical support, troubleshooting assistance, or replacement parts, please contact MediAcous customer service through their official channels. You can often find contact information on the product packaging, the official MediAcous website, or through the retailer where you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BHSY8G1R>

More documents and user manuals: <https://manuals.plus/>