

manuals.plus /

› **OUKITEL** /

› **OUKITEL WP18 Pro Rugged Smartphone User Manual**

## OUKITEL WP18 Pro

# OUKITEL WP18 Pro Rugged Smartphone User Manual

Model: WP18 Pro

## 1. INTRODUCTION

---

This manual provides essential information for the safe and efficient operation of your OUKITEL WP18 Pro Rugged Smartphone. Designed for durability, this device features a robust build, a large battery, and advanced functionalities to support various demanding environments.



Figure 1: OUKITEL WP18 Pro Rugged Smartphone

The OUKITEL WP18 Pro is a rugged smartphone built to withstand harsh conditions, featuring a durable exterior and a large battery capacity.

## 2. WHAT'S IN THE BOX

Verify that all items are present in the packaging:

- OUKITEL WP18 Pro Phone
- 18W Fast Charger
- 2A TYPE-C Data Cable
- SIM Tray Ejector
- Packing Box, Manual, Warranty Card

- Color Protective Film

### 3. KEY FEATURES

- **Massive 12500mAh Battery:** Provides extended usage with up to 37 days standby, 70 hours calling, 48 hours music, and 22 hours video playback. Supports OTG for reverse charging other devices.




Figure 2: Illustrates the 12500mAh battery capacity, offering extended standby, call, video, and music times.

- **Rugged Durability (IP68 & IP69K & MIL-STD-810G):** Designed to be waterproof (up to 1.5 meters), dustproof, and drop-proof (from 1.5 meters). Operates in temperatures from -10°C to 70°C.



Figure 3: Demonstrates the phone's resistance to water, extreme temperatures, and drops, highlighting its rugged design.

- **Android 12 System:** Experience a cleaner interface, enhanced privacy protection, and a smoother user experience.

# The Best Android 12.0 Experience Ever



Android 12.0



MT6762



1TB Expansion



4 RAM GB + 64  
ROM GB



Figure 4: Shows the OUKITEL WP18 Pro running Android 12, emphasizing the user interface and system features.

- **5.93" TFT HD+ Display with Corning Gorilla Glass:** Offers a wide visual experience with 720\*1440 resolution and 400NIT brightness.

# 5.93" HD+ Full Large Anti-Scratch Display

HD 720 \* 1440 Resolution



Corning Tempered Glass



440nit Screen Brightness



18:9 Aspect Ratio



Figure 5: Highlights the 5.93-inch HD+ display with Corning Gorilla Glass, providing a clear and durable viewing experience.

- **13MP Main Camera & Underwater Mode:** Capture high-quality photos and videos with the 13MP main camera and 5MP front camera. Features a dedicated underwater recording mode.

# Record Every Beautiful Moment of Life



Figure 6: Details the camera specifications, including the 13MP rear camera and 5MP front camera, suitable for various photography needs.

- **4GB RAM + 64GB ROM (Expandable to 1TB):** Ample storage for apps, images, and videos.



Figure 7: Illustrates the phone's memory and storage capabilities, including 4GB RAM, 64GB ROM, and support for 1TB expansion via TF card.

- **4G Dual SIM & Fingerprint Unlock:** Supports two Nano SIM cards or one Nano SIM and one TF card. Features a side-mounted fingerprint sensor for easy access.

## 4. SETUP GUIDE

---

### 4.1 Inserting SIM/TF Card

1. Locate the SIM card tray on the side of the phone.
2. Insert the SIM tray ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano SIM card(s) and/or TF card into the designated slots on the tray. Ensure correct orientation.
4. Carefully push the tray back into the phone until it is flush with the device.

### 4.2 Initial Power On and Setup

1. Press and hold the Power button (located on the side) until the OUKITEL logo appears.
2. Follow the on-screen prompts to select your language, connect to Wi-Fi, and set up your Google account.
3. Configure security settings, including fingerprint unlock, for convenient and secure access.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Basic Navigation

- **Touchscreen:** Tap to select, swipe to scroll, pinch to zoom.
- **Power Button:** Press to wake/sleep, long press for power options.
- **Volume Buttons:** Adjust media and call volume.

### 5.2 Camera Usage

The OUKITEL WP18 Pro features a 13MP main camera and a 5MP front camera.

1. Open the Camera app from your home screen or app drawer.
2. Select between Photo, Video, and other modes (e.g., Panorama, Beauty).
3. For underwater photography, activate the dedicated "Underwater Mode" if available in the camera settings to optimize touch response and image quality in wet conditions.
4. Tap the shutter button to capture photos or start/stop video recording.

Your browser does not support the video tag.

Video 1: OUKITEL WP18 Pro Rugged Phone Features Overview. This video demonstrates the phone's ruggedness, battery life, and camera capabilities.

### 5.3 OTG Functionality (Reverse Charging)

Your OUKITEL WP18 Pro can act as a power bank to charge other devices.

1. Connect the OTG cable (not included) to your WP18 Pro's USB-C port.
2. Connect the other end of the OTG cable to the device you wish to charge.
3. Ensure the OTG setting is enabled in your phone's USB preferences if charging does not begin automatically.



Figure 8: Shows the OUKITEL WP18 Pro utilizing its reverse charging feature to power another device, demonstrating its power bank capability.

## 6. MAINTENANCE AND CARE

- **Waterproof and Dustproof Care:**
  - Ensure all port covers (USB-C, headphone jack) are securely closed before exposing the phone to water or dust.
  - After exposure to water, especially saltwater, rinse the phone with clean fresh water and dry thoroughly before opening any ports or charging.
- **Drop-proof Design:** While designed to be drop-proof, extreme impacts can still cause damage. Avoid unnecessary drops.
- **Battery Longevity:** To maximize battery life, avoid fully discharging the battery frequently. Use the provided 18W fast charger for optimal charging.
- **Screen Protection:** The Corning Gorilla Glass provides scratch resistance, but a protective film (included) is recommended for additional safeguarding.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Phone does not power on.	Low battery; software crash.	Charge the phone for at least 30 minutes. Perform a forced restart by holding the Power button for 10-15 seconds.
Cannot connect to network.	SIM card issue; network settings.	Ensure SIM card is correctly inserted. Check network settings (Settings > Network & internet > Mobile network). Restart the phone.
Battery drains quickly.	Background apps; high brightness; poor signal.	Close unused apps. Reduce screen brightness. Disable Wi-Fi/Bluetooth when not in use. Check for app updates.
Phone is slow/unresponsive.	Too many apps; low storage.	Clear cache and data of frequently used apps. Uninstall unnecessary apps. Free up storage space. Restart the phone.

## 8. SPECIFICATIONS

Feature	Detail
Product Dimensions	6 x 3 x 0.8 inches
Item Weight	14.7 ounces
Item Model Number	WP18 Pro
Batteries	1 Lithium Polymer batteries required (included)
Operating System	Android 12.0
Wireless Communication Technologies	Cellular, NFC
Connectivity Technologies	Bluetooth, Wi-Fi, NFC
GPS	True
Special Features	Supports USB OTG, Rugged Body, Fast Charging Support, Built-In GPS, Water Resistant
Human Interface Input	Touchscreen
Scanner Resolution	720 x 1440
Other Camera Features	Rear, Front
Audio Jack	3.5 mm
Form Factor	Bar
Color	Green
Battery Power Rating	55.6 Watt Hours
Phone Talk Time	65 Hours
Phone Standby Time (with data)	800 hours
Manufacturer	OUKITEL
Date First Available	October 10, 2022
Memory Storage Capacity	64 GB
Standing Screen Display Size	5.93 Inches
RAM Memory Installed Size	4 GB
Battery Capacity	12500 Milliamp Hours
Screen Size	5.93 Inches
Resolution	720 x 1440

Feature	Detail
Wireless Carrier	T-Mobile
Cellular Technology	4G

## 9. WARRANTY AND SUPPORT

---

OUKITEL offers a comprehensive support package for your WP18 Pro smartphone:

- **30-Day No-Reason Return:** If you are not satisfied, you can return the product within 30 days.
- **One-Year Free Warranty:** Covers manufacturing defects for one year from the date of purchase.
- **Long-Term Technical Support:** Ongoing assistance for any technical issues you may encounter.
- **24-Hour Online Customer Service:** Dedicated support available around the clock for your convenience.

For support, please refer to the contact information provided in your warranty card or visit the official OUKITEL website.