

Nokia E3110

Nokia Essential Wireless Earbuds E3110 User Manual

Model: E3110

1. INTRODUCTION

Thank you for choosing the Nokia Essential Wireless Earbuds E3110. These earbuds are designed to provide a high-quality audio experience with convenient features such as Bluetooth 5.1 connectivity, Environmental Noise Cancellation (ENC) for clear calls, and intuitive touch controls. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

2. PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- 1 x Nokia E3110 Earbuds (Left and Right)
- 1 x Charging Case
- 1 x USB Charging Cable
- 1 x User Manual

Packaging List



Image: Contents of the Nokia E3110 Earbuds package, including the earbuds, charging case, USB cable, and user manual.

3. PRODUCT OVERVIEW

The Nokia E3110 earbuds feature a semi in-ear design, weighing approximately 3.2g per earbud for comfortable wear. They are equipped with a 13mm dynamic driver for balanced sound and deep bass. The charging case provides additional battery life and protects the earbuds when not in use.



Image: The Nokia E3110 wireless earbuds, one placed in the open charging case and the other standing upright, showcasing their sleek black design.

Semi in Ear Design Only 3.2g of Each Earbud*

Ergonomic design for secure & comfortable fit
Comfortable for long time wearing with ergonomic
designed earbud fitting in your ears.




Image: A person wearing a Nokia E3110 earbud, illustrating its semi in-ear design and comfortable fit.

Full-Bodied sound

Designed with a refined 13mm powerful dynamic driver the E3110 plays crisp, balanced sound with impressively deep bass



Image: An exploded diagram illustrating the internal components of the Nokia E3110 earbud, highlighting the 13mm dynamic driver for sound production.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB charging cable to the charging port on the case and to a power source. The indicator lights on the case will show the charging status.

- Earbuds provide up to 4 hours of playback on a single charge.
- The 250mAh charging case extends total playback time up to 25 hours.
- A 20-minute charge can provide approximately one hour of music playback.

16 Hours* Long Battery Life Stay Tune on the Go



4hours
Play time with
single charge

16hours
In total with
charging box

250mAh
Capacity for
charging box

Image: The Nokia E3110 earbuds in their charging case, with text indicating 4 hours play time per single charge, 16 hours total with charging box, and 250mAh capacity for the charging box.

4.2 Bluetooth Pairing

The Nokia E3110 earbuds utilize Bluetooth 5.1 technology for a stable and fast connection.

1. **Initial Pairing:** Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Nokia E3110" from the list of found devices to connect.
4. Once paired, the earbuds will automatically connect to your device when taken out of the case for subsequent uses.

Bluetooth 5.1 Stable and Seamless Connection

Bluetooth v5.1 delivering fast,
stable and seamless audio experience




Image: A graphic representation of a Bluetooth 5.1 chip, symbolizing the stable and seamless connection technology of the earbuds.

Equipped with the Most Advanced Bluetooth V5.1 Chipset

Which provides more stable connection
and faster pairing




Image: Nokia E3110 earbuds and their open charging case positioned next to a smartphone displaying a game, illustrating the advanced Bluetooth V5.1 chipset for stable connection and faster pairing.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The Nokia E3110 earbuds feature intuitive touch controls on each earpiece. A light tap allows you to manage music playback, calls, and voice assistant functions.

Function	Action	Earbud (L/R)
Play/Pause Music	Single Tap	L/R
Next Song	Double Tap	Right
Previous Song	Double Tap	Left
Volume Up	Triple Tap	Right
Volume Down	Triple Tap	Left

Function	Action	Earbud (L/R)
Answer/End Call	Single Tap	L/R
Reject Call	Press and Hold (2s)	L/R
Activate Voice Assistant (Siri, Google Assistant)	Press and Hold (2s)	L/R

5.2 Environmental Noise Cancellation (ENC)

The E3110 earbuds feature ENC technology, which helps reduce ambient noise during calls. This ensures your voice is transmitted clearly to the other party, even in noisy environments.




Image: A person using the Nokia E3110 earbud for a call, highlighting the Environmental Noise Reduction (ENC) feature for clear communication.

5.3 Single or Dual Earbud Use

The E3110 earbuds support independent use of either the left or right earbud. You can switch between using one or both earbuds seamlessly, providing flexibility for calls or music listening.

6. MAINTENANCE

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Ensure charging contacts on both earbuds and case are clean and free of debris.

6.2 Water Resistance

The Nokia E3110 earbuds feature an IP44 splash-proof design, meaning they are resistant to splashes of water and sweat. They are not designed for submersion in water.



Image: The Nokia E3110 earbuds with water droplets on their surface, illustrating their IP44 splash-proof design suitable for use in light rain or during workouts.

6.3 Storage

Store the earbuds in their charging case when not in use to protect them and ensure they remain charged. Avoid storing them in extreme temperatures or high humidity.

7. TROUBLESHOOTING

If you encounter issues with your Nokia E3110 earbuds, refer to the following common solutions:

- **No Sound/Poor Sound Quality:**
 - Ensure earbuds are properly paired and connected to your device.
 - Check the volume level on both your device and the earbuds.
 - Ensure earbuds are clean and free of debris.
 - Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise place back in case and re-pair).
- **Pairing Issues:**
 - Make sure Bluetooth is enabled on your device.
 - Ensure earbuds are in pairing mode (open the charging case).
 - Forget the device from your phone's Bluetooth settings and try pairing again.
 - Ensure earbuds are charged.
- **Charging Issues:**
 - Verify the charging cable and power adapter are working correctly.
 - Ensure the charging contacts on the earbuds and inside the case are clean.
 - Make sure the earbuds are correctly seated in the charging case.
- **Earbuds Not Turning On:**
 - Ensure the earbuds are sufficiently charged.
 - Place them back in the charging case and then remove them again.

8. SPECIFICATIONS







Feature	Specification
Model	E3110
Bluetooth Version	5.1
Driver Unit	13mm Dynamic
Earbud Weight	Approx. 3.2g (each)
Playback Time (Earbuds)	Up to 4 hours
Total Playback Time (with Case)	Up to 25 hours
Charging Case Capacity	250mAh
Noise Reduction	ENC (Environmental Noise Cancellation)
Water Resistance Rating	IP44 (Splash-proof)
Control Type	Touch
Microphone	Built-In
Compatible Devices	Smartphones, Tablets, Laptops, Desktops, Cars
Product Dimensions	11.8 x 11.6 x 4.2 cm


Feature	Specification
Item Weight	80 g

9. WARRANTY AND SUPPORT

Nokia products are manufactured by Richgo under license. For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Nokia accessories website. Keep your proof of purchase for warranty claims.

Related Documents - E3110


	<p>Nokia Essential True Wireless Earphones E3110 User Guide</p> <p>User guide for the Nokia Essential True Wireless Earphones E3110, covering setup, pairing, controls, troubleshooting, and safety information.</p>
	<p>Nokia E3110 Earphones: Frequently Asked Questions and Support</p> <p>Comprehensive FAQ covering Bluetooth version, battery life, charging, individual use, voice assistant, water resistance, multi-device pairing, battery replacement, product information, setup, volume control, audio sync, sound drop-outs, voice clarity, and customer support for Nokia E3110 earphones.</p>
	<p>Nokia Essential True Wireless Earphones E3110 User Guide</p> <p>Comprehensive user guide for Nokia Essential True Wireless Earphones E3110, covering setup, troubleshooting, specifications, and safety information.</p>
	<p>Nokia Essential True Wireless Earphones E3511 User Guide</p> <p>User guide for Nokia Essential True Wireless Earphones E3511, covering setup, pairing, charging, controls, troubleshooting, and safety information.</p>
	<p>Nokia Comfort Earbuds TWS-411 Quick Start Guide</p> <p>A quick start guide for Nokia Comfort Earbuds, Nokia Comfort Earbuds Core (TWS-411), detailing setup, Bluetooth pairing, touch controls, safety precautions, device care, and regulatory information.</p>
	<p>Nokia Comfort Earbuds TWS-411/TWS-411W Quick Start Guide</p> <p>User guide for Nokia Comfort Earbuds+ (TWS-411/TWS-411W) detailing setup, Bluetooth pairing, touch controls, safety precautions, and product care from HMD Global.</p>



[Nokia Essential True Wireless Earphones E3110 User Guide](#)

Comprehensive user guide for Nokia Essential True Wireless Earphones E3110, covering setup, troubleshooting, specifications, and safety information.

lang:en score:42 filesize: 2.15 M page_count: 1 document date: 2022-02-28



[\[pdf\] Troubleshooting Guide Guide](#)


E3110 user guide v1 20220212 PobierzSłuchawki bezprzewodowe douszne Nokia Fioletowe w Max

Kuchniegproxysklep maxkuchnie.pl storage file pimcore import 2024 12 5

a72df49b1f0fc2de8b1757b10c4eb0b3 nokia tws e3110 instrukcja obsługi |||

Contents // Nokia Essential True Wireless Earphones **E3110** User guide // // Powering on Pairing mode 1 2 Settings Bluetooth MY DEVICES Nokia **E3110** Charging Earphones charging // / 100 Solid white light// / 100 White light off// / Case charging // / 100 Flashing green ...

lang:en score:40 filesize: 2.13 M page_count: 1 document date: 2022-02-28



[Nokia Essential True Wireless Earphones E3110 User Guide](#)

User guide for the Nokia Essential True Wireless Earphones E3110, covering setup, pairing, controls, troubleshooting, and safety information.


lang:en score:38 filesize: 2.15 M page_count: 1 document date: 2022-02-25



[Nokia E3110 Earphones: Frequently Asked Questions and Support](#)

Comprehensive FAQ covering Bluetooth version, battery life, charging, individual use, voice assistant, water resistance, multi-device pairing, battery replacement, product information, setup, volume control, audio sync, sound drop-outs, voice clarity, and customer support for Nokia E3110 earphones.


lang:en score:33 filesize: 122.01 K page_count: 4 document date: 2023-12-04



[Nokia Essential True Wireless Earphones E3106 User Guide](#)

Comprehensive user guide for Nokia Essential True Wireless Earphones E3106, covering powering on, pairing, charging, troubleshooting, controls, specifications, and safety instructions.


lang:en score:30 filesize: 2.58 M page_count: 1 document date: 2023-02-21



[Nokia Essential True Wireless Earphones E3100 Plus User Guide](#)

Comprehensive user guide for the Nokia Essential True Wireless Earphones E3100 Plus, covering powering on, pairing, charging, troubleshooting, controls, specifications, and safety instructions.


lang:en score:25 filesize: 2.2 M page_count: 1 document date: 2022-06-21



[Nokia Essential True Wireless Earphones E3100 Plus User Guide](#)

Comprehensive user guide for Nokia Essential True Wireless Earphones E3100 Plus, covering setup, powering on, pairing, charging, troubleshooting, specifications, safety information, reset procedures, and FCC compliance.

lang:en score:24 filesize: 2.54 M page_count: 1 document date: 2023-08-16



[pdf]

Instrukcja obsługi słuchawek bezprzewodowych NOKIA E3110 Essential True Wireless obsługi
słuchawek Feb 10 2025 · Normalna temperatura robocza produktu wynosi 0 °C 40 lub 32 °F 104°F
manuals plus pl nokia e3110 essential true wireless earphones obsługi mediaexpert products files 55
5549576 |||

...

lang:en score:18 filesize: 1.23 M page_count: 13 document date: 2025-02-10