

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Beurer](#) /

› [Beurer FB 65 Wellness Foot Spa Instruction Manual](#)

Beurer FB65

Beurer FB 65 Wellness Foot Spa Instruction Manual

Model: FB65

Brand: Beurer

INTRODUCTION AND OVERVIEW

The Beurer FB 65 Wellness Foot Spa provides a relaxing foot care experience with vibration and bubble massage. It features powerful water heating up to 48°C, massage nubs, and large massage rollers for intense foot stimulation. The integrated ambient lighting offers six different light effects to enhance your mood. The included pedicure attachments allow for comprehensive foot care. Practical features include a storage and drying bag, convenient carrying handles, and non-slip rubber feet with a cable winder. This foot spa accommodates shoe sizes up to 51.



A clear view of the Beurer FB 65 foot spa, illustrating its overall design, the layout of the control panel, and the internal massage nubs and rollers.

SAFETY WARNINGS

- If water leaks from the device, it must no longer be used as the device has a hot surface.
- Individuals sensitive to heat should exercise caution when using the device.
- Children are not permitted to play with the device.
- If the power cord of this device is damaged, it must be discarded.
- Protect the device from splashes.

SETUP

1. Remove the foot spa from its packaging.
2. Fill the foot spa with water up to the indicated mark.

OPERATING INSTRUCTIONS

1. Select the desired temperature setting.
2. Turn on the foot spa using the on/off switch.
3. Choose the desired massage program.
4. Enjoy the massage and relaxation.

Massage par vibrations et massage à bulles
avec différents programmes prédéfinis



This image illustrates the foot spa in use, demonstrating the bubble and vibration massage functions. The control panel is visible on the wooden top.



Chauffage à l'eau à 8 niveaux (34 à 48 °C)

3 zones de température au choix

This image shows a user interacting with the touch control panel to set the water temperature, highlighting the foot spa's heating capability.

PEDICURE STATION USAGE

To use the pedicure station, insert the attachments into the designated slots and follow the instructions provided with the accessories.

Avec station de pédicure rotative et 3 embouts différents



The image displays the integrated rotating pedicure station of the foot spa, along with its three distinct attachments: a pumice stone for exfoliation, a brush for cleaning, and a massage roller for additional foot stimulation.

KEY FEATURES

- **Wellness at Home:** The foot spa offers a wellness experience for your feet. It can be filled with cold water for refreshment or warm/hot water for a soothing, warming effect.
- **Relaxing Massage:** The Beurer FB 65 Wellness bubble foot spa provides relaxing vibration or bubble massage with different massage programs. The activatable lighting creates the right ambiance.
- **Powerful Water Heating:** Water can be heated in 8 stages between 34 and 48°C. The foot massage bath body is double-walled for better thermal insulation.
- **Foot Massage and Pedicure:** Nubs and extra-large rollers further massage the soles of the feet. The rotating pedicure station with 3 pedicure attachments allows for foot care.
- **Practical Design:** The touch screen, storage and drying bag, practical carrying handles, and non-slip rubber feet, including a cable winder, facilitate handling.



Éclairage d'ambiance

enclenchable dans 6 couleurs différentes



The foot spa is shown with its ambient lighting feature active, displaying one of the six available color options, enhancing the relaxation experience.

MAINTENANCE

Regular cleaning is essential for hygiene and longevity. After each use, empty the water completely and clean the interior of the foot spa. Use mild cleaning agents and a soft cloth. Ensure the device is thoroughly dried before storage. Avoid abrasive cleaners or harsh chemicals. Store the foot spa and its accessories in the provided storage bag in a dry place.

TROUBLESHOOTING

If the device does not function as expected, please refer to the safety warnings section. Ensure the power cord is undamaged and properly connected. If issues persist, contact customer support.

SPECIFICATIONS

Units	1 Total
Brand	Beurer

Country of Origin	China
ASIN	B0BHTHL9RC
Product Dimensions (L x W x H)	46.2 x 40.5 x 19 cm
Item Weight	3.45 Kilograms
Manufacturer	Beurer GmbH
Model Number	FB65
Use for	Feet
Power Source	Electric cable
Material	Rubber
Color	Hout (Wood)
Special Feature	Heat
Massager Form	Foot massager and spa
Specific Uses for Product	Home use, foot care

WARRANTY AND SUPPORT

Warranty information and customer support details are typically provided with the product packaging or on the manufacturer's official website. Please refer to these sources for specific warranty terms and contact information.

© 2023 Beurer. All rights reserved.