

- Manuals.plus /
- › ECR4Kids /
- › ECR4Kids Scoop Front Storage Bin Instruction Manual

ECR4Kids Scoop Front Storage Bin

ECR4Kids Scoop Front Storage Bin Instruction Manual

Model: Scoop Front Storage Bin
Brand: ECR4Kids

1. INTRODUCTION AND OVERVIEW

The ECR4Kids Scoop Front Storage Bins are designed to help organize and tidy various spaces, including classrooms and homes. These sturdy plastic bins are suitable for containing small items and keeping areas clutter-free. They are versatile for storing books, toys, manipulatives, games, and other supplies.

Key features include a durable design, rounded edges for safety, an easy-to-grasp scoop front handle for convenient access, and a stackable design for space-saving storage when empty. The bins are UL GREENGUARD Gold Certified for low VOCs and CPSIA compliant, ensuring safety and quality.



Image: A single green ECR4Kids Scoop Front Storage Bin, showcasing its design.



Image: A child playing with blocks, with an ECR4Kids bin nearby, highlighting the product's safety certifications.

2. SETUP

The ECR4Kids Scoop Front Storage Bins come fully assembled and ready for immediate use. No assembly is required.

- Unpack the bins from their packaging.
- Inspect each bin for any signs of damage during transit. If any damage is found, please refer to the 'Warranty and Support' section.
- Place the bins in your desired location for storage.

3. OPERATING INSTRUCTIONS

These multipurpose bins offer flexible storage solutions for various items.

Using the Bins for Storage:

- **Organizing Items:** Use the bins to store books, toys, art supplies, snacks, tools, and other small items.

- **Easy Access:** The scoop front design allows for convenient and quick access to the contents within the bin.
- **Labeling:** For enhanced organization, label the bins by content, reading level, theme, or color-code them to create an intuitive system.
- **Compatibility:** The bins are designed to fit in most 12-inch cubbies and can be paired with ECR4Kids storage lockers, cubby units, or tray cabinets (sold separately) to maximize space and maintain a clutter-free environment.



Multipurpose
Keep toys, school supplies, office
items, and household essentials
organized and within reach

Image: A woman placing items into an ECR4Kids Scoop Front Storage Bin, demonstrating its multipurpose use.

Portable Design
Rounded edges
make it easy to
carry and transport



Scoop Front
Allows for convenient
access to contents



Image: A woman holding an ECR4Kids Scoop Front Storage Bin, illustrating its portable design and easy-to-grasp scoop front.

Space-Saving Storage:

- When not in use, the bins can be nested or stacked to save space. Built-in stack supports prevent locking when empty, ensuring easy separation.

Maximize Your Space

Pair with ECR4Kids Storage Units to keep your learning space clutter-free



*** Storage unit sold separately**

Image: Several ECR4Kids Scoop Front Storage Bins neatly arranged within a wooden storage unit, demonstrating how to maximize space.

Video: An official ECR4Kids video demonstrating the features and uses of the Scoop Front Storage Bins, including their stackable design and ease of use for children.

4. MAINTENANCE

The ECR4Kids Scoop Front Storage Bins are designed for easy cleaning and disinfection.

- **Cleaning:** Wipe the bins with a damp cloth and mild soap.
- **Disinfecting:** For thorough cleaning, use a child-safe disinfectant solution as needed.
- **Drying:** Allow the bins to air dry completely before refilling or stacking.

5. TROUBLESHOOTING

While the ECR4Kids Scoop Front Storage Bins are built for durability, here are some general troubleshooting tips:

- **Damaged Bin:** If a bin arrives damaged or becomes damaged during normal use, please contact ECR4Kids

customer support for assistance.

- **Difficulty Stacking:** Ensure bins are empty and aligned correctly before stacking to prevent them from getting stuck.
- **Cleaning Stains:** For stubborn stains, a gentle scrub brush may be used with mild soap. Avoid abrasive cleaners that could scratch the plastic.

6. SPECIFICATIONS

Detailed specifications for the ECR4Kids Scoop Front Storage Bin:



Image: A diagram illustrating the precise dimensions of the ECR4Kids Scoop Front Storage Bin.

Feature	Detail
Color	Green
Material	Plastic
Product Dimensions (L x W x H)	11.6"L x 8"W x 5"H (29.5 cm L x 20.3 cm W x 12.7 cm H)

Feature	Detail
Interior Base Dimensions (L x W)	9.5"L x 6"W (24 cm L x 15 cm W)
Item Weight	8 ounces
Capacity	1.2 US Gallons
Finish Type	Smooth
Certifications	UL GREENGUARD Gold Certified, CPSIA Compliant

7. WHAT'S IN THE BOX

Each package of the ECR4Kids Scoop Front Storage Bin contains:

- Scoop Front Storage Bin (quantity as per purchase)

8. WARRANTY AND SUPPORT

ECR4Kids is committed to providing high-quality, safe, and durable products. For any questions, concerns, or issues regarding your Scoop Front Storage Bin, please contact ECR4Kids customer support.

For information on product warranty and return policies, please refer to the seller's specific terms at the time of purchase or visit the official ECR4Kids brand store for detailed information.

ECR4Kids Brand Store: [Visit the ECR4Kids Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BHV4ZLLH>

More documents and user manuals: <https://manuals.plus/>