HUAWEI MO-huano10seds128beu

HUAWEI Nova 10 SE User Manual

Model: MO-huano10seds128beu

Introduction

This manual provides essential information for the safe and efficient operation of your HUAWEI Nova 10 SE smartphone. Please read this manual thoroughly before using your device to ensure proper functionality and to prevent damage.

Safety Information

- **Battery Safety:** The device is powered by a non-removable Li-Po 4500 mAh battery. Do not attempt to replace the battery yourself. Use only HUAWEI-approved chargers and cables.
- **Network Compatibility:** This smartphone is designed for specific network frequencies. For USA buyers, it is not compatible with CDMA networks (VERIZON, SPRINT, US CELLULAR). Verify compatibility with your network provider before use.
- **Operating Environment:** Avoid exposing the device to extreme temperatures, direct sunlight, or high humidity. Keep it away from water and other liquids.
- **Disposal:** Dispose of the device and its accessories responsibly according to local regulations. Do not dispose of electronic waste in household trash.

What's in the Box

Upon unboxing your HUAWEI Nova 10 SE, please ensure all the following items are present:

- HUAWEI Nova 10 SE Smartphone (Starry Black)
- USB Cable
- Quick Start Guide (may be separate or integrated)
- SIM Ejector Tool (may be included depending on region)

Product Overview

Familiarize yourself with the physical components of your HUAWEI Nova 10 SE.



Figure 1: Front and back view of the HUAWEI Nova 10 SE smartphone. The front displays the large OLED screen with a punch-hole camera, while the back shows the triple camera module and the HUAWEI branding.



Figure 2: Front view of the HUAWEI Nova 10 SE, highlighting the 6.67-inch OLED display and the front-facing camera located at the top center.



Figure 3: Side view of the HUAWEI Nova 10 SE, showing the power button and volume rocker on the right edge of the device.



Figure 4: Bottom view of the HUAWEI Nova 10 SE, illustrating the USB-C charging port, speaker grille, and microphone.



Figure 5: Top view of the HUAWEI Nova 10 SE, showing the secondary microphone and SIM card tray slot.

Setup

1. **Insert SIM Card(s):**

   Locate the SIM card tray on the side of the device. Use the provided SIM ejector tool to open the tray. Insert your Nano-SIM card(s) into the designated slots. This device supports Dual SIM functionality.

   Note: Ensure the SIM card is correctly oriented as shown in the tray diagram. This phone supports 4G/LTE networks.

2. **Initial Charge:**

   Before first use, fully charge the device using the supplied USB cable and a compatible power adapter. The battery capacity is 4500 mAh.

3. **Power On:**

   Press and hold the power button (located on the right side) until the HUAWEI logo appears on the screen.

4. **Initial Setup Wizard:**

   Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and account setup. The device runs on EMUI 12.

Operating

Basic Navigation (EMUI 12)

- **Touchscreen Gestures:** Navigate the device using standard touchscreen gestures such as tap, swipe, pinch-to-zoom, and long press.
- **Home Screen:** Customize your home screen with widgets and app shortcuts.
- **Notifications Panel:** Swipe down from the top of the screen to access notifications and quick settings.

Making Calls

1. Open the **Phone** application.
2. Enter the phone number using the dial pad or select a contact from your address book.
3. Tap the call button to initiate the call.

Using the Camera

The HUAWEI Nova 10 SE features a versatile camera system:

- **Main Camera:** 108 MP, f/1.9, 27mm (wide), PDAF
- **Ultrawide Camera:** 8 MP, f/2.2, 112°
- **Macro Camera:** 2 MP, f/2.4
- **Front Camera:** 16 MP, f/2.2 (wide)

1. Open the **Camera** application.
2. Select your desired mode (Photo, Video, Portrait, etc.).

3. Tap the shutter button to capture an image or start/stop recording.

Maintenance

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the device. Avoid using harsh chemicals or abrasive materials.
- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security.
- **Storage Management:** Periodically clear unnecessary files and applications to maintain sufficient storage space (128GB internal storage).
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device before the battery level drops too low.

Troubleshooting

Problem	Possible Solution
Device does not power on.	Ensure the battery is charged. Connect the device to a charger for at least 10 minutes, then try powering on again.
Cannot connect to network.	Check SIM card insertion. Verify network compatibility with your carrier. Restart the device.
Apps are slow or crashing.	Close background applications. Clear app cache. Ensure sufficient storage space is available. Restart the device.
Battery drains quickly.	Reduce screen brightness. Disable unnecessary features like GPS or Wi-Fi when not in use. Limit background app activity.

Specifications

Feature	Detail
Model Name	Huawei Nova 10 SE
Operating System	EMUI 12
Processor	Qualcomm Snapdragon 680G 4G (6 nm), Octa-core (4x2.4 GHz Cortex-A73 & 4x1.9 GHz Cortex-A53)
RAM	8 GB
Internal Storage	128 GB (non-expandable via microSDXC)
Display	6.67 inches OLED, 1080 x 2400 pixels
Main Camera	108 MP (wide), 8 MP (ultrawide), 2 MP (macro)

Feature	Detail
Front Camera	16 MP (wide)
Battery	Li-Po 4500 mAh, non-removable
Audio Jack	3.5 mm
Connectivity	Wi-Fi, Cellular (4G/LTE), GPS
SIM Support	Dual SIM (Nano-SIM)
Color	Starry Black
Item Weight	1.1 pounds
First Available Date	February 14, 2023

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official HUAWEI support website. Keep your proof of purchase for warranty claims.
Manufacturer: Huawei
For further assistance, you may contact HUAWEI customer service through their official channels.

© 2024 HUAWEI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question