

[Manuals.plus](#) /

› [Sejoy](#) /

› Sejoy Electric Rotary Shaver User Manual (Model 6970392211831)

Sejoy 6970392211831

Sejoy Electric Rotary Shaver User Manual

Model: 6970392211831

Brand: Sejoy

INTRODUCTION

Thank you for choosing the Sejoy Electric Rotary Shaver. This manual provides essential information for the safe and effective use, maintenance, and care of your new shaver. Please read these instructions thoroughly before first use and retain them for future reference.

SAFETY INFORMATION

Do not use the shaver near water while it is charging. Always ensure the shaver is fully charged before use and allow it to dry completely after washing.

Important: This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

WHAT'S IN THE BOX

- Cordless Electric Shaver
- Instruction Manual
- USB Cable (without adapter)
- Small Cleaning Brush



Image: The Sejoy Electric Rotary Shaver, its packaging, USB charging cable, and cleaning brush.

PRODUCT FEATURES

- **3D Floating Shaving Head:** Equipped with 54 self-sharpening blades and a 0.11mm ultra-thin hypoallergenic stainless steel double cutter net. The 3 sets of 4D floating heads adapt to facial contours for efficient shaving.
- **1 Hour Fast Charging:** USB Type-C charging port allows for convenient charging via car, computer, or power bank. A full charge provides over 90 minutes of continuous use.
- **Pop-up Trimmer:** Integrated trimmer on the back for precise grooming of beards and sideburns.
- **Easy to Clean:** The shaver head can be opened with one touch and rinsed under running water.
- **Self-Sharpening Blades:** Blades automatically sharpen during use, maintaining sharpness and durability.

- **Ergonomic Design:** Designed for comfortable handling and efficient shaving.

DOUBLE-TRACK CLOSE CUTTER

Compared with ordinary single-ring knife net
the shaving area and shaving volume are doubled

18x3 Blades

0.11mm
Thickness

Image: Detail of the double-track close cutter system with 18x3 blades and 0.11mm thickness.



The back of the shaver features pop-up trimmer that open at the touch of a button, making it easy to trim longer beards or shave eyebrows for styling.

Image: Exploded view showing the double-ring blade design and the automatic grinding process.

2 IN 1 Men's Shaver



Image: The shaver demonstrating its 2-in-1 functionality with the pop-up trimmer.



Image: The pop-up trimmer mechanism on the back of the shaver.

HIGH PERFORMANCE MOTOR

Strong motor provides smooth shaving eaperien



Self-sharpening Blade

Image: Diagram illustrating the high-performance motor and self-sharpening blade system.

Package Including



Blackstone 1 x1



Protective cap x1



brush x1



User manuel x1



Power cord x1

SETUP

Initial Charging

1. Before first use, fully charge the shaver. Connect the provided USB cable to the shaver's Type-C port and to a compatible USB power source (e.g., computer, power bank, or a USB wall adapter, not included).
2. The LCD power indicator will show charging status. A full charge takes approximately 1 hour.
3. Once fully charged, the shaver provides over 90 minutes of continuous shaving time.



Image: The shaver being charged via its USB-C port, illustrating its fast charging capability.



Image: Detail of the USB-C charging interface on the shaver.



Image: The intelligent charging system with power indicator light.

OPERATING INSTRUCTIONS

Shaving

1. Ensure the shaver is charged.
2. Press the power button to turn on the shaver.
3. For optimal results, move the shaver in small circular motions against the direction of hair growth. The 3D floating heads will adapt to your facial contours.
4. The shaver can be used for both dry and wet shaving.
5. After shaving, press the power button again to turn off the shaver.

Using the Pop-up Trimmer

1. Locate the pop-up trimmer switch on the back of the shaver.
2. Slide the switch upwards to activate the trimmer.
3. Use the trimmer to shape sideburns, mustaches, or trim longer facial hair.
4. Once finished, slide the switch downwards to retract the trimmer.

Multifunction Shaver



Image: Examples of the shaver's multifunctionality for different shaving needs.

MAINTENANCE

Cleaning the Shaver Head

1. After each use, ensure the shaver is turned off.
2. Press the release button to open the shaver head.
3. Remove the cutter head assembly.
4. Rinse the shaver head and the internal cutting elements thoroughly under running water. You may also use the provided small cleaning brush to remove any trapped hair.
5. Allow all parts to air dry completely before reassembling.
6. Align the cutter head assembly and press it back into place until it clicks securely.

WASHABLE SHAVER HEAD

Easy to Clean



- ① Press the button to open the cutter head
- ② Pull out the cutter head
- ③ After cleaning, insert it back into the fuselage

Image: Visual guide for detaching and rinsing the shaver head under water.



The fuselage is made of Taiwan Chimei ABS shell material, and the head cover part is injection molded by Germany Bayer high-performance PC, which is crafted with care, tightly sewn and durable.

Image: Step-by-step instructions for opening, removing, and cleaning the cutter head.



Image: The split design head being easily removed for washing under a faucet.

TROUBLESHOOTING

- **Shaver not turning on:** Ensure the shaver is fully charged. If the battery is low, the red light may flash. Connect to a power source using the USB cable.
- **Poor shaving performance:** Clean the shaver head thoroughly to remove any hair or debris. Ensure the blades are not damaged. The self-sharpening feature helps maintain blade sharpness over time.
- **Shaver making unusual noise:** Turn off the shaver and clean the head. Check for any obstructions or misaligned parts. If the issue persists, contact customer support.
- **Charging issues:** Verify the USB cable is securely connected to both the shaver and the power source. Try a different USB port or adapter.

SPECIFICATIONS

Feature	Detail
Product Dimensions	2.64 x 3.94 x 7.4 inches
Item Weight	4.94 ounces
Model Number	6970392211831
Batteries	1 Lithium Ion battery (included)
Power Source	Battery Powered
Special Features	Ergonomic Design, Fast Charging, Hypoallergenic, Rechargeable, Self-Sharpening
Recommended Uses	Beard Shaving
Manufacturer	JOYTECH Healthcare Co.,Ltd

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact Sejoy customer service directly. Keep your proof of purchase for any warranty claims.

© 2025 Sejoy. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BHWYPXF4>

More documents and user manuals: <https://manuals.plus/>