

[manuals.plus](#) /› [SCOORNEST](#) /› [SCOORNEST A9 Wireless Mini Security Camera User Manual](#)

SCOORNEST A9

SCOORNEST A9 Wireless Mini Security Camera User Manual

Model: A9

1. INTRODUCTION

Thank you for choosing the SCOORNEST A9 Wireless Mini Security Camera. This manual provides essential information for the safe and effective use of your device. Please read it thoroughly before operation and retain it for future reference. This camera is designed for indoor surveillance, offering features such as 1080P video, motion detection, and mobile app connectivity.

2. PRODUCT OVERVIEW

2.1 Package Contents

Verify that all items are present in your package:

- 1 x SCOORNEST A9 Mini Camera
- 1 x Magnetic Bracket
- 1 x USB Charging Cable
- 1 x User Manual

Multi-scenario use

Protect security and protect property

Home



Baby



Care



Pet



Elderly



Office

Image: The package includes one mini camera, one magnetic bracket, and one USB charging cable.

2.2 Camera Components and Features

The SCOORNEST A9 camera is a compact device with essential features for home security.



Image: The SCOORNEST A9 Mini Camera shown next to a smartphone displaying its live video feed.

Key features include:

- **1080P Full HD Video:** Provides clear and smooth video recording.
- **Motion Detection:** Automatically detects movement and can trigger recording or alerts.
- **WiFi Connectivity:** Connects to your 2.4GHz Wi-Fi network for remote viewing.
- **Wireless Battery Operated:** Allows flexible placement without constant power connection.
- **Night Vision:** Enables monitoring in low-light conditions.
- **Loop Recording:** Supports Micro SD card storage up to 128GB (not included).



Image: Visual representation of the camera's main features: 1080P resolution, motion detection, WiFi connectivity, and wireless battery operation.

3. SETUP GUIDE

Follow these steps to set up your SCOORNEST A9 camera:

3.1 Download the Mobile App

1. Scan the QR code provided in the quick start guide or search for "HDwifCamPro" in the Apple App Store (for iOS devices) or Google Play Store (for Android devices).
2. Download and install the app on your smartphone.

3.2 Connect the Camera to Your Phone

1. Ensure the camera is charged or connected to a power source using the USB cable.
2. Power on the camera using the 'ON/OFF' button.
3. Open the HDwifCamPro app and follow the on-screen instructions to add a new device. This typically involves connecting to the camera's direct WiFi hotspot (usually starting with 'IPC-' or similar) in your phone's WiFi settings, then returning to the app.

3.3 Connect to Home WiFi

1. Once connected to the camera's hotspot, the app will prompt you to connect the camera to your home 2.4GHz Wi-Fi network.
2. Select your Wi-Fi network from the list and enter the password.
3. The camera will then connect to your home Wi-Fi, allowing you to view live video remotely from anywhere.



Image: A visual guide illustrating the three-step process for connecting the camera: downloading the HDwifCamPro app, connecting the camera directly to the phone, and then connecting the camera to a 2.4GHz WiFi network for remote access.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Press and hold the 'ON/OFF' button to power the camera on or off. An indicator light will confirm the status.

4.2 Live View

Once the camera is connected to your Wi-Fi network, open the HDwifCamPro app to access the live video feed. You can monitor your space in real-time.

1080P RESOLUTION

Clear picture and smooth video



Image: A smartphone screen showing a clear and smooth 1080P resolution video feed of a modern living room, demonstrating the camera's video quality.

4.3 Motion Detection

Enable motion detection in the app settings. When motion is detected, the camera can automatically start recording and send push notifications to your phone.

MOTION DETECTION

Sensitive to capture motion



Image: A scene depicting motion detection, where a person is shown in a room, and a red alarm icon signifies that motion has been captured by the camera.

4.4 Night Vision

The camera is equipped with night vision capabilities for monitoring in low-light or dark environments. This feature typically activates automatically or can be toggled in the app.



Image: A split image demonstrating the camera's day and night vision capabilities, showing a child sleeping in color during the day and in black and white with night vision enabled.

4.5 Recording and Storage

Insert a Micro SD card (up to 128GB, not included) into the camera's slot for local storage. The camera supports loop recording, overwriting the oldest footage when the card is full.

4.6 Flexible Placement

The camera's wireless and compact design, along with the magnetic bracket, allows for versatile placement in various indoor settings.



Image: Several mini cameras are shown discreetly placed in different areas of a home, highlighting their wireless and battery-operated nature for flexible installation.

4.7 Multi-Scenario Use

The SCOORNEST A9 camera is suitable for various indoor monitoring needs, including:

- **Home Security:** Monitor entryways, living areas, or valuables.
- **Baby Monitoring:** Keep an eye on infants in their nursery.
- **Pet Monitoring:** Observe pets while away from home.
- **Elderly Care:** Provide surveillance for elderly family members.
- **Office Security:** Monitor small office spaces.

SCOORNEST your dearest friend for home security



Image: A collage demonstrating the camera's versatility across multiple scenarios, including home, baby, car, pet, elderly care, and office environments.

5. MAINTENANCE

5.1 Cleaning

To clean the camera, gently wipe the lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the device.

5.2 Battery Charging

Charge the camera using the provided USB cable and a standard 5V USB power adapter. A full charge typically takes a few hours. The indicator light will change to show charging status.

5.3 Storage

When not in use for extended periods, store the camera in a cool, dry place. Ensure the battery is partially charged to maintain its health.

6. TROUBLESHOOTING

If you encounter issues with your SCOORNEST A9 camera, please refer to the following common problems and solutions:

- Camera not connecting to Wi-Fi:** Ensure your Wi-Fi network is 2.4GHz. Check the Wi-Fi password for accuracy. Restart both the camera and your router.
- No live video feed:** Verify the camera is powered on and connected to your Wi-Fi. Check your phone's internet connection.
- Motion detection not working:** Ensure motion detection is enabled in the app settings. Check the sensitivity level.
- Poor video quality:** Ensure the camera lens is clean. Check your Wi-Fi signal strength; a weak signal can affect video streaming quality.
- Battery life is short:** Battery life can vary based on usage (e.g., continuous recording, frequent

motion detection). Ensure the camera is fully charged before use. For continuous operation, keep it plugged into a power source.

If problems persist, please contact customer support for assistance.

7. SPECIFICATIONS

Feature	Specification
Model Number	A9
Dimensions (L x W x H)	1.69 x 1.69 x 0.87 inches
Item Weight	2.39 ounces
Video Resolution	1080P (2 MP)
Frame Rate	30 fps
Connectivity	Wireless (2.4GHz WiFi)
Power Source	Battery Powered (300mAh)
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant
Storage	Supports Micro SD Card up to 128GB (not included)
Controller Type	Android (compatible with iOS via app)

8. WARRANTY AND SUPPORT

SCOORNEST is committed to providing reliable products and customer satisfaction. This product comes with a **one-year warranty** from the date of purchase and **lifetime after-sales service**.

If you encounter any issues or have questions regarding your SCOORNEST A9 camera, please contact our customer support team. We aim to respond and resolve your concerns within 24 hours.

For support, please refer to the contact information provided with your purchase or on the official SCOORNEST website.