

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HOCANFLO](#) /

› [HOCANFLO Smart Toilet Model 001 \(One Piece\) Instruction Manual](#)

## HOCANFLO 001

# HOCANFLO Smart Toilet Model 001 (One Piece) Instruction Manual

Your guide to installation, operation, and maintenance.

## 1. INTRODUCTION

Thank you for choosing the HOCANFLO Smart Toilet Model 001. This advanced one-piece toilet integrates a bidet with temperature-controlled wash functions, a warm air dryer, and a heated seat for enhanced hygiene and comfort. This manual provides essential information for the proper installation, operation, and maintenance of your new smart toilet. Please read all instructions carefully before use.



*Image 1: HOCANFLO Smart Toilet Model 001 in a modern bathroom setting.*

## **2. SETUP AND INSTALLATION**

The HOCANFLO Smart Toilet is designed for straightforward installation. While professional plumbing assistance is not always required, it is recommended to have two individuals for safe handling due to the product's weight

(approximately 98.8 pounds). Ensure you have a 120V, 15A GFI outlet within 3 feet of the toilet location.

## 2.1 Unpacking

Carefully unbox the smart toilet. The packaging includes the toilet unit, remote control, installation guide, sealing flange, water filter, battery box, floor anchor kit, and an angle valve. Inspect all components for damage before proceeding.

## 2.2 Pre-Installation Checks

- Verify water pressure is between 30-80 PSI.
- Ensure the existing water line connection is compatible. Adapters may be required for non-standard US connections (e.g., 1/4 inch).
- Confirm the availability of a grounded electrical outlet.

## 2.3 Installation Steps

1. **Remove Old Toilet:** Turn off the water supply, flush the old toilet to empty the tank, disconnect the water line, unbolt the toilet, and carefully remove it. Clean the flange area thoroughly.
2. **Install Mounting Bracket:** Secure the provided mounting bracket to the floor flange.
3. **Install Angle Valve:** Connect the new angle valve (included) to your water supply line. Ensure all connections are tight, using Teflon tape if necessary to prevent leaks. The included water lines are labeled 'A' and 'B' for easy connection to corresponding ports on the toilet.
4. **Prepare Toilet:** Install the wax ring onto the base of the new smart toilet, not directly onto the floor flange.
5. **Position Toilet:** Carefully align the smart toilet over the mounting bracket and flange. Apply firm, even pressure to create a secure seal with the wax ring.
6. **Secure Toilet:** Screw the toilet onto the mounting bracket.
7. **Connect Water Lines:** Attach the labeled water lines from the angle valve to the corresponding inlets on the smart toilet.
8. **Connect Power:** Plug the smart toilet into the grounded electrical outlet.
9. **Test Flush:** Turn on the water supply and perform a test flush to check for leaks and proper operation.

Your browser does not support the video tag.

*Video 1: Official HOCANFLO installation guide for the Smart Toilet.*

Your browser does not support the video tag.

*Video 2: Loupusuo Smart Toilet water pipe installation guide.*

# Product Parameters



Image 2: Product dimensions and water connection diagram.

## 3. OPERATING INSTRUCTIONS

Your HOCANFLO Smart Toilet offers a range of automated and customizable features for a personalized experience. Control is available via the integrated controls on the toilet or the convenient remote control.

### 3.1 Automatic Functions

- **Auto Open/Close & Flush:** The lid automatically opens when approached and closes for flushing when you exit. A foot sensor flush option is also available.
- **Heated Seat:** Enjoy a comfortable experience with a heated seat featuring 3 levels of heating.
- **Pre-Wet Bowl:** The bowl is pre-moistened before use to facilitate easier flushing and maintain cleanliness.
- **Air Deodorizer:** An integrated air deodorizer effectively eliminates unpleasant odors.

### 3.2 Bidet Functions

The integrated bidet sprayer delivers fresh, temperature-controlled water for comprehensive front and rear cleansing. The built-in warm air dryer quickly dries the area, reducing the need for toilet paper.

- **Temperature Control:** Adjust water temperature to your preference.
- **Wash Modes:** Multiple water washing modes are available, including bidet washing, feminine washing, mobile cleaning, and self-cleaning.
- **Warm Air Dryer:** Customize warm air drying levels for comfort.

### 3.3 Remote Control


The remote control provides access to all smart toilet functions, including wash settings, temperature adjustments, and flushing options. It also allows for saving up to two user profiles for personalized settings.

## Convenient Flushing



Image 3: Convenient flushing options: foot sensor and off-seat automatic.


# Function Introduction



**Heated Seat**



**Warm Air Drying**



**Water Temperature Regulation**



**Real-time TEMP display**

*Image 4: Key functions including heated seat and warm air drying.*

# Multiple water washing mode



**Bidet washing**



**Feminine washing**



**Mobile cleaning**



**Self cleaning**



## Pre-Wet

Pre-moistened ceramic bowls make flushing easier



## Air Deodorizer

Effectively eliminate unpleasant smells to keep the air fresh



*Image 5: Various bidet washing modes and air deodorizer.*

Your browser does not support the video tag.

*Video 3: HOCANFLO video demonstrating luxury bathroom features like auto-flush and warm air dryer.*

Your browser does not support the video tag.

*Video 4: TDH -US video showcasing smart toilet functions.*

Your browser does not support the video tag.

*Video 5: Vipbear Home video demonstrating smart toilet features including heated seat and dryer.*

Your browser does not support the video tag.

*Video 6: LEIVI T16 Smart Toilet features overview.*

## 4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your HOCANFLO Smart Toilet.

- **Cleaning:** The smooth, crevice-free design of the toilet makes it easy to clean. Use mild, non-abrasive cleaners.
- **Nozzle Cleaning:** The bidet features a self-cleaning function for the nozzle. Refer to the remote control

instructions for activating this feature.

- **Water Filter:** The included water filter helps prevent mineral buildup. Check and replace the filter periodically as recommended in the full user manual.

## 5. TROUBLESHOOTING

If you encounter any issues with your smart toilet, please refer to the following common solutions:

- **No Power:** Ensure the toilet is properly plugged into a working GFI outlet. Check the circuit breaker if necessary.
- **No Water/Weak Spray:** Verify the water supply valve is fully open. Check the water filter for clogs. Ensure water pressure is within the recommended range (30-80 PSI).
- **Leaks:** Tighten all water connections. If leaks persist, re-check the wax ring installation.
- **Remote Not Responding:** Replace the AAA batteries in the remote control. Ensure the remote is within range of the toilet.
- **Power Outage:** The smart toilet includes a backup flush function for uninterrupted use during power outages.

## 6. SPECIFICATIONS

<b>Brand</b>	HOCANFLO
<b>Model Number</b>	001
<b>Color</b>	White
<b>Material</b>	Ceramic, Acrylonitrile Butadiene Styrene
<b>Installation Type</b>	Floor Mounted
<b>Shape</b>	Oval
<b>Item Weight</b>	98.8 pounds
<b>Product Dimensions</b>	15.75 x 15.75 x 15.75 inches
<b>Batteries Included?</b>	Yes
<b>Battery Cell Type</b>	Alkaline

## 7. WARRANTY AND SUPPORT

HOCANFLO guarantees lifetime support for your smart toilet. If you have any questions or require assistance, please do not hesitate to reach out. We aim to respond to all inquiries within 12 hours.

