

[Manuals.plus](#) /

› [ClimaTek](#) /

› ClimaTek Refrigerator Water Valve K-75423 Instruction Manual

ClimaTek K-75423

ClimaTek Refrigerator Water Valve Instruction Manual

MODEL: K-75423

Introduction

This manual provides essential information for the installation, operation, and maintenance of your ClimaTek K-75423 Refrigerator Water Valve. Please read these instructions carefully before proceeding with installation or service to ensure proper function and safety. Retain this manual for future reference.

Product Overview

The ClimaTek K-75423 is a replacement water valve designed for refrigerators, specifically compatible with Kenmore models and others. This component is crucial for controlling the flow of water to the refrigerator's ice maker and water dispenser. It is a high-quality replacement part built for durability and reliable performance.



Image Description: This image displays the ClimaTek K-75423 Refrigerator Water Valve. It features a light yellow plastic body with two

solenoid valves, each having electrical terminals. A metal mounting bracket is attached to the side of the valve, indicating its readiness for installation in a refrigerator.

Key features include:

- Direct replacement for part # K-75423.
- Designed for compatibility with Kenmore and other refrigerator brands.
- Ensures proper water supply to ice makers and dispensers.

Safety Information

WARNING:

- Always disconnect power to the refrigerator before attempting any installation, repair, or maintenance. Failure to do so can result in electric shock, serious injury, or death.
- Shut off the main water supply to the refrigerator before disconnecting any water lines. Failure to do so can result in water damage.
- Wear appropriate personal protective equipment, such as gloves and eye protection, during installation.
- If you are unsure about any step of the installation process, it is recommended to consult a qualified appliance technician.
- Ensure all connections are secure and leak-free before restoring power and water supply.

Installation Instructions

The following steps outline a general procedure for replacing a refrigerator water valve. Specific refrigerator models may vary, so always refer to your appliance's service manual for detailed instructions.

1. Prepare the Refrigerator:

- Unplug the refrigerator from the electrical outlet to disconnect power.
- Turn off the water supply to the refrigerator. This is typically done via a shut-off valve located behind or near the refrigerator, or at the main household water supply.
- Move the refrigerator away from the wall to access the rear panel.

2. Access the Old Water Valve:

- Locate the access panel on the back of the refrigerator, usually at the bottom. Remove the screws securing the panel and set it aside.
- Identify the existing water valve. It will have water lines connected to it (usually a supply line and lines going to the ice maker and dispenser) and electrical wires.

3. Disconnect the Old Valve:

- Place a towel or shallow pan underneath the valve to catch any residual water.
- Carefully disconnect the water lines from the old valve. Note their positions for correct reattachment.
- Disconnect the electrical wiring harness from the old valve.
- Unmount the old valve from its bracket or mounting points.

4. Install the New Water Valve:

- Mount the new ClimaTek K-75423 water valve in the same location as the old one, ensuring it is securely fastened.
- Reconnect the electrical wiring harness to the new valve. Ensure connections are firm.
- Reconnect the water lines to their corresponding ports on the new valve. Hand-tighten connections first, then use a wrench for a snug fit, being careful not to overtighten.

5. **Test for Leaks and Functionality:**

- Turn on the main water supply to the refrigerator.
- Carefully inspect all water line connections for any signs of leaks. Tighten connections if necessary.
- Plug the refrigerator back into the electrical outlet.
- Test the water dispenser and ice maker (if applicable) to ensure water flows correctly and the valve operates as expected.

6. **Final Steps:**

- Once satisfied that there are no leaks and the valve is functioning, replace the rear access panel.
- Push the refrigerator back into its original position.

Operation

The ClimaTek K-75423 Refrigerator Water Valve operates automatically to control the flow of water. When the refrigerator's ice maker calls for water or the water dispenser lever is activated, the valve opens to allow water to pass through. When the demand is met, the valve closes, stopping the water flow. No manual operation is required for this component.

Maintenance

The ClimaTek K-75423 Refrigerator Water Valve is designed for minimal maintenance. However, periodic checks can help ensure its longevity and proper function:

- **Leak Inspection:** Periodically check the water lines and connections around the valve for any signs of leaks or drips. Address any leaks immediately to prevent water damage.
- **Connection Integrity:** Ensure all water line connections remain snug. Avoid overtightening, which can damage fittings.
- **Water Quality:** If your household water supply has high sediment content, consider installing a water filter for your refrigerator's water line to protect the valve and other components from clogging.

Troubleshooting

If you experience issues with your refrigerator's water supply after installing or while using the ClimaTek K-75423 water valve, consider the following:

Problem	Possible Cause	Solution
No water from dispenser or ice maker	• Water supply turned off • Kinked water line • Clogged water filter (if applicable) • Valve solenoid failure • Electrical connection issue	• Ensure water supply is on. • Check water lines for kinks and straighten them. • Replace refrigerator water filter. • Verify electrical connections to the valve. If solenoid is faulty, valve replacement may be necessary.

Problem	Possible Cause	Solution
Water leak around the valve	- Loose water line connections - Cracked water line - Faulty valve body	- Tighten water line connections (do not overtighten). - Inspect water lines for damage and replace if necessary. - If the valve body is cracked, the valve must be replaced.
Low water pressure from dispenser	- Partially closed water supply valve - Clogged water filter - Sediment in water lines or valve	- Ensure water supply valve is fully open. - Replace refrigerator water filter. - Flush water lines or inspect valve for obstructions.

If troubleshooting steps do not resolve the issue, it is recommended to contact a qualified appliance repair technician.

Specifications

Model Number	K-75423
Brand	ClimaTek
Product Dimensions	5 x 5 x 5 inches
Item Weight	12 ounces
Compatibility	Kenmore and other compatible refrigerator models

Warranty and Support

For specific warranty information regarding your ClimaTek K-75423 Refrigerator Water Valve, please refer to the documentation provided with your purchase or visit the official ClimaTek website. For technical support or further assistance, please contact ClimaTek customer service.

Manufacturer: ClimaTek
Date First Available: June 9, 2020

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BJ34ZBJP>

More documents and user manuals: <https://manuals.plus/>