WLIVE ASNG058WXF

WLIVE Wide Dresser with 6 Drawers - Instruction Manual

Model: ASNG058WXF
Brand: WLIVE

Introduction

Thank you for choosing the WLIVE Wide Dresser with 6 Drawers. This versatile furniture piece is designed to provide ample storage and can also serve as a TV stand for televisions up to 50 inches. Its sturdy construction and thoughtful design make it a practical addition to bedrooms, closets, living rooms, hallways, and entryways. Please read this manual carefully before assembly and use to ensure proper setup and long-lasting enjoyment of your new dresser.



Figure 1: Fully assembled WLIVE Wide Dresser in white, showcasing its six fabric drawers and wooden top. Decorative items are placed on top, including books and a vase with flowers.

Safety Information

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload drawers. Each fabric drawer is designed to hold approximately 10 lbs.
- Utilize the included anti-tipping system to secure the dresser to a wall. This is crucial to prevent accidental tipping, especially in households with children or pets.
- Do not allow children to climb on or play with the dresser.
- Keep small parts and packaging materials away from children to avoid choking hazards.

Parts List

Before beginning assembly, please verify that all parts listed below are present and undamaged. Refer to the assembly instructions video for visual guidance on identifying components.

Part	Description	Quantity
Wooden Top	Water-resistant wooden top surface.	1
Steel Frame Components	Various metal bars and connectors for the frame.	Set
Fabric Drawers	Foldable non-woven fabric drawers with handles.	6
Adjustable Feet	Feet for leveling and floor protection.	5
Hardware Kit	Screws, wrench, anti-tipping kit.	1

Setup and Assembly

Assembly is straightforward and all necessary hardware is included. For detailed visual instructions, please refer to the official WLIVE assembly video below.

Your browser does not support the video tag.

Video 1: Official WLIVE Fabric Wide Dresser with 6 Drawers Assembly Instructions. This video provides a step-by-step guide to assembling your dresser, including unboxing, frame construction, and drawer setup.

Step-by-Step Guide:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent damage.
2. **Assemble the Metal Frame:**
   - Connect the vertical and horizontal metal bars using the provided screws and wrench. Ensure all connections are secure.
   - Attach the adjustable feet to the bottom of the frame. These can be adjusted later to level the dresser on uneven surfaces.



Figure 2: Illustration of the dresser's sturdy steel frame construction and the anti-tipping device for enhanced safety.

3. **Attach the Wooden Top:** Secure the water-resistant wooden top to the assembled metal frame using the designated screws.
4. **Prepare Fabric Drawers:**
   - Unfold each fabric drawer. Insert the bottom support panel into each drawer to create a sturdy base.
   - Attach the handles to the front of each fabric drawer.



Figure 3: A view into the spacious fabric drawers, demonstrating their capacity for organizing various items like clothing and blankets.

5. **Insert Drawers:** Slide the assembled fabric drawers into their respective compartments within the metal frame.
6. **Install Anti-Tipping Device:** For safety, install the anti-tipping device according to the instructions provided in the hardware kit. Secure the dresser to a wall to prevent accidental tipping.

Operating Instructions

Using the Drawers:

The six foldable fabric drawers are designed for easy access and organization. Simply pull the handles to open and push to close. Avoid forcing drawers if they feel stuck; ensure they are properly aligned within their compartments.



Figure 4: Detail of the dresser's high-grade wooden top material and one of the adjustable feet, which helps in leveling the unit.

Using as a TV Stand:

The sturdy wooden top can accommodate a TV up to 50 inches. Ensure the TV's base fits securely on the dresser top and does not overhang significantly. For optimal stability, place the TV centrally on the dresser.




Figure 5: Visual guide demonstrating that the dresser is suitable for supporting televisions up to 50 inches, providing a stable surface.

Maintenance

- **Cleaning:** Wipe the wooden top and metal frame with a dry cloth. For the fabric drawers, spot clean with a damp cloth and mild soap if necessary, then air dry completely. Do not machine wash the fabric drawers.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten as needed to maintain stability.
- **Relocation:** If moving the dresser, empty all drawers first to reduce weight and prevent damage. It is lightweight enough for one person to move.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Dresser feels wobbly/unstable.	Loose screws or uneven floor.	Tighten all assembly screws. Adjust the adjustable feet on the bottom until the dresser is stable. Ensure the anti-tipping device is properly installed.
Drawers do not slide smoothly.	Drawer not properly inserted or overloaded.	Remove the drawer and re-insert, ensuring it aligns correctly with the frame. Reduce the weight of items in the drawer.
Missing parts during assembly.	Packaging error.	Contact WLIVE customer support with your purchase details for replacement parts.

Specifications

Brand: WLIVE

Model Name: ASNG058WXF

Product Dimensions: 42.3" L x 15.6" W x 29.8" H

Color: White

Mounting Type: Freestanding (with optional wall mount for anti-tipping)

Room Type: Bedroom, Hallway, Living Room, Office

Special Features: Adjustable feet, Foldable fabric drawers, Removable drawers, Sturdy steel frame, Anti-tipping system

Assembly Required: Yes

Item Weight: 29.7 pounds

Material: Metal frame, Wooden top, Non-woven fabric drawers

TV Compatibility: Up to 50 inches

Warranty and Support

For any questions, concerns, or to report missing/damaged parts, please contact WLIVE customer support. Refer to your purchase documentation or the WLIVE official website for specific warranty details and contact information.
You can also visit the WLIVE Store on Amazon for more product information and support.

© 2023 WLIVE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question