

Noise Noise Twist

Noise Twist Smart Watch User Manual

Model: Noise Twist (wrb-sw-twist-std-blk_blk)

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Noise Twist Smart Watch. Please read it thoroughly before using the device and retain it for future reference.



Image: Front view of the Noise Twist Smart Watch.

2. WHAT'S IN THE BOX

Upon unboxing, verify that all the following items are present:

- Noise Twist Smart Watch
- Magnetic Charger
- User Manual (this document)
- Warranty Card

3. SETUP

3.1 Charging the Smart Watch

Before initial use, fully charge your Noise Twist Smart Watch. Connect the magnetic charger to the charging pins on the back of the watch and plug the USB end into a compatible power adapter (not included) or a computer's USB

port.

3.2 Pairing with Your Smartphone

1. Download the **NoiseFit App** from your smartphone's app store (available for Android and iOS).
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the NoiseFit App and follow the on-screen instructions to create an account or log in.
4. Select 'Add Device' or 'Pair New Device' within the app.
5. The app will search for your Noise Twist Smart Watch. Select it from the list of available devices.
6. Confirm the pairing request on both your watch and smartphone.



Image: Illustration of the pairing process with a smartphone, showing a call screen on the watch.

4. OPERATING INSTRUCTIONS

4.1 Display and Navigation

The Noise Twist Smart Watch features a 1.38-inch TFT round display. Navigate through menus and functions using the touchscreen and the physical push button on the side.




Image: Close-up of the Noise Twist Smart Watch display, highlighting its 1.38-inch TFT round dial.

4.2 Bluetooth Calling (Tru Sync™ & Noise Buzz)

The Tru Sync™ technology enables advanced Bluetooth calling directly from your wrist. The Noise Buzz feature allows you to manage calls efficiently.

- **Making Calls:** Access the dial pad on your watch to initiate calls.
- **Receiving Calls:** Answer or reject incoming calls directly from your watch.
- **Call Logs:** View your recent call history.
- **Contacts:** Save up to 10 favorite contacts for quick access.



Image: A user interacting with the Noise Twist Smart Watch for hands-free calling, showing the call interface.

4.3 Health Monitoring (Noise Health Suite™)

Monitor your health with the integrated Noise Health Suite™:

- **24x7 Heart Rate Monitor:** Tracks your heart rate continuously.
- **Blood Oxygen Monitor (SpO2):** Measures blood oxygen levels.
- **Sleep Monitor:** Analyzes your sleep patterns across four stages.
- **Stress Measurement:** Helps you understand and manage stress levels.
- **Breathe Practice:** Guided breathing exercises for relaxation.
- **Female Cycle Tracker:** Monitors and predicts menstrual cycles.




Image: Display of the Noise Twist Smart Watch showing heart rate and sleep tracking data, illustrating its health monitoring capabilities.

4.4 Sports Modes

The watch supports over 100 sports modes to track various physical activities. Select your preferred mode before starting a workout to get accurate data on calories burned, distance, and heart rate.

4.5 Watch Faces

Personalize your watch with over 100 available watch faces. You can change them via the watch settings or through the NoiseFit App.

Keep up with every call

Access to recent calls




Image: A user wearing the Noise Twist Smart Watch, showcasing different watch faces and indicating the availability of sports modes.

4.6 Productivity Features

Enhance your daily productivity with these features:

- **Notifications:** Receive call, SMS, and app notifications.
- **Quick Reply:** Respond to messages directly from your watch (Android only).
- **Smart DND:** Automatically silences notifications during sleep.
- **Reminder:** Set custom reminders.
- **Calculator:** Basic arithmetic functions.
- **Weather:** Get current weather updates.
- **World Clock:** View time in different time zones.
- **Alarm, Stopwatch & Timer:** Standard timekeeping functions.

4.7 Battery Life

The Noise Twist Smart Watch offers up to 7 days of battery life under typical usage. With Bluetooth calling enabled, the battery life is approximately 2 days.

Faster way to connect

Access to dial pad




Image: The Noise Twist Smart Watch displaying a fully charged battery icon, indicating its long battery life.

4.8 Water Resistance

The device is rated IP68 for water resistance, protecting it from splashes, dust, and moisture. It can withstand immersion in water up to 1.5 meters deep.

Want to upgrade your wrist?

AMOLED display

Screen size

Always on display

Refresh Rate

Bluetooth calling

Twist



○

1.38"

○

30 Hz

✓

Vortex Plus



✓

1.46"

✓

45 Hz

✓

Image: The Noise Twist Smart Watch partially submerged in water, illustrating its IP68 water resistance rating.

5. MAINTENANCE

5.1 Cleaning the Smart Watch

- Wipe the watch and strap regularly with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or solvents.
- Ensure the charging pins are clean and dry before charging.

5.2 Charging Guidelines

- Use only the provided magnetic charger.
- Do not charge the watch in wet conditions.
- Avoid exposing the watch to extreme temperatures during charging.

5.3 Water Resistance Precautions

- The IP68 rating means the watch is resistant to dust and can be immersed in fresh water up to 1.5 meters for 30 minutes. It is not suitable for hot water baths, saunas, or diving.
- Avoid exposing the watch to high-velocity water or sudden temperature changes.
- Dry the watch thoroughly after exposure to water.

6. TROUBLESHOOTING

If you encounter issues with your Noise Twist Smart Watch, refer to the following common solutions:

Problem	Possible Solution
Watch not turning on	Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
Unable to pair with phone	Check if Bluetooth is enabled on your phone. Restart both the watch and phone. Ensure the NoiseFit App is updated. Try unpairing and re-pairing.
Inaccurate health data	Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensor on the back of the watch. Avoid excessive movement during measurements.
Short battery life	Reduce screen brightness. Limit continuous heart rate monitoring. Turn off unnecessary notifications. Disable Bluetooth calling if not in use.
Notifications not received	Check app permissions for NoiseFit App on your phone. Ensure notifications are enabled in both the phone settings and the NoiseFit App. Disable Smart DND if active.

7. SPECIFICATIONS

Detailed technical specifications for the Noise Twist Smart Watch:

Feature	Detail
Model Name	Noise Twist
Model Number	wrb-sw-twist-std-blk_blk
Display	1.38 inch TFT LCD, 240 x 280 Resolution, 550 Nit Max Brightness
Connectivity	Bluetooth v5.3 (Tru Sync™)
Operating System Compatibility	Android, iOS
Battery Capacity	300 mAh Lithium Ion
Battery Life	Up to 7 days (typical usage), Up to 2 days (with calling enabled)
Water Resistance	IP68 (Water Resistant up to 1.5 meters)
Sensors	Heart Rate Monitor, SpO2 (Oxymeter), Sleep Tracking, Stress Tracking
Sports Modes	100+

Feature	Detail
Band Material	Silicone
Case Material	Polycarbonate
Dimensions	47 x 39 x 12 Millimeters
Weight	45 Grams
Manufacturer	Nexxbase Marketing Pvt. Ltd
Country of Origin	China

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your Noise Twist Smart Watch comes with a **1-year limited warranty** provided by the manufacturer from the date of purchase. Please refer to the included Warranty Card for full terms and conditions.

8.2 Customer Support

For any queries, technical assistance, or warranty claims, please contact Noise customer support:

- **Email:** help@nexxbase.com
- **Phone:** 02268056040

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question