

[Manuals.plus](#) /

> [WLIVE](#) /

> WLIVE LED TV Stand Instruction Manual

WLIVE ADSG027DHS

WLIVE LED TV Stand Instruction Manual

Model: ADSG027DHS

1. INTRODUCTION

Thank you for choosing the WLIVE LED TV Stand. This modern entertainment center is designed to enhance your living space with its sleek design, ample storage, and customizable LED lighting. Please read this manual carefully before assembly and use to ensure proper setup and safe operation.

2. SAFETY INFORMATION

WARNING: This TV stand requires proper assembly to ensure stability. Do not place heavy items on the top shelves. The stand can support up to 150 lbs and is suitable for TVs up to 65 inches. Always ensure the stand is level and stable before use. Keep children and pets away from the stand during assembly and while in use.

- Ensure all parts are present and undamaged before beginning assembly.
- Follow all assembly steps precisely as outlined in the instructions.
- Do not overtighten screws, as this may damage the material.
- Place the TV stand on a flat, level, and stable surface.
- Distribute weight evenly across shelves.
- Keep electrical components (LED lights) away from water.

3. PACKAGE CONTENTS

Please verify that all components listed below are included in your package. If any parts are missing or damaged, please contact WLIVE customer support.

- All necessary hardware for assembly
- Particle board panels
- Tempered glass shelves (3)
- LED light strips (2)
- Remote control for LED lights
- Instruction manual




Figure 3.1: Illustration of all included parts and hardware for assembly.

4. SPECIFICATIONS

Feature	Detail
Brand	WLIVE
Model Number	ADSG027DHS
Color	Rustic Brown
Dimensions (L x W x H)	58.3" x 15.4" x 20.8" (58.26 x 15.43 x 20.82 inches)
Item Weight	52.4 pounds
Max TV Size Supported	Up to 65 inches

Max Load Weight	150 lbs
Number of Shelves	3 (Adjustable Glass Shelves)
LED Lights	2 LED strips, 20 colors, 22 dynamic modes, 5 adjustable levels
Material	Engineered Wood, Tempered Glass
Assembly Required	Yes



Max Weight Capacity

PRODUCT SIZE



Battery CR2025 Required




Figure 4.1: Detailed product dimensions and maximum weight capacity.

5. SETUP AND ASSEMBLY

The WLIVE LED TV Stand is designed for easy assembly. Please follow the step-by-step instructions provided in the included assembly guide. It is recommended to have two people for assembly.

5.1 Before You Begin

- Clear a spacious area for assembly.
- Lay out all parts and hardware and compare them with the package contents list.
- Keep small parts out of reach of children.

5.2 Assembly Steps (General Overview)

1. Assemble the main frame of the TV stand using the provided screws and connectors.
2. Install the adjustable glass shelves into the designated slots. The shelves can be adjusted to three different levels to accommodate various item heights.
3. Attach the LED light strips to the interior of the open compartments.
4. Ensure all connections are secure and the stand is stable before placing any items on it.



Figure 5.1: Illustration of the 3-level adjustable glass shelves.




Figure 5.2: Overview of the sturdy structure, waterproof wood, and tempered glass features.

6. OPERATING THE LED LIGHTS

The WLIVE LED TV Stand features built-in LED lights with customizable settings to create the perfect ambiance.

6.1 Remote Control Functions

Use the provided remote control to manage the LED lighting. Ensure the remote control battery (CR2025, not included) is properly installed.

- **Power Button:** Turn the LED lights On/Off.
- **Color Selection:** Choose from 20 main colors.
- **Mode Selection:** Select from 22 dynamic modes (e.g., flash, strobe, fade, smooth).
- **Brightness Adjustment:** Adjust the light intensity across 5 adjustable levels.
- The remote control has an effective distance of up to 15 meters.



**SAME STYLE OF FIREPLACE TV
STAND FOR YOU TO SELECT**



Figure 6.1: Remote control for LED lights and available color/mode options.

Your browser does not support the video tag.

Video 6.1: Demonstration of the WLIVE TV Stand with LED Lights, showcasing various lighting effects and features.

7. MAINTENANCE

To ensure the longevity and appearance of your WLIVE LED TV Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. The open design facilitates easy cleaning.
- **Dusting:** Regularly dust the stand and shelves to prevent buildup.
- **Spills:** Immediately wipe up any spills to prevent damage to the engineered wood.
- **LED Lights:** The LED strips are designed for long-term use. If issues arise, contact customer support. Do not attempt to repair them yourself.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight and secure.

8. TROUBLESHOOTING

If you encounter any issues with your WLIVE LED TV Stand, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Stand is wobbly/unstable	Loose screws; uneven floor	Tighten all assembly screws. Ensure the stand is on a level surface.
LED lights not working	Remote battery dead; loose connection; power issue	Replace remote battery (CR2025). Check all LED strip connections. Ensure power adapter is plugged in.
Remote not responding	Battery dead; remote too far; obstruction	Replace remote battery. Ensure you are within 15m range and there are no obstructions between remote and receiver.
Missing parts during assembly	Packaging error	Contact WLIVE customer support with your purchase details.

9. WARRANTY AND SUPPORT

WLIVE stands behind the quality of its products. For warranty information, returns, or any product-related inquiries, please contact WLIVE customer support directly. You can find contact information on the WLIVE official website or through your purchase platform.

For additional support and product information, visit the official WLIVE store:[WLIVE Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BJ73DHVS>

More documents and user manuals: <https://manuals.plus/>