

Zyyini Zyyini-5Inch-2018

Zyyini 5-Inch Portable Digital TV User Manual

INTRODUCTION

This manual provides comprehensive instructions for the Zyyini 5-Inch Portable Digital TV. It covers essential information regarding product features, proper setup, operational procedures, routine maintenance, and troubleshooting common issues. Please read this manual thoroughly before using the device to ensure safe and optimal performance.

SAFETY INFORMATION

- Do not expose the device to water or excessive moisture.
- Use only the provided power adapter to charge the device.
- Keep the device away from direct sunlight and heat sources.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Keep out of reach of small children.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Zyyini 5-Inch Portable Digital TV
- Remote Control
- AAA Batteries (2 for remote control)
- Power Adapter
- Portable Telescopic Antenna
- External Antenna with Magnetic Base

Color Mini TV



High sensitivity tuner
Equipped with suitable stand
Can better watch clear content, comfortable and labor-saving

Image: The Zyyini 5-Inch Portable Digital TV shown with its complete set of accessories, including the remote control, power adapter, and both the portable telescopic antenna and the external antenna with a magnetic base.

PRODUCT OVERVIEW

The Zyyini 5-Inch Portable Digital TV is a versatile device designed for entertainment on the go. It features a 5-inch 1080p LED display, supports ATSC digital TV, analog TV, and ATV signals, and includes a built-in media player for USB and TF card content. Its compact design and rechargeable battery make it ideal for travel, camping, and outdoor use.

Zyyini 5inch Portable Digital TV



Mini TV



ATV/VHF/UHF



Antennas



1500mAh Battery



Image: The portable TV in an outdoor setting, demonstrating its use for receiving ATV/VHF/UHF channels.

5inch Mini Digital TV

Lightweight | Portable



Image: The compact Zyyini 5-Inch Portable Digital TV fits easily into luggage, emphasizing its portability for travel.



Image: A side view of the TV, illustrating the control buttons, USB port, and TF card slot for media playback.

SETUP

1. Charging the Battery

Before first use, fully charge the integrated 1500mAh rechargeable lithium battery. Connect the provided power adapter to the DC IN port on the TV and plug it into a standard electrical outlet. The charging indicator will illuminate.

2. Connecting the Antenna

The TV includes both a portable telescopic antenna and an external antenna with a magnetic base. For initial setup, screw the portable telescopic antenna into the antenna port. For improved reception, especially indoors or in areas with weak signals, connect the external antenna. Extend the antenna fully and position it for best signal reception.

Your browser does not support the video tag.

Video: This video demonstrates how to attach and extend the portable antenna, highlighting the TV's capability to receive analog and digital TV signals, as well as FM radio.

3. Powering On/Off

Press and hold the power button on the TV or press the power button on the remote control to turn the device on or off.

4. Initial Channel Scan

After powering on, navigate to the 'Menu' using the remote control. Select 'Channel Setup' or 'Auto Scan' to automatically search for and store available digital (ATSC) and analog channels. This process may take several minutes.

OPERATING INSTRUCTIONS

1. Basic TV Functions

- **Channel Selection:** Use the CH+ and CH- buttons on the remote or the TV to change channels.
- **Volume Control:** Adjust the volume using the VOL+ and VOL- buttons on the remote or the TV.
- **Input Source:** Press the 'Input' or 'Source' button on the remote to switch between TV, USB, and TF card modes.

2. Media Playback (USB & TF Card)

Insert a USB flash drive into the USB port or a TF (Micro SD) card into the TF CARD slot. Switch the input source to 'USB' or 'TF Card'. The TV supports 1080p video playback and various formats including MKV, MOV, AVI, WMV, MP4, FLV, MPEG1-4, and MP3 audio files. Ensure your storage device is formatted to FAT32 for optimal compatibility.



Image: A close-up of the TV's side panel, highlighting the USB port and TF card slot for external media playback.

3. Remote Control Usage

The remote control allows for convenient operation of all TV functions. Ensure the two AAA batteries are correctly inserted. Point the remote control directly towards the TV's infrared receiver for proper functionality.

MAINTENANCE

1. Cleaning

To clean the screen, gently wipe it with a soft, dry, lint-free cloth. For the casing, use a slightly damp cloth and then dry thoroughly. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the surface.

2. Battery Care

To maximize the lifespan of the built-in lithium battery, avoid fully discharging it frequently. Recharge the

battery when the low battery indicator appears. Store the TV in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

- **No Power:** Ensure the power adapter is securely connected and plugged into a working outlet. Check if the internal battery is charged.
- **No Signal or Poor Reception:** Adjust the position and orientation of the antenna. Perform a channel scan again. Try using the external antenna for better signal strength.
- **Media Files Not Playing:** Verify that the USB drive or TF card is formatted to FAT32. Check if the media files are in supported formats (MKV, MOV, AVI, WMV, MP4, FLV, MPEG1-4, MP3).
- **Remote Control Not Responding:** Ensure the remote control batteries are correctly inserted and not depleted. Replace batteries if necessary. Make sure there are no obstructions between the remote and the TV's IR sensor.
- **Audio/Video Out of Sync:** If this occurs, try turning the TV off and then on again.

SPECIFICATIONS

Feature	Specification
Screen Size	5 Inches
Display Technology	LED
Resolution	1080p
Refresh Rate	60 Hz
Tuner Type	ATSC, Analog, Digital
Battery	1500mAh Rechargeable Lithium
Connectivity	USB
Audio Output Ports	1
Speaker	2W built-in speakers
Item Weight	0.52 Kilograms
Model Number	Zyyini-5Inch-2018
Voltage	12 Volts
Power Consumption	2 Watts

WARRANTY AND SUPPORT

The Zyyini 5-Inch Portable Digital TV comes with a limited warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact your retailer. For product support, inquiries, or additional assistance, please visit the official Zyyini brand store or contact customer service through the details provided at the point of purchase.

Zyyini Brand Store: <https://www.amazon.com/stores/Zyyini/page/7A3A16FD-50E2-459F-85A7-4CF8D1D47F17>

