

## Farberware 22309

# Farberware Cookstart DiamondMax Nonstick Cookware Set

Model: 22309

## INTRODUCTION

The Farberware Cookstart 15-Piece DiamondMax Nonstick Cookware Set is designed to provide convenience and reliability for everyday cooking. This comprehensive set includes essential pots, pans, and kitchen tools, featuring durable aluminum construction and advanced nonstick interiors for easy food release and cleanup. Suitable for various cooking tasks, from simmering sauces to baking, this set is a versatile addition to any kitchen.



Image: The complete Farberware Cookstart 15-Piece DiamondMax Nonstick Cookware Set, showcasing various pots, pans, and a baking sheet.

## WHAT'S INCLUDED

This 15-piece set provides a comprehensive collection of cookware and essential kitchen tools:

- 1-Quart Covered Saucepan
- 2-Quart Covered Straining Saucepan
- 5-Quart Covered Dutch Oven
- 8-Inch Skillet
- 9.75-Inch Skillet
- 9-Inch by 13-Inch Cookie Sheet
- Six Prestige Nylon Tools:
  - Slotted Turner

- Slotted Spoon
- Solid Spoon
- Pasta Fork
- Whisk
- Ladle



8 in Fry Pan



9.75 in Fry Pan



1 Qt Saucepan with Lid



2 Qt Straining Saucepan with Lid



5 Qt Dutch Oven with Lid



9 in x 13 in Cookie Pan



Includes 6 Prestige® Kitchen Tools:  
Whisk, Pasta Fork, Solid Spoon,  
Slotted Turner, Slotted Spoon, Ladle

## What's Included

**FARBERWARE®**

Image: A visual breakdown of all components included in the Farberware Cookstart 15-piece set, detailing each pot, pan, baking sheet, and kitchen tool.

### SETUP AND FIRST USE

- Unpack:** Carefully remove all cookware and tools from the packaging.
- Wash Before First Use:** Before using for the first time, wash all pieces in warm, soapy water. Rinse thoroughly and dry completely. This removes any manufacturing residues.
- Seasoning (Optional but Recommended):** For enhanced nonstick performance and longevity, lightly coat the

interior of the nonstick pans with a small amount of cooking oil (e.g., vegetable, canola, or grapeseed oil) using a paper towel. Heat the pan over low heat for 30 seconds, then remove from heat and wipe off any excess oil. Repeat this process periodically.

## OPERATING INSTRUCTIONS

---

### Cooking with Your Cookware

- **Heat Settings:** Use low to medium heat settings for most cooking. High heat can damage the nonstick coating over time and is generally not necessary due to the aluminum's excellent heat distribution. Match the pan bottom to the burner size for efficient heating.
- **Oil/Butter Use:** While the DiamondMax nonstick surface allows for cooking with little to no oil, using a small amount of butter or oil is recommended for best cooking results and flavor. Avoid aerosol cooking sprays as they can leave a residue that is difficult to remove and may affect nonstick performance.
- **Utensils:** Always use nylon, plastic, silicone, or wooden utensils to protect the nonstick surface. Metal utensils can scratch and damage the coating.
- **Oven Safety:** The pots and pans are oven safe up to 350°F (175°C). Glass lids are also oven safe to this temperature.
- **Lids:** The shatter-resistant glass lids allow you to monitor cooking progress without lifting the lid, helping to retain heat and moisture.

# DURABLE CONSTRUCTION



**HEAVY-DUTY ALUMINUM  
FOR FAST AND EVEN HEATING**

**FARBERWARE®**

Image: A Farberware pan on a gas stove, demonstrating the durable construction and even heat distribution during cooking.

# DIAMONDMAX™ NONSTICK



**EASY RELEASE AND  
ENHANCED DURABILITY**

**FARBERWARE®**

Image: Two fried eggs in a Farberware nonstick pan, illustrating the easy food release provided by the DiamondMax nonstick coating.

## MAINTENANCE AND CARE

### Cleaning Instructions

- **Dishwasher Safe:** The entire cookware set, including glass lids, is dishwasher safe for convenient and effortless cleanup.
- **Hand Washing:** For best results and to prolong the life of your cookware, hand washing with warm, soapy water and a soft sponge or cloth is recommended.
- **Stubborn Food:** If food is stuck, fill the pan with warm water and a small amount of dish soap, let it soak for a few minutes, then clean with a soft sponge. Do not use abrasive cleaners, steel wool, or scouring pads, as these can damage the nonstick surface.
- **Avoid Oven Cleaners:** Never use oven cleaners on your nonstick cookware.

# EASY CLEAN DISHWASHER SAFE



**FOR CONVENIENT AND  
EFFORTLESS CLEANUP**

**FARBERWARE®**

Image: Farberware pots and pans placed in a dishwasher, highlighting their dishwasher-safe feature for easy cleaning.

## Storage

- Store cookware carefully to prevent scratching the nonstick surface. Place a paper towel or soft cloth between stacked pans.

# FARBERWARE®

Farberware understands the true value of a home cooked meal. We've been welcomed into the kitchens of families big and small for over 120 years, helping them put their best meal on the table night after night.

So when you're cooking for your family, remember:

**Cook with love, cook with Farberware.**



Image: An infographic providing key tips for maximizing the life of your Farberware pan, including matching burner size, using low heat, avoiding cooking sprays, and proper cleaning.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Food sticking to nonstick surface	High heat, use of cooking sprays, damaged coating, insufficient oil/butter.	Use low to medium heat. Avoid cooking sprays. Ensure proper seasoning. Use a small amount of oil or butter. Avoid metal utensils.
Pan warping or deforming	Sudden temperature changes (e.g., hot pan under cold water), excessive high heat.	Allow pans to cool completely before washing. Use only low to medium heat settings.
Handles becoming hot during stovetop use	Heat source too high or flame extending up the sides of the pan.	Ensure flame/heat source is confined to the bottom of the pan. Use oven mitts or pot holders if handles become hot.

## SPECIFICATIONS

Feature	Detail
Model Number	22309
Material	Heavy-Duty Aluminum
Nonstick Coating	DiamondMax™ Nonstick
Color	Black
Oven Safe Temperature	Up to 350°F (175°C)
Dishwasher Safe	Yes
Handle Type	Dual-Riveted, Comfortable Grip

Feature	Detail
Lid Type	Shatter-Resistant Glass
Item Weight (Set)	8.2 Pounds
UPC	631899223098



**FDA COMPLIANT  
NONSTICK IS FOOD  
CONTACT SAFE**



**PANS AND LIDS  
OVEN SAFE  
TO 350°F**



**STAY COOL  
HANDLES**

UNDER NORMAL STOVETOP USE



**DISHWASHER  
SAFE**

## **LIMITED LIFETIME WARRANTY**

Image: An overview of key product features, including FDA compliance, oven safety, stay-cool handles, dishwasher compatibility, and the limited lifetime warranty.

### **WARRANTY AND SUPPORT**

Farberware Cookstart cookware comes with a **Limited Lifetime Warranty**, ensuring quality and durability. For warranty claims, product support, or any inquiries, please refer to the official Farberware website or contact their customer service directly.


For more information, visit the [Farberware Store on Amazon](#).

## Related Documents

	<p><a href="#">Farberware FCD06ASWWHC Countertop Dishwasher Instruction Manual</a> Your guide to the Farberware FCD06ASWWHC Professional 6-Piece Countertop Dishwasher. This manual provides essential safety, installation, operation, and maintenance instructions for optimal performance and care of your appliance.</p>
	<p><a href="#">Farberware FDW05ASBWHA Complete Portable Countertop Dishwasher: Use and Care Manual</a> Comprehensive use and care manual for the Farberware Professional 5-Liter Complete Portable Countertop Dishwasher (Model FDW05ASBWHA). Includes safety instructions, features, specifications, operating guides, loading tips, maintenance, troubleshooting, and warranty information.</p>
	<p><a href="#">Farberware Professional 5-Liter Complete Portable Countertop Dishwasher Use and Care Manual</a> This manual provides comprehensive instructions for the Farberware Professional 5-Liter Complete Portable Countertop Dishwasher, covering safety guidelines, operation, features, maintenance, and troubleshooting tips.</p>
	<p><a href="#">Farberware FCD06ABBWHA Countertop Dishwasher User Manual</a> User manual for the Farberware FCD06ABBWHA 6-place setting countertop dishwasher. Contains safety instructions, operation guides, maintenance tips, troubleshooting advice, and warranty details for optimal appliance use.</p>

Documents - Farberware – 22309






### [\[pdf\] User Manual Catalog](#)

Housewares Catalogue November 2022 min 11 17 — CM0916W 12 Cup Coffee Maker w Permanent Filter White Black Decker 2 CS 10561261 4L Manual Air Fryer brydenst |||

TABLE OF CONTENTS Affresh ..... ....

Farberware 1/CS 10903016 22320 Cookstart 15pc Pot Gadget Set Red Farberware 1/CS 10903017 **22309** Cookstart 15pc Pot Gadget Set Black Farberware 1/CS 10903019 22304 Cookstart 15pc Pot ...

lang:de score:21 filesize: 2.55 M page\_count: 40 document date: 2022-11-17



### [Brydens Housewares Catalogue - April 2023](#)

Discover a comprehensive collection of housewares and small appliances from leading brands such as Black+Decker, Hamilton Beach, Oster, Rubbermaid, and more, featured in the Brydens April 2023 catalogue. Find kitchen essentials, cleaning tools, storage solutions, and personal care appliances.

lang:de score:13 filesize: 2.88 M page\_count: 40 document date: 2023-04-18